chefess ME-L1518

chefess Glass Electric Water Kettle ME-L1518 User Manual

Model: ME-L1518 | Brand: chefess

Introduction

Thank you for purchasing the chefess Glass Electric Water Kettle. This manual provides important information for the safe and efficient operation of your new appliance. Please read it thoroughly before first use and keep it for future reference. This kettle features a 1.8L capacity, 12-level temperature control, a tea infuser, and a 24-hour keep-warm function, designed for versatility and convenience in preparing various hot beverages.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then

remove plug from wall outlet.

- Do not use appliance for other than intended use.
- Extreme caution must be used when moving an appliance containing hot water.
- The kettle must only be used with the stand provided.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

Product Components

Familiarize yourself with the parts of your chefess Electric Water Kettle.



Image: The chefess Glass Electric Water Kettle, showing its transparent glass body, stainless steel base, handle with control panel, and

removable tea infuser. A close-up of the control panel with temperature display is also visible.

1. Glass Kettle Body (Borosilicate Glass)
2. Lid (304 Stainless Steel inner lid)
3. Handle
4. Control Panel with Digital Display
5. Power Base (304 Stainless Steel heat panel)
6. Removable Tea Infuser (304 Stainless Steel)
7. Water Level Markings (MIN, 0.5L, 1.0L, 1.5L, MAX 1.8L)
8. Blue LED Indicator Light



Image: A detailed breakdown of the kettle's superior materials, highlighting the 304 Stainless steel inner lid, 304 Stainless steel infuser, high borosilicate glass body, and 304 Stainless steel heat panel.

Setup and First Use

1. **Unpacking:** Carefully remove the kettle and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, fill the kettle with clean water to the MAX line. Boil the water (see "Operating Instructions" for details), then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a dry, flat, stable, and heat-resistant surface, away from the edge of the counter. Ensure the power cord is not dangling or touching hot surfaces.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

Operating Instructions

Filling the Kettle

- Open the lid.
- Fill the kettle with fresh, cold water. Do not fill below the MIN mark or above the MAX (1.8L) mark. Overfilling may cause boiling water to spill out.
- Close the lid securely.

Basic Boiling Function

1. Place the filled kettle onto the power base.
2. Press the power button ( ) on the handle. The display will light up.
3. To boil water to 100°C (212°F), simply press the boil button (often indicated by a wave or boil icon). The kettle will start heating, and the blue LED light will illuminate.
4. Once the water reaches boiling point, the kettle will automatically shut off, and the LED light will turn off.

Temperature Control Function

This kettle offers 12 precise temperature settings for various beverages.



Image: The kettle's control panel displaying various temperature presets for different drinks like Lemon Water (40°C), Milk Powder (45°C), Honey Water (55°C), Green Tea (80°C), White Tea (85°C), French Press Coffee (90°C), and Black Tea (100°C).

1. Place the filled kettle onto the power base.
2. Press the power button ( ).
3. Use the temperature selection buttons (often indicated by '+' or '-' or a specific temperature icon) to cycle through the desired temperature settings (e.g., 40°C, 45°C, 55°C, 80°C, 85°C, 90°C, 100°C).
4. Once the desired temperature is selected, the kettle will begin heating. The blue LED light will illuminate.
5. The kettle will automatically shut off once the target temperature is reached.

Keep Warm Function (24-Hour)

The kettle can maintain your selected temperature for up to 24 hours.



Image: A woman relaxing and reading a book, with the chefess kettle on a side table, illustrating the convenience of the flexible keep warm function, which can maintain temperature for up to 24 hours.

1. After selecting your desired temperature and the kettle has reached it, activate the "Keep Warm" function (often indicated by a specific button or icon, e.g., a wavy line or "Keep Warm").
2. The kettle will then maintain the water at the set temperature for up to 24 hours.
3. To deactivate, press the power button or lift the kettle from its base.

Using the Tea Infuser

The integrated stainless steel tea infuser allows for direct brewing of loose leaf teas.



Image: A visual guide demonstrating the steps to use the tea infuser: 1. Inserting the infuser, 2. Adding loose leaf tea, 3. Filling the kettle with water, 4. Brewing, and 5. Pouring the brewed tea.

1. Remove the tea infuser from the kettle.
2. Open the infuser and add your desired amount of loose leaf tea. Do not overfill.
3. Close the infuser and place it back into the kettle.
4. Fill the kettle with water to the desired level.
5. Select the appropriate temperature for your tea (e.g., 80°C for green tea, 100°C for black tea).
6. Once the water reaches the set temperature, allow the tea to steep for the recommended time.
7. Carefully remove the infuser using its handle to prevent over-steeping. Be cautious as the infuser will be hot.
8. Enjoy your freshly brewed tea.

Care and Maintenance

Cleaning the Kettle

- Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
- Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- The interior of the kettle can be cleaned with a soft brush or sponge.
- The tea infuser can be removed and rinsed under running water. For thorough cleaning, use a small brush to remove tea residues.
- Never immerse the kettle body or power base in water or any other liquid.

Descaling

Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. This can affect performance and taste. Descale your kettle regularly.

1. Fill the kettle with a mixture of 1 part white vinegar and 2 parts water, or use a commercial descaling solution according to its instructions.
2. Bring the mixture to a boil.
3. Allow the mixture to soak in the kettle for at least 30 minutes, or longer for heavy scale.
4. Empty the kettle and rinse thoroughly with fresh water several times to remove any vinegar odor or descaling solution residue.
5. If necessary, boil clean water in the kettle and discard it to ensure all residues are gone.

Troubleshooting

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in; power outage; kettle not properly seated on base; faulty outlet.	Ensure plug is securely in outlet. Check power supply. Re-seat kettle on base. Try a different outlet.
Kettle boils slowly or does not reach desired temperature.	Limescale buildup; incorrect temperature setting.	Descale the kettle (see "Care and Maintenance"). Verify the correct temperature setting is selected.
Kettle leaks.	Overfilled; lid not closed properly; damage to kettle.	Do not fill above the MAX line. Ensure lid is securely closed. If damage is suspected, discontinue use and contact customer support.
Automatic shut-off not working.	Kettle is faulty.	Discontinue use immediately and contact customer support.
Water tastes strange.	New kettle residue; limescale buildup.	Perform initial cleaning steps again. Descale the kettle.

Specifications

Feature	Detail

Feature	Detail
Model	ME-L1518
Brand	chefess
Capacity	1.8 Liters (60.8 oz)
Power / Wattage	1000 watts
Voltage	120 Volts
Material	Borosilicate Glass, 304 Stainless Steel
Color	Black
Product Dimensions	21.34 x 13.21 x 23.88 cm
Item Weight	1.52 Kilograms
Auto Shutoff	Yes
Keep Warm Function	Up to 24 hours
Temperature Control	12 levels (40°C to 100°C)

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or contact chefess customer service. Please have your model number (ME-L1518) and purchase date available when contacting support.
Keep your purchase receipt as proof of purchase for warranty claims.

© 2025 chefess. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question