Noble Noble FoKus Kama

Noble FoKus Kama Wireless Open-Ear Headphones User Manual

1. INTRODUCTION

Thank you for choosing the Noble FoKus Kama Wireless Open-Ear Headphones. These headphones are designed to provide a high-resolution audio experience while maintaining situational awareness, allowing you to enjoy your music without completely isolating yourself from your surroundings. This manual will guide you through the setup, operation, and maintenance of your new headphones.

2. WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- Kama Headphones (Left and Right)
- Charging Case
- USB-C Charging Cable
- Instruction Manual

The Noble FoKus Kama headphones are shown alongside their open charging case, revealing the earbuds nestled inside.

3. PRODUCT OVERVIEW

The Noble FoKus Kama headphones feature an open-ear design for comfort and awareness. Each earbud is equipped with touch controls for easy management of audio and calls. The compact charging case provides additional battery life and protects your headphones when not in use.

Components

- **Open-Ear Design:** Allows ambient sound to be heard for situational awareness.
- **Touch Controls:** Integrated on each earbud for media playback, call management, and volume adjustment.
- **Charging Contacts:** Located on the earbuds and within the case for secure charging.
- **USB-C Charging Port:** On the charging case for convenient power input.
- **LED Indicator:** On the charging case to show charging status and battery level.

An exploded diagram illustrates the internal components of a Noble FoKus Kama earbud, including the driver, battery, and circuit board.

4. SETUP

4.1 Initial Charging

1. Place both Noble FoKus Kama earbuds into the charging case.
2. Connect the USB-C charging cable to the charging port on the case and plug the other end into a compatible USB power source (e.g., computer, wall adapter).
3. The LED indicator on the charging case will illuminate to show charging status. Allow the headphones and case to fully charge before first use.

4.2 Powering On/Off

- **Power On:** The earbuds will automatically power on when removed from the charging case.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging.

5. OPERATION

5.1 Bluetooth Pairing

1. Ensure the earbuds are charged and removed from the charging case. They will automatically enter pairing mode, indicated by a flashing LED light (refer to the specific LED pattern in the included manual for details).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.

3. Select "Noble FoKus Kama" from the list of found devices.
4. Once connected, the LED indicator on the earbuds will change (refer to the specific LED pattern in the included manual for details), and you will hear an audible confirmation.

5.2 Touch Controls

The Noble FoKus Kama headphones feature intuitive touch controls on each earbud. Specific functions may vary, but generally include:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Volume Control:** Typically a long press or multiple taps on specific earbuds (refer to the detailed instructions in the included manual for precise control mapping).

5.3 Charging the Earbuds and Case

- **Earbuds:** Place the earbuds into the charging case. They will automatically charge from the case's internal battery.
- **Charging Case:** Connect the USB-C cable to the case and a power source. The LED indicator will show the charging status.

6. MAINTENANCE

To ensure the longevity and optimal performance of your Noble FoKus Kama headphones, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the earbuds and charging case. Avoid using abrasive materials or harsh chemicals.
- **Storage:** When not in use, store the headphones in their charging case to protect them from dust and damage.
- **Avoid Water:** The headphones are not water-resistant. Avoid exposure to liquids.
- **Temperature:** Do not expose the headphones to extreme temperatures (hot or cold).

7. TROUBLESHOOTING

If you encounter issues with your Noble FoKus Kama headphones, try the following solutions:

Problem	Solution
Headphones not powering on	Ensure earbuds and charging case are fully charged. Place earbuds in case, close lid, then reopen and remove.
Unable to pair with device	Make sure Bluetooth is enabled on your device. Ensure earbuds are in pairing mode. Forget the device in your Bluetooth settings and try pairing again.
No sound or low volume	Check device volume and headphone volume. Ensure earbuds are properly seated in your ears. Re-pair the headphones.

Problem	Solution
Touch controls not responding	Ensure your fingers are clean and dry. Try restarting the earbuds by placing them in the case and removing them.
Charging case not charging	Verify the USB-C cable is securely connected to both the case and the power source. Try a different cable or power adapter.

8. SPECIFICATIONS

Key technical specifications for the Noble FoKus Kama Wireless Open-Ear Headphones:

Feature	Detail
Model Name	Noble FoKus Kama
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Bluetooth Range	12 Meters
Ear Placement	Open Ear
Form Factor	On Ear
Audio Driver Type	Dynamic Driver
Frequency Response	20000 Hz
Sensitivity	96 dB
Impedance	16 Ohms
Noise Control	Passive Noise Cancellation
Battery Life (Earbuds)	Up to 8.5 Hours
Control Type	Media Control, Call Control, Volume Control
Control Method	App, Touch
Material	Plastic, Silicone, Fabric
Item Weight	8.6 ounces (0.25 Kilograms)
Water Resistance Level	Not Water Resistant
UPC	198715622386

9. VIDEO GUIDE

Watch this official video for a visual overview of the Noble FoKus Kama headphones:

This video provides a visual overview of the Noble FoKus Kama headphones, showcasing their design and key features.

10. WARRANTY & SUPPORT

Noble products are manufactured to the highest quality standards. For warranty information, technical support, or customer service inquiries, please refer to the contact details provided on the official Noble website or the warranty card included in your product packaging.
Please retain your proof of purchase for warranty claims.