Yomile AD007

Yomile AD007 Electric Air Duster & Car Vacuum User Manual

Model: AD007

1. Product Overview

The Yomile AD007 is a versatile 2-in-1 device designed for both air dusting and vacuum cleaning. It features a powerful brushless motor, a long-lasting battery, and multiple attachments for various cleaning tasks in your car, office, or home.



Image 1.1: Yomile AD007 device and included accessories.

2. What's in the Box

Please check the package contents to ensure all items are present:

- Yomile AD007 Main Unit (Electric Air Duster & Car Vacuum)
- Accessory Kit (various nozzles and brushes)
- USB-C Charging Cable
- User Manual



Image 2.1: Multi-function accessories for diverse cleaning needs.

3. Setup and Charging

3.1 Initial Charge

1. Before first use, fully charge the device.
2. Connect the provided USB-C charging cable to the device's charging port.
3. Connect the other end of the cable to a compatible USB power adapter (not included).
4. The battery indicator lights will illuminate during charging and turn solid when fully charged. A full charge typically takes 3-4 hours.



Image 3.1: Device indicating battery status and USB-C charging.

3.2 Attaching Accessories

The Yomile AD007 comes with various nozzles and brushes for different applications. To attach an accessory:

1. Identify the desired accessory for your cleaning task.
2. For air dusting, attach the appropriate nozzle to the front (blowing) outlet.
3. For vacuuming, attach the appropriate nozzle to the rear (suction) inlet.
4. Ensure the accessory is securely fitted to prevent air leakage or detachment during use.

4. Operating Instructions

4.1 Power On/Off and Speed Adjustment

1. To power on the device, press and hold the power button for approximately 2 seconds.
2. The device has 3 adjustable wind/suction speeds. Press the power button briefly to cycle through the speeds (Low → Medium → High).
3. To power off the device, press and hold the power button again for approximately 2 seconds.

4.2 Using the Air Duster Function

The air duster function is ideal for removing dust and debris from delicate electronics, keyboards, and hard-to-reach areas.

1. Attach the desired nozzle to the front (blowing) outlet of the device.
2. Power on the device and select the appropriate speed.
3. Direct the airflow towards the area to be cleaned, maintaining a safe distance from sensitive components.



Image 4.1: Using the air duster function to clean a computer tower.



Image 4.2: Effective dusting of a keyboard with the Yomile AD007.

4.3 Using the Vacuum Cleaner Function

The vacuum function is suitable for picking up small debris, crumbs, pet hair, and dust from various surfaces.

1. Attach the desired nozzle to the rear (suction) inlet of the device.
2. Power on the device and select the appropriate speed.
3. Move the nozzle over the area to be vacuumed, ensuring good contact with the surface.



Image 4.3: Vacuuming crumbs from a car seat.



Image 4.4: Cleaning a car interior with the vacuum function.

4.4 Versatile Applications

The Yomile AD007 is designed for a variety of cleaning scenarios:

- **Computer & Electronics:** Dusting keyboards, computer towers, camera lenses.
- **Car Interiors:** Vacuuming seats, floor mats, dashboards, and blowing dust from vents.
- **Home & Office:** Cleaning desks, shelves, upholstery, and small spills.
- **Air Pump:** Can be used to inflate small items or vacuum storage bags (with appropriate attachments).



Image 4.5: Illustrating the 4-in-1 functionality of the device.



Image 4.6: Visual representation of adjustable speed settings for both modes.

5. Maintenance

5.1 Emptying the Dust Cup

Regularly empty the dust cup to maintain optimal suction performance.

1. Ensure the device is powered off.
2. Twist or unlatch the dust cup from the main unit (refer to the device's specific design for exact mechanism).
3. Empty the collected debris into a waste bin.
4. Reattach the dust cup securely.

5.2 Cleaning the Filter

The washable HEPA filter should be cleaned periodically to prevent clogging and maintain efficiency.

1. Remove the dust cup as described above.
2. Carefully remove the filter from the dust cup.
3. Rinse the filter under running water until clean. Do not use harsh detergents.
4. Allow the filter to air dry completely before reinserting it into the dust cup. Ensure it is fully dry to prevent damage to the motor.
5. Reassemble the dust cup and attach it to the main unit.



Image 5.1: Washable HEPA filter and accessory kit.

5.3 General Cleaning

Wipe the exterior of the device with a soft, damp cloth. Do not immerse the main unit in water or use abrasive cleaners.

6. Troubleshooting

If you encounter issues with your Yomile AD007, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Low battery.	Charge the device fully using the provided USB-C cable.
Weak air blowing or suction.	Clogged filter or full dust cup.	Empty the dust cup and clean the HEPA filter. Ensure the filter is completely dry before reassembly.
Weak air blowing or suction.	Nozzle or inlet/outlet blocked.	Check for and remove any blockages in the nozzles, air duster outlet, or vacuum inlet.
Device stops unexpectedly.	Overheating or low battery.	Allow the device to cool down. If the issue persists, charge the battery.

If the problem persists after attempting these solutions, please contact customer support.

7. Specifications

Feature	Detail

Feature	Detail
Brand	Yomile
Model Name	AD007
Special Feature	Cordless, 2-in-1 (Air Duster & Vacuum)
Motor Type	Brushless
Air Duster Speed	Up to 210,000 RPM (3 speeds)
Vacuum Suction Power	Up to 21,000 PA (3 speeds)
Battery Capacity	9000mAh Lithium-Ion
Battery Life	Up to 40 minutes
Charging Time	3-4 hours (via USB-C)
Filter Type	Washable Cloth Filter
Item Weight	Approximately 1.1 lbs (0.5 kg)
Product Dimensions	Approximately 6.3 x 3.9 x 2.6 inches
Connectivity Technology	USB

8. Warranty and Support

Yomile provides comprehensive customer support for your product.

- **After-Sale Service:** Enjoy 24 months of after-sale service.
- **Customer Support:** Dedicated 7x24 customer support is available to assist you with any inquiries or issues.

For support, please refer to the contact information provided with your purchase or visit the official Yomile website.

9. Important Safety Information

- Read all instructions before using the appliance.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without the dust cup and filter in place.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not handle plug or appliance with wet hands.
- Exercise extreme caution when cleaning on stairs.
- Store the appliance indoors. Put away after use to prevent accidents.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision

or instruction concerning use of the appliance by a person responsible for their safety.