Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vieta Pro Goody 4

Vieta Pro Goody 4 Portable Bluetooth Speaker Instruction Manual

Introduction

Thank you for choosing the Vieta Pro Goody 4 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read it carefully to ensure optimal performance and longevity of your speaker.





Image: The Vieta Pro Goody 4 portable Bluetooth speaker, shown with water droplets, highlighting its waterproof design.

Setup

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the supplied USB Type-C charging cable to the speaker's charging port and the other end to a compatible USB power adapter (not included). The LED indicator will show charging status.

2. Powering On/Off

Press and hold the power button located on the speaker to turn it on or off. A sound prompt will indicate the power status.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode (LED indicator will flash).
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.

3. Select "Vieta Pro Goody 4" from the list.
4. Once connected, the speaker will emit a confirmation sound, and the LED indicator will stop flashing.

4. True Wireless Stereo (TWS) Pairing

To achieve a more immersive sound experience, you can pair up to 99 Goody 4 speakers together using TWS technology.

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press the TWS button. The speaker will enter TWS pairing mode.
3. The primary speaker will automatically search for other Goody 4 speakers.
4. Once connected, both speakers will emit a confirmation sound, and audio will play in stereo.

5. Aux-In Connection

For non-Bluetooth devices, connect an audio cable (3.5mm jack, not included) from your device's audio output to the speaker's AUX-IN port. The speaker will automatically switch to AUX mode.

Operation





Image: The Vieta Pro Goody 4 speaker, showing its side control buttons and integrated carrying strap.

1. Music Playback

- **Bluetooth:** Control playback (play/pause, skip tracks) directly from your connected device or using the speaker's control buttons.
- **USB Playback:** Insert a USB drive containing audio files into the USB port. The speaker will automatically detect and play the music.
- **Aux-In:** Play music from your connected device. Control playback from the source device.

2. Volume Control

Use the volume buttons on the speaker to adjust the playback volume. You can also control the volume from your connected device.

3. Call Handling

When connected via Bluetooth, the integrated microphone allows you to answer or end calls directly from the speaker. Press the play/pause button to answer or end a call.

4. Voice Control

The speaker is compatible with voice assistants like Alexa. Activate your device's voice assistant feature and speak commands through the speaker's microphone.

5. RGB Lighting

The speaker features RGB lighting. Refer to the specific button on the speaker (if present) or the accompanying quick start guide for instructions on how to change or disable the lighting effects.

Maintenance



Image: The Vieta Pro Goody 4 speaker demonstrating its IPX7 water resistance by being partially submerged in water.

1. Water Resistance (IPX7)

The Goody 4 speaker is IPX7 waterproof, meaning it can be submerged in water up to 1 meter for 30 minutes. Ensure all

ports are securely closed before exposing the speaker to water. After exposure to water, dry the speaker thoroughly before charging or using any ports.

2. Cleaning

Clean the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the surface. Ensure the speaker is dry before storing or using.

3. Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery periodically to maintain its health.

Troubleshooting

No Power

- Ensure the battery is charged. Connect the speaker to a power source using the USB Type-C cable.
- Press and hold the power button for a few seconds to ensure it's not just a short press.

No Sound

- Check the volume levels on both the speaker and your connected device.
- Ensure the speaker is correctly paired via Bluetooth or connected via Aux-In/USB.
- If using Bluetooth, try disconnecting and re-pairing the device.

Bluetooth Pairing Issues

- Ensure the speaker is within the Bluetooth range (typically 10 meters) of your device.
- Turn off and on Bluetooth on your device, then try pairing again.
- Clear the speaker from your device's Bluetooth history and re-pair.
- Ensure no other devices are actively connected to the speaker.

Short Battery Life

- Ensure the speaker is fully charged before use.
- High volume levels and continuous RGB lighting can reduce battery life.
- Battery performance may degrade over time with prolonged use.

Specifications

Feature	Specification
Model Name	Goody 4

Model Number	VM-BS48GR
Brand	Vieta Pro
Connectivity Technology	Bluetooth 5.3
Speaker Output Power	25 Watts
Battery Life	Up to 13 hours
Waterproof Rating	IPX7
Dimensions (L x W x H)	7.4 x 7.4 x 19.1 cm
Weight	880 grams
Special Features	Anti-shock, USB Port, Wireless Speakers (TWS), Microphone, RGB Lighting
Compatible Devices	Smartphone, Tablet, Laptop, MP3 Player
Included Components	USB Type-C Charging Cable



Image: A visual comparison of Vieta Pro speaker models, including the Goody 4, Easy 4, and Upper 4, illustrating their relative sizes.

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Vieta Pro website. You may also contact the seller, FRAMASON AUDIO SA, for assistance with your product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DGXKZ92X

More documents and user manuals: **https://manuals.plus/**