SUPERLEX B0DH214H75

SUPERLEX Electric 5-in-1 Vegetable Cutter Instruction Manual

Model: B0DH214H75
Brand: SUPERLEX

1. Introduction

This manual provides essential information for the safe and efficient operation of your SUPERLEX Electric 5-in-1 Vegetable Cutter. This versatile kitchen appliance is designed to simplify food preparation by offering multiple functions including coarse grating, fine grating, thick slicing, fine slicing, and grinding. Please read these instructions thoroughly before first use and retain them for future reference.



The SUPERLEX Electric 5-in-1 Vegetable Cutter shown in operation, demonstrating its versatility with different vegetables and cheeses.

2. Safety Instructions

- Always ensure the appliance is unplugged before assembly, disassembly, or cleaning.
- Keep hands and utensils away from moving blades during operation. Use the food pusher provided.
- Do not immerse the motor unit in water or other liquids.
- This appliance is not intended for use by children. Keep out of reach of children.
- Do not operate the appliance with a damaged cord or plug, or if it has been dropped or damaged in any way.
- Ensure all parts are correctly assembled and locked into place before operating.
- Avoid processing extremely hard foods that may damage the blades or motor.

3. Product Components

Your SUPERLEX Electric 5-in-1 Vegetable Cutter includes the following main components:

- Motor Unit
- Feeding Tube / Hopper
- Food Pusher
- Blade Holder
- 5 Interchangeable Drum Blades (Fine Grating, Coarse Grating, Thick Slicing, Fine Slicing, Grinding)



This image displays the five unique drum blades included with the cutter: fine grating, coarse grating, thick slicing, fine slicing, and grinding.

4. Setup

1. Unpack all components and remove any packaging materials.
2. Place the motor unit on a stable, flat, and dry surface.
3. Insert the desired drum blade into the blade holder. Ensure it is securely fitted.
4. Attach the blade holder assembly to the motor unit's outlet. Rotate until it locks into place.
5. Place the feeding tube/hopper on top of the blade holder.
6. Ensure the food pusher is ready for use.

5. Operating Instructions

1. After assembly, plug the appliance into a suitable power outlet.
2. Prepare your ingredients by cutting them into pieces that fit comfortably into the feeding tube.
3. Place the ingredients into the feeding tube.
4. Press the one-click operation button to start the motor.
5. Gently push the ingredients down the feeding tube using the food pusher. Do not force the food.
6. Once processing is complete, release the button to stop the motor and unplug the appliance.



Illustrates the simple one-click operation for starting and stopping the device.



Shows the safe method of feeding ingredients into the cutter using the provided food pusher.

6. Blade Usage Guide

The SUPERLEX Electric 5-in-1 Vegetable Cutter comes with five distinct drum blades for various food preparation needs:

- **Coarse Grating Blade:** Ideal for shredding hard cheeses, carrots, potatoes, and other firm vegetables.
- **Fine Grating Blade:** Perfect for finely grating ingredients like parmesan cheese, chocolate, or breadcrumbs.
- **Thick Slicing Blade:** Produces thicker slices of vegetables such as cucumbers, zucchini, or potatoes.
- **Fine Slicing Blade:** Creates thinner, more delicate slices for salads or garnishes.
- **Grinding Blade:** Suitable for grinding nuts, spices, or making fine crumbs.



An overview of the electric vegetable cutter in action, producing different textures and shapes from various ingredients.

SUPERLEX

Detailed view of the interchangeable blades, illustrating which blade produces fine slices, coarse grates, or other specific cuts.

7. Cleaning and Maintenance

Regular cleaning ensures the longevity and hygiene of your appliance. The removable drum and rotating grater facilitate easy cleaning.

1. Always unplug the appliance before cleaning.
2. Disassemble the feeding tube, blade holder, and drum blade from the motor unit.
3. Wash all removable parts (blades, blade holder, feeding tube, food pusher) with warm, soapy water. Rinse thoroughly and dry immediately. These parts are generally dishwasher safe, but hand washing is recommended for optimal blade sharpness.
4. Wipe the motor unit with a damp cloth. Never immerse the motor unit in water.
5. Ensure all parts are completely dry before reassembling or storing.

8. Storage

The compact design of your SUPERLEX Electric 5-in-1 Vegetable Cutter makes storage convenient. It features integrated cable storage to keep your countertop tidy.

- Store the appliance in a dry place, away from direct sunlight and heat.
- Utilize the integrated cable storage to wrap the power cord neatly.
- Keep the interchangeable blades in a safe place to prevent accidental cuts and damage.



Demonstrates the space-saving design and integrated cable storage for convenient storage.

9. Troubleshooting

If you encounter any issues with your appliance, please refer to the following common troubleshooting steps:

- **Appliance does not turn on:** Ensure the power cord is securely plugged into a working outlet. Check if the one-click operation button is fully pressed. Verify that all components are correctly assembled and locked.
- **Food is not processing correctly:** Ensure the correct blade is installed for the type of food and desired cut. Do not overload the feeding tube; process food in smaller batches if necessary. Ensure the food pusher is used to guide ingredients gently.
- **Motor stops during operation:** The appliance may have an overheating protection feature. Unplug it and let it cool down

for 15-20 minutes before resuming use. Reduce the load or process harder foods in smaller pieces.

If the problem persists, please contact customer support.

10. Specifications

Feature	Specification
Brand	SUPERLEX
Model	B0DH214H75
Color	Stainless Steel
Dimensions	21 x 11 x 27.5 cm
Power	150 watts
Material	Stainless Steel
Weight	1.5 kg
Special Features	Safety Pusher, One-Click Operation, Food-Grade Materials, 5-in-1 Versatility

11. Warranty and Support

Your SUPERLEX Electric 5-in-1 Vegetable Cutter comes with a standard manufacturer's warranty. Please refer to the warranty card included in the product packaging for specific terms and conditions.
For technical support, troubleshooting assistance, or warranty claims, please contact SUPERLEX customer service through the retailer where the product was purchased or visit the official SUPERLEX website for contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How to detach the cutter (5) from the drum housing (10)

To detach the drum blade from the SUPERLEX B0DH214H75 Electric Vegetable Cutter, follow these steps based on the standard assembly of this type of appliance:Unplug the device: Always ensure the motor unit is disconnected...

Read full answer