SUPERLEX Automatische Milchaufschäumer

SUPERLEX Automatic Electric 4-in-1 Milk Frother

Model: Automatische Milchaufschäumer

Introduction

Welcome to the SUPERLEX Automatic Electric Milk Frother. This appliance is designed to create rich, creamy milk foam for various beverages or to simply heat milk. Please read this manual carefully before use to ensure safe and efficient operation and to achieve the best results with your new appliance.



Image: The SUPERLEX milk frother pouring frothed milk into a coffee cup, demonstrating its primary function.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions before using the appliance.
2. Do not immerse the power base, cord, or plug in water or other liquids.
3. Close supervision is necessary when any appliance is used by or near children.
4. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
5. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.

6. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
7. Do not use outdoors.
8. Do not let cord hang over edge of table or counter, or touch hot surfaces.
9. Do not place on or near a hot gas or electric burner, or in a heated oven.
10. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
11. Do not use appliance for other than intended use.
12. Avoid contact with moving parts.
13. The appliance heats milk to approximately 70°C. Handle with care to avoid burns.
14. Ensure the lid is properly closed during operation.
15. Do not fill above the indicated MAX level to prevent overflow.



Image: The SUPERLEX milk frother highlighting its safety features, such as dry-burn and overheating protection, and

heat-resistant exterior.

Product Overview

Components

- Frother Jug (with non-stick interior)
- Lid
- Frothing Whisk (for foam)
- Heating Whisk (for heating without foam, if separate, or a single whisk for both functions)
- Power Base

Controls and Fill Levels

The appliance features a single multi-function button for easy operation and clear MAX/MIN indicators inside the jug.



Image: The control panel of the SUPERLEX milk frother, illustrating the 4-in-1 button and its corresponding icons for different milk preparation modes.



Image: A view of the frother's interior, clearly showing the MAX fill line for heating (300ml), MAX fill line for frothing (150ml), and MIN fill line (80ml).

Setup

1. Unpack all components and remove any packaging materials.
2. Wash the interior of the frother jug, the whisk, and the lid with warm soapy water. Rinse thoroughly and dry completely before first use. Do not immerse the power base in water.
3. Place the power base on a stable, flat, heat-resistant, and dry surface.
4. Ensure the correct whisk is securely inserted at the bottom of the frother jug for your desired function (e.g., frothing whisk for foam, or heating whisk if provided separately for just heating).

Operating Instructions

General Operation

1. **Add Milk:** Pour cold milk into the frother jug. Observe the MAX/MIN fill lines:
    - For **frothing** (hot or cold foam): Do not exceed the **MAX 150ml** line.
    - For **heating milk only** (no foam): Do not exceed the **MAX 300ml** line.
    - Always ensure milk is above the **MIN 80ml** line.
2. **Secure Lid:** Place the lid firmly onto the frother jug.
3. **Place on Base:** Position the frother jug onto the power base.
4. **Select Function:** Press the multi-function button to select your desired mode. The indicator light will illuminate.
    - **Hot Thick Foam:** Press the button once. (Icon: three wavy lines, cup with thick foam)
    - **Hot Light Foam:** Press the button twice. (Icon: three wavy lines, cup with light foam)
    - **Hot Milk (no foam):** Press the button three times. (Icon: three wavy lines, plain cup)
    - **Cold Foam:** Press and hold the button for approximately 2 seconds. (Icon: snowflake, cup with foam)
5. **Start/Stop:** The frother will start automatically after selecting the function. It will automatically stop when the cycle is complete. You can manually stop the process at any time by pressing the button once.
6. **Serve:** Carefully remove the jug from the base and pour out the frothed or heated milk immediately.

Tips for Best Results

- Use cold, fresh milk (dairy or non-dairy alternatives). Different types of milk may produce varying foam quality and consistency.
- Always clean the frother immediately after each use to prevent milk residue from drying and sticking.



Image: The SUPERLEX milk frother showcasing its four distinct functions: cold foam, hot milk with light foam, hot milk with creamy foam, and hot milk with stiff foam, alongside examples of beverages created.



Image: A collage of different milk-based beverages, such as latte, cappuccino, and hot chocolate, illustrating the versatility of the SUPERLEX milk frother.

Maintenance and Cleaning

Proper cleaning after each use ensures optimal performance and extends the lifespan of your milk frother. The non-stick coating simplifies the cleaning process.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Separate Components:** Remove the frother jug from the power base. Carefully remove the whisk from the bottom of the jug.
3. **Wash Jug and Whisk:** Wash the interior of the frother jug, the whisk, and the lid with warm soapy water and a soft, non-abrasive sponge or cloth.
4. **Rinse and Dry:** Rinse all washed parts thoroughly under running water and dry them immediately with a soft cloth.
5. **Clean Exterior:** Wipe the exterior of the frother jug and the power base with a damp cloth. Do **NOT** immerse the power

base, cord, or plug in water or any other liquid.

6. **Storage:** Ensure all parts are completely dry before reassembling and storing the appliance.



Image: A hand cleaning the interior of the SUPERLEX milk frother under running water, demonstrating its easy-to-clean design.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in or loose connection. Frother jug not correctly placed on base.	Ensure the power cord is securely plugged into a working electrical outlet. Verify the frother jug is properly seated on the power base.

Problem	Possible Cause	Solution
Milk does not froth or froths poorly.	Incorrect milk level. Wrong whisk used or whisk not properly installed. Type of milk. Interior not clean.	Ensure milk level is between MIN and MAX frothing lines (max 150ml). Verify the frothing whisk is correctly installed. Use cold, fresh milk. Different milk types yield different foam quality. Clean the interior thoroughly to remove any residue.
Milk burns or sticks to the bottom.	Overfilling. Residue from previous use.	Do not exceed the MAX heating line (300ml). Clean the interior thoroughly after each use to prevent milk residue buildup. The appliance has overheating protection and will shut off automatically if it detects an issue.
Appliance stops unexpectedly.	Automatic shut-off activated (cycle complete or overheating protection).	This is normal operation if the cycle is complete. If it stops prematurely, check for overheating (allow to cool) or ensure proper milk levels.

Specifications

- **Brand:** SUPERLEX
- **Model Number:** Automatische Milchaufschäumer
- **Power:** 500 Watts
- **Voltage:** 220-240V
- **Frequency:** 50/60 Hz
- **Capacity (Frothing):** Max 150 ml
- **Capacity (Heating):** Max 300 ml
- **Minimum Capacity:** 80 ml
- **Material:** Stainless Steel (interior), Non-stick coating
- **Color:** Black
- **Heating Temperature:** Approximately 70°C
- **Special Features:** Non-stick, Automatic Shut-off, 360° Swivel Base, Overheating Protection
- **Dimensions (Package):** 24.5 x 13 x 13 cm
- **Weight (Package):** 760 grams

Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the documentation included with your purchase or visit the official SUPERLEX website. Please have your model number (Automatische Milchaufschäumer) and purchase details ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question