Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY ERF6N64H

ALLIMITY ERF6N64H Replacement Remote Control User Manual

For Hisense Smart TVs

1. Introduction

This manual provides instructions for the ALLIMITY ERF6N64H replacement remote control. This remote is designed to function as a direct replacement for your original Hisense TV remote, offering seamless operation without the need for complex programming or pairing.





Image 1.1: Front view of the ALLIMITY ERF6N64H remote control, displaying all buttons.

2. Compatibility

The ALLIMITY ERF6N64H remote control is compatible with a wide range of Hisense Smart TV models. Please verify your TV model against the list below:

- 85U86KQ, 65U87KQ, 65U8KQTUK, 75U80KQ, 75U82KQ, 75U87KQ, 75U89KQ, 75U8KQTUK, 55U89KQ, 85U81KQ, 85U82KQ, 85U87KQ, 85U88KQ, 85U89KQ, 85U8KQTUK, 75U86KQ, 85U8KQ, 55U8KQTUK
- 65U89KQ, 55U8K, 65U8K, 75U8KQ, 75U8K, 85U8K, 75U88KQ, 55U88KM, 65U81KQ, 65U88KQ, 65U88KM, 75U88KM, 65U8KQ, 85U80KQ, 75U81KQ, 55U8KQ, 55U80KQ, 55U81KQ, 55U82KQ, 55U86KQ, 55U87KQ, 55U88KQ, 65U80KQ, 65U82KQ, 65U86KQ

3. Setup

3.1. Battery Installation

To begin using your remote control, you must install batteries. No programming or pairing is required; simply insert the batteries, and the remote will be ready for use.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.

3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Image 3.1: Back view of the remote control with the battery cover removed, showing battery placement.

4. Operating Instructions

Once batteries are installed, point the remote control directly at your Hisense TV and press the desired buttons. Ensure there are no obstructions between the remote and the TV's infrared receiver.

4.1. Basic Functions

- **Power Button ( ):** Turns the TV on or off.
- **Number Buttons (0-9):** Directly select channels.
- **Input Button:** Cycles through available input sources (HDMI, AV, etc.).
- **Volume Up/Down (VOL +/-):** Adjusts the TV's volume level.
- **Channel Up/Down (CH +/-):** Changes the TV channel.
- **Mute Button ( ):** Mutes or unmutes the TV's audio.

4.2. Navigation and Menu Control

- **Directional Pad (Up, Down, Left, Right):** Navigates through menus and on-screen options.
- **OK Button:** Confirms selections or opens menus.
- **EXIT Button:** Exits the current menu or screen.
- **Back Button (↩):** Returns to the previous screen or menu.
- **Home Button ( ):** Accesses the TV's main home screen or smart features.

4.3. Quick Access App Buttons

The remote includes dedicated buttons for popular streaming services:

- **Disney:** Launches the Disney+ application.
- **GUIDE:** Opens the electronic program guide.
- **deezer:** Launches the Deezer music streaming application.
- **NETFLIX:** Launches the Netflix application.
- **YouTube:** Launches the YouTube application.
- **prm video:** Launches the Prime Video application.
- **VIDAA TV:** Accesses the VIDAA Smart TV platform.

5. Maintenance

5.1. Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

5.2. Battery Care

- Replace batteries when the remote's response becomes sluggish or stops working.
- Always replace both batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.
- If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

6. Troubleshooting

6.1. Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-) and are not depleted. Replace with fresh batteries if necessary.
- **Line of Sight:** Make sure there are no objects blocking the path between the remote control and the TV's infrared sensor.
- **Distance:** Ensure you are within a reasonable operating distance from the TV.
- **TV Sensor:** Verify that the TV's infrared sensor is not obstructed or dirty.

If the issue persists after checking these points, the remote control may require replacement.

7. Specifications

Feature	Detail
Model Number	ERF6N64H
Brand	ALLIMITY
Compatible Devices	Hisense Televisions
Power Source	2 x AAA Batteries (not included)
Dimensions	6 x 2 x 0.5 inches (15.24 x 5.08 x 1.27 cm)
Item Weight	2.08 ounces (59 grams)
Color	Black





Image 7.1: Remote control dimensions.

8. Warranty and Support

For any questions, concerns, or support regarding your ALLIMITY ERF6N64H replacement remote control, please contact the seller or manufacturer directly through your purchase platform. Please refer to your purchase documentation for specific warranty information, as it may vary.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DH2NQDLK

More documents and user manuals: **https://manuals.plus/**