Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

tectake VC900

tectake VC900 Bagless Vacuum Cleaner User Manual

Model: VC900 (Type 405232)

1. Important Safety Instructions

Please read all instructions carefully before using the appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Always ensure the power supply matches the voltage specified on the rating label. Unplug the vacuum cleaner from the power outlet before cleaning or performing any maintenance. Do not use the appliance with a damaged cord or plug. Do not pull the cord to unplug; grasp the plug itself.
- **Usage Precautions:** This appliance is for domestic use only. Do not vacuum liquids, hot ashes, burning cigarettes, sharp objects, or flammable/explosive materials. Do not operate the vacuum cleaner without the dust container and filters properly installed. Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- **Children and Vulnerable Persons:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Maintenance:** Only use manufacturer-recommended attachments. Do not attempt to repair the appliance yourself. Contact qualified service personnel for repairs.

2. Product Overview

The tectake VC900 is a powerful bagless vacuum cleaner designed for efficient cleaning of various surfaces. It features a HEPA filter for improved air quality and comes with multiple attachments for versatile use.



Figure 2.1: Components of the tectake VC900 Vacuum Cleaner.

1. Floor Nozzle
2. Switch Button (on floor nozzle)
3. Telescopic Tube
4. Airflow Regulator
5. Suction Hose
6. Dust Container
7. Wheels
8. Power Control (on main unit)
9. ON/OFF Foot Switch
10. Cable Rewind Foot Switch
11. Crevice Nozzle
12. Upholstery Nozzle
13. Small Steering Wheel (front wheel)

3. Setup

Follow these steps for initial assembly and preparation for use:

1. **Unpack:** Carefully remove all components from the packaging. Ensure all parts listed in the Product Overview are present.
2. **Attach Suction Hose:** Insert the end of the suction hose into the suction inlet on the main unit until it clicks securely into place.
3. **Assemble Telescopic Tube:** Connect the telescopic tube to the handle end of the suction hose. Adjust the length of the telescopic tube by pressing the release button and extending or retracting it to a comfortable height.
4. **Attach Floor Nozzle:** Connect the floor nozzle to the end of the telescopic tube. Ensure it is firmly attached.
5. **Power Connection:** Extend the power cord from the vacuum cleaner and plug it into a suitable electrical outlet (220-240V AC).

4. Operating Instructions

Operating the tectake VC900 is straightforward. Follow these guidelines for effective cleaning:



Figure 4.1: Floor nozzle with adjustable suction and floor type switch.

1. **Power On/Off:** Press the ON/OFF foot switch (9) on the main unit to start or stop the vacuum cleaner.
2. **Adjust Suction Power:** Use the power control (8) on the main unit to adjust the suction strength. There are typically two power levels. For lighter cleaning or delicate surfaces, use a lower setting. For deep cleaning of carpets or heavily soiled areas, use the maximum setting.
3. **Floor Nozzle Usage:** The universal floor nozzle (1) has a switch (2) to adapt to different floor types.
    - For hard floors (e.g., tiles, laminate), ensure the brush is extended.
    - For carpets and rugs, retract the brush.
4. **Using Attachments:** For specialized cleaning, remove the floor nozzle and attach the desired accessory directly to the telescopic tube or hose handle.



Figure 4.2: Foot switch, telescopic tube, dust container release, and accessory nozzles.

- **Crevice Nozzle (11):** Ideal for cleaning narrow gaps, corners, and edges.
- **Upholstery Nozzle (12):** Suitable for cleaning upholstered furniture, curtains, and car interiors.

5. **Airflow Regulator:** The airflow regulator (4) on the hose handle allows for manual adjustment of suction power, useful for delicate items or when suction is too strong.
6. **Cord Rewind:** After use, press the cable rewind foot switch (10) to automatically retract the power cord into the unit.

5. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.



Figure 5.1: Filter system and dust container emptying.

1. **Emptying the Dust Container:** The dust container (6) should be emptied regularly, especially when the 'MAX' indicator is reached or suction power decreases.
    - Press the dust container release button (as shown in Figure 4.2, image 3).
    - Remove the dust container from the main unit.
    - Open the bottom lid of the dust container and empty its contents into a waste bin.
    - Close the lid and reattach the dust container to the vacuum cleaner, ensuring it clicks into place.
2. **Cleaning the HEPA Filter:** The HEPA filter is washable and should be cleaned periodically (e.g., every 3-6 months, depending on usage).
    - Remove the dust container.
    - Locate and remove the HEPA filter from the dust container assembly.
    - Rinse the HEPA filter under cold running water until the water runs clear. Do not use detergents.
    - Allow the filter to air dry completely for at least 24 hours before reinserting it. Do not use a hairdryer or other heating devices.

3. **Cleaning the Motor Filter:** The motor filter (located before the motor) should also be checked and cleaned regularly. Tap it gently to remove dust or rinse if washable and allow to dry completely.
4. **General Cleaning:** Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure all parts are dry before storage or next use.

6. Troubleshooting

If you encounter issues with your vacuum cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	No power supply.	Check if the plug is securely inserted into the outlet. Check the power outlet with another appliance.
Low suction power.	Dust container full. Clogged filters. Blockage in hose or nozzle.	Empty the dust container. Clean or replace filters. Check hose, telescopic tube, and nozzles for blockages and remove them.
Unusual noise during operation.	Foreign object in fan or motor.	Immediately turn off and unplug the vacuum cleaner. Check for and remove any foreign objects. If the noise persists, contact customer support.
Power cord does not rewind.	Cord is jammed or mechanism is faulty.	Gently pull out a small length of cord and try rewinding again. If it still fails, manually guide the cord back or contact customer support.

If the problem persists after attempting these solutions, please contact tectake customer support.

7. Specifications

Technical details for the tectake VC900 Bagless Vacuum Cleaner:



Figure 7.1: Dimensions of the tectake VC900 Vacuum Cleaner.

- **Model Number:** 405232
- **Power:** 899 W
- **Voltage:** 220-240 V AC
- **Dust Container Capacity:** Approx. 3 Liters
- **Noise Level:** 79 dB
- **Cable Length:** Approx. 4.9 meters
- **Weight:** Approx. 5.7 kg
- **Overall Dimensions (L x W x H):** Approx. 43 x 27 x 88 - 117 cm (adjustable height)
- **Telescopic Tube Length:** Approx. 43 - 76 cm
- **Floor Nozzle Dimensions (L x W):** Approx. 27 x 9 cm
- **Upholstery Nozzle Dimensions (L x W):** Approx. 12 x 4.5 cm
- **Crevice Nozzle Dimensions (L x W):** Approx. 3 x 2.5 cm
- **Filter Type:** HEPA Filter
- **Recommended Surface:** Hard floors, carpets

- **Materials:** Steel, ABS plastic, polypropylene, PVC, copper

8. Warranty and Support

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. For technical support, spare parts, or any questions regarding the operation or maintenance of your tectake VC900 vacuum cleaner, please contact tectake customer service or your authorized dealer.

Please have your model number (405232) and purchase date available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DH4Q8Q9S

More documents and user manuals: **https://manuals.plus/**