Packard Bell PBKM1210BK

Packard Bell Wireless Keyboard and Mouse Combo User Manual

Model: PBKM1210BK

Introduction

This user manual provides detailed instructions for the setup, operation, and maintenance of your Packard Bell Wireless Keyboard and Mouse Combo. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Image: The Packard Bell Wireless Keyboard and Mouse Combo, featuring a full-sized black keyboard with a numeric keypad and a compact black wireless mouse.

Package Contents

- Wireless Keyboard
- Wireless Mouse
- USB Receiver (stored inside the mouse battery compartment)
- User Manual (this document)

Setup

1. Battery Installation

1. **For the Mouse:**

Locate the battery compartment on the underside of the mouse. Open the cover and insert the required AAA batteries (not included), ensuring correct polarity (+/-). The USB receiver is typically stored here. Remove it before closing the compartment.

2. **For the Keyboard:**

   Locate the battery compartment on the underside of the keyboard. Open the cover and insert the required AA batteries (not included), ensuring correct polarity (+/-). Close the compartment cover securely.

2. Connecting the USB Receiver

1. Turn on your computer (PC, laptop, or desktop).
2. Plug the USB receiver into an available USB port on your computer.
3. The computer will automatically detect and install the necessary drivers. This process may take a few moments. No additional software installation is required.

3. Powering On

- **Keyboard:** Ensure the keyboard has fresh batteries. There is usually no separate power switch for the keyboard; it activates upon key press.
- **Mouse:** Locate the ON/OFF switch on the underside of the mouse and slide it to the "ON" position.

Your keyboard and mouse should now be connected and ready for use. If they do not respond, refer to the Troubleshooting section.

Operating Instructions

Keyboard Usage

- **Typing:** The keyboard features a standard QWERTY layout with a numeric keypad for efficient data entry.
- **Function Keys (F1-F12):** These keys may have secondary functions (e.g., media control, volume, brightness) accessible by pressing the **Fn** key simultaneously. Refer to your operating system's documentation for specific function key behavior.
- **Quiet Keys:** The keys are designed for quiet operation, reducing typing noise in shared environments.

Mouse Usage

- **Left Click:** Primary action, selection.
- **Right Click:** Context menu.
- **Scroll Wheel:** Scroll documents and web pages vertically. The scroll wheel may also function as a middle click button.

Wireless Connection

The 2.4GHz wireless technology provides a stable connection up to 10 meters (33 feet) from the USB receiver. For best performance, ensure there are no major obstructions between the devices and the receiver.

Maintenance

- **Cleaning:**

  Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth with mild soap can be used, but ensure no liquid enters the device. Avoid abrasive cleaners or solvents.

- **Battery Replacement:**

  When the keyboard or mouse performance degrades (e.g., lag, unresponsive keys/cursor), it's time to replace the

batteries. Follow the battery installation steps in the Setup section. Dispose of old batteries responsibly according to local regulations.

- **Storage:**

  If storing the combo for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Low batteries; USB receiver not connected; Out of range; Interference.	Replace batteries. Ensure USB receiver is firmly plugged into a working USB port. Move devices closer to the receiver. Avoid placing near other wireless devices.
Lagging or intermittent connection	Low batteries; Interference; Receiver too far or obstructed.	Replace batteries. Move receiver to a front USB port or use a USB extension cable. Reduce interference from other wireless devices.
Mouse cursor erratic or not moving smoothly	Dirty optical sensor; Unsuitable surface; Low batteries.	Clean the optical sensor on the underside of the mouse. Use a mouse pad or a smooth, non-reflective surface. Replace batteries.
Keyboard keys not working	Low batteries; Key stuck; Software issue.	Replace batteries. Gently clean around the key. Restart your computer.

Specifications

- **Model:** PBKM1210BK
- **Connectivity:** 2.4GHz Wireless
- **Receiver:** USB Nano Receiver
- **Keyboard Dimensions:** Approximately 21 x 7 x 1.5 inches
- **Item Weight:** 1.6 pounds (combined)
- **Color:** Black
- **Compatible Devices:** PC, Laptop, Desktop Computers
- **Battery Type:** AA (for keyboard), AAA (for mouse) - *Batteries not included*

Warranty and Support

Packard Bell products are designed for reliability and performance. For warranty information and technical support, please refer to the warranty card included with your product or visit the official Packard Bell support website. Keep your purchase receipt as proof of purchase for warranty claims.
Manufacturer: Southern Telecom Inc
Website: Visit the Packard Bell Store on Amazon (for general brand information)

© 2024 Packard Bell. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question