Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EconoHome B0DH9MRQF5

Econohome Hanging Egg Chair with Stand User Manual

Model: B0DH9MRQF5

1. Introduction

Thank you for choosing the Econohome Hanging Egg Chair with Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read these instructions carefully before use and retain them for future reference.
This indoor/outdoor swing hammock chair is designed for relaxation and features plush, washable cushions. It has a maximum weight capacity of 350 lbs.

Safety Warnings:

- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity of 350 lbs.
- Keep children and pets away from the chair during assembly.
- Place the chair on a flat, stable surface.
- Avoid swinging excessively or standing on the chair.

2. Package Contents

Please verify that all parts listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Egg Chair Basket (main seating frame)
- Steel Stand (base and curved support pole)
- Suspension Chain
- Spring
- Seat Cushion
- Headrest Cushion
- Assembly Hardware (bolts, washers, nuts, Allen key)



Figure 2.1: Complete Econohome Hanging Egg Chair with Stand in Grey.

3. Setup and Assembly

Follow these steps to assemble your Econohome Hanging Egg Chair. It is recommended to have two people for easier assembly.

1. **Assemble the Base:** Connect the base pieces of the stand according to the diagrams in your hardware kit. Ensure all bolts are tightened securely.
2. **Attach the Support Pole:** Secure the curved support pole to the assembled base using the provided hardware.
3. **Attach the Spring and Chain:** Connect the spring to the top of the curved support pole. Then, attach the suspension chain to the spring.
4. **Hang the Egg Chair Basket:** Carefully lift the egg chair basket and attach its hanging loop to the suspension chain. Ensure the connection is secure.
5. **Place Cushions:** Position the seat cushion and headrest cushion inside the egg chair basket. The cushions are designed to fit snugly and can be tied to the frame to prevent slipping.

6. **Final Check:** Before first use, double-check all connections to ensure they are tight and secure.



Figure 3.1: Key components of the egg chair assembly.

Your browser does not support the video tag.

Video 3.1: A 3D animation demonstrating the assembly process of the Econohome Hanging Egg Chair with Stand.

4. Operating Instructions

The Econohome Hanging Egg Chair is designed for comfortable relaxation. Once assembled, you can enjoy its features:

- **Seating:** Gently sit into the chair, ensuring your weight is centered.
- **Adjustable Height:** The suspension chain allows for minor height adjustments. To change the height, you may need to remove the chair from the chain, adjust the chain length by adding or removing links (if applicable and safe to do so), and then re-attach the chair. Always ensure the chain is securely fastened after adjustment.
- **Movement:** The chair is designed to swing gently. Avoid aggressive swinging to prevent instability or damage.



Figure 4.1: Demonstrating comfortable use of the egg chair with its breathable cushions and stable design.

Your browser does not support the video tag.

Video 4.1: An overview of the Econohome Hanging Egg Chair with Stand, showcasing its features and general use.

5. Maintenance

Proper maintenance will extend the life and appearance of your egg chair.

- **Cushions:** The seat and headrest cushions are made from 100% polyester and soft cotton, and are removable for easy washing. Follow the care instructions on the cushion labels for best results.
- **Frame:** The aluminum and steel frame is designed to resist rust and corrosion. Wipe the frame with a damp cloth and mild soap as needed. Avoid harsh chemicals.
- **Rattan:** The weather-resistant rattan can be cleaned with a soft brush or cloth and mild soapy water. Rinse thoroughly and allow to air dry.
- **General Care:** Periodically check all bolts and connections and tighten if necessary to maintain stability.



Figure 5.1: The plush, washable cushions of the egg chair.

6. Troubleshooting

If you encounter any issues with your Econohome Hanging Egg Chair, refer to the following common solutions:

Problem	Possible Cause	Solution
Chair feels unstable or wobbly.	Loose connections or uneven surface.	Ensure all bolts on the stand and chair frame are tightened. Move the chair to a flat, level surface.
Squeaking noise during use.	Loose bolts or friction between metal parts.	Tighten all assembly screws. Apply a small amount of lubricant to the spring or chain connections if necessary.
Cushions slide out of place.	Cushions not secured.	Utilize the ties on the cushions to secure them to the chair frame.

7. Specifications

- **Model:** B0DH9MRQF5
- **Material:** Aluminum, Steel, Polyester, Cotton
- **Color:** Grey
- **Product Dimensions (L x W):** 37.4" x 37.4" (Chair base footprint)
- **Overall Height:** Approximately 78" (including stand)
- **Chair Basket Dimensions (H x W x D):** Approximately 42" x 29" x 25"
- **Maximum Weight Recommendation:** 350 lbs
- **Item Weight:** 48 lbs
- **Seating Capacity:** 1 person



Figure 7.1: Dimensions of the Econohome Hanging Egg Chair.

8. Warranty Information

For specific warranty details regarding your Econohome Hanging Egg Chair, please refer to the warranty card included with your purchase or contact the retailer directly. Warranty terms typically cover manufacturing defects and material flaws under normal use.

9. Support

If you require further assistance, have questions about assembly, or need to report missing/damaged parts, please contact Econohome customer support through the retailer where you purchased the product. Please have your model number (B0DH9MRQF5) and purchase information ready.

© 2026 EconoHome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DH9MRQF5

More documents and user manuals: **https://manuals.plus/**