Matbip AB1

Matbip P4 Wireless Controller User Manual

Model: AB1

INTRODUCTION

Thank you for purchasing the Matbip P4 Wireless Controller. This manual provides detailed instructions on how to set up, operate, and maintain your controller to ensure optimal performance and an enhanced gaming experience. Please read this manual thoroughly before use.



Image: The Matbip P4 Wireless Controller, showcasing its ergonomic design and button layout.

Key Features

- **Versatile Functionality:** Supports Turbo function, dual vibration, 6-axis gyro sensor, gravity sensing, touchpad, and a 3.5mm headphone jack. Integrated LED light and speaker.
- **Enhanced Stability and Battery Life:** Equipped with a 1000mAh rechargeable battery, providing over 10 hours of continuous gameplay on a single charge. Features a low voltage warning function.
- **Stable Bluetooth Connectivity:** Utilizes advanced wireless chip for stable Bluetooth connection to P4, with data transfer speeds up to 2.1Mbps. Offers a communication range of up to 10m and supports up to four controllers simultaneously.
- **Wide Compatibility:** Compatible with P3, P4, P4 Pro, P4 Slim, and PC (Windows 7/8/10). Can be used as a wired controller when connected to a computer via USB cable.
- **Ergonomic Design:** Crafted from durable materials with an ergonomic shape that fits comfortably in the hand, reducing fatigue during extended play. Features anti-slip pads for a secure grip.

Setup Guide

Connecting to P4

1. Connect the controller to your P4 console using the provided USB cable for initial pairing.
2. The light bar on the controller will slowly flash and then illuminate steadily, indicating successful pairing.
3. After initial pairing, you can press the Home button to automatically pair wirelessly.

Connecting to PC (Windows 7/8/10)

1. Press and hold the SHARE button on the controller.
2. While still holding SHARE, press the Home button.
3. The LED light will flash rapidly.
4. On your PC, search for Bluetooth devices and select the controller to pair.
5. After initial pairing, you can press the Home button to automatically pair wirelessly.



Image: Visual representation of the controller's 1000mAh battery capacity, charging time (4.0 hours), and continuous operation time (20 hours).

Operating Instructions

Turbo Function

- **To activate Turbo:** Simultaneously press the SHARE button and the desired function button (e.g., X, Square, Circle, Triangle) for which you want to enable rapid fire.
- **To deactivate Turbo:** Simultaneously press the SHARE button and the same function button that has Turbo enabled.
- The Turbo function will also be cleared when the controller's power is turned off.



Image: Illustration of the Turbo function, showing rapid fire rates of 8, 12, and 20 shots per second.

Dual Vibration

The controller features dual vibration motors that provide tactile feedback during gameplay, enhancing immersion. The vibration intensity responds to in-game events, such as impacts or explosions.



Image: Diagram showing the internal dual vibration motors within the controller's grips, indicating haptic feedback.

6-Axis Gyro Sensor and Gravity Sensing

The integrated 6-axis gyro sensor and gravity sensing functions allow for precise motion control in compatible games. This enables fine movements and quick reactions to enemy attacks.



Image: A user holding the controller, demonstrating how the 6-axis gyro sensor enables directional control, field of view movement, and target aiming in a game.

Touchpad

The high-precision touchpad allows for intuitive interaction and navigation in games that support touch input.



Image: A finger interacting with the controller's touchpad, illustrating its high-precision input capabilities in a game scenario.

3.5mm Headphone Jack

Connect your headset to the 3.5mm audio jack for immersive in-game audio and communication with teammates. Please note that this product does not include a speaker function.



Image: A user enjoying an immersive game experience with headphones connected to the controller's 3.5mm jack. It also shows compatible and incompatible headphone types.

Maintenance

- Clean the controller regularly with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- To charge the controller, always use the included data cable.
- Avoid dropping the controller or subjecting it to strong impacts.

Troubleshooting

Controller moves on its own / Gyro Sensor Calibration

If the controller exhibits unintended movements, you may need to calibrate the gyro sensor:

1. Place the P4 controller on a flat, horizontal surface.
2. Simultaneously press the X button, Square button, and Home button.
3. The red lamp will flash and then turn off, indicating that the calibration is complete.

Connection Issues / Controller Unresponsive

If you are unable to connect the controller or it becomes unresponsive:

- Locate the small 2mm reset hole on the back of the controller.
- Use a needle or a small pointed object to press the reset button inside the hole. This will reset the controller and often resolve connection problems.
- Ensure the controller is sufficiently charged.
- Verify that your console or PC's Bluetooth is enabled and functioning correctly.

Specifications

Feature	Detail
Age Range	All ages
Language	English
Package Size	17 x 11.7 x 7.3 cm
Weight	310 g
Release Date	2024/12/9
Model Number	AB1
Country of Origin	China

Warranty and Support

For warranty information and technical support, please refer to the seller or manufacturer's official website. Keep your purchase receipt as proof of purchase.

© 2024 Matbip. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question