Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bell+Howell 6442

Bell+Howell Elegant Cordless Table Lamp

Model: 6442

Introduction

This manual provides comprehensive instructions for the safe and efficient use of your Bell+Howell Elegant Cordless Table Lamp. Please read this manual thoroughly before operating the device and retain it for future reference.

The Bell+Howell Elegant Cordless Table Lamp is designed to provide versatile and portable lighting with touch-activated controls, multiple light color options, and dimmable brightness. Its rechargeable battery ensures convenience and freedom from power outlets.

Product Features

- **Effortless Touch Activation:** Simple tap control for power and settings adjustment.
- **Cordless and Rechargeable:** Provides a clutter-free setup and sustainable lighting solution.
- **Feather-Light Portability:** Lightweight design allows for easy movement and placement.
- **Adaptable Lighting Modes:** Offers three distinct light colors: warm, white, and daylight.
- **Dimmable Brilliance:** Adjustable brightness to suit various activities and preferences.
- **Durable Construction:** Features a sturdy metal base for stability and elegant design.



Image: The Bell+Howell Elegant Cordless Table Lamp placed on an outdoor table, illustrating its lightweight and portable design for various settings.

What's Included

- 2 x Bell+Howell Elegant Cordless Table Lamps
- USB-C Charging Cable (quantity may vary per package)
- Instruction Manual

Setup

1. Unpacking

Carefully remove all components from the packaging. Inspect the lamps for any signs of damage. Retain packaging materials for future storage or transport if needed.

2. Initial Charging

Before first use, fully charge the lamp. Connect the provided USB-C charging cable to the lamp's charging port and plug the other end into a compatible USB power adapter (not included). A full charge typically takes 3-4 hours. The lamp will indicate when charging is complete (e.g., indicator light changes color or turns off).



Image: A visual representation of the lamp's charging features, including USB-C compatibility, 3-4 hour charge time, and 5-6 hour run time.

3. Placement

Place the lamp on a stable, flat surface. Ensure it is not near sources of excessive heat or moisture. The cordless design allows for flexible placement in bedrooms, kitchens, living areas, or even outdoors in dry conditions.



Image: Examples of the lamp's versatile use in different environments, such as a bedside table, dining table, kitchen counter, and an outdoor setting.

Operating Instructions

Power On/Off and Light Mode Selection

The lamp features intuitive touch controls located on the top surface.

- **To Turn On/Off:** Press the On/Off button located on the top surface of the lamp.
- **To Change Light Modes:** Tap the top surface of the lamp to cycle through the three available light colors: Warm, White, and Daylight.



Image: A visual guide to the lamp's touch controls, showing how to press for power, tap to change light modes, and hold to adjust brightness.



Image: The lamp displaying its three distinct light color options: warm, white, and daylight, suitable for different ambiances.

Adjusting Brightness (Dimming)

To adjust the brightness, touch and hold the top surface of the lamp. The brightness will gradually increase or decrease. Release your finger when the desired brightness level is reached.

Maintenance

Cleaning

To clean the lamp, ensure it is turned off and disconnected from any charging source. Wipe the surface with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.

Battery Care

- To prolong battery life, avoid fully discharging the lamp frequently.
- Charge the lamp regularly, even if not in frequent use, to maintain battery health.

- Store the lamp in a cool, dry place when not in use for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Lamp does not turn on.	Battery is depleted.	Charge the lamp fully using the USB-C cable.
Lamp light is dim or flickers.	Low battery.	Recharge the lamp.
Cannot change light mode or brightness.	Touch sensor issue or lamp malfunction.	Ensure your finger is clean and dry. Try restarting the lamp by turning it off and on. If the issue persists, contact customer support.
Lamp does not charge.	Faulty cable, adapter, or charging port.	Try a different USB-C cable and power adapter. Ensure the charging port is clean and free of debris.

Specifications

Feature	Detail
Model Name	The Lexington
Model Number	6442
Product Dimensions	4.8"D x 4.8"W x 7.67"H
Item Weight	12 ounces
Power Source	Battery Powered
Light Source Type	LED
Number of Light Sources	6
Switch Type	Touch
Material	Iron (Base), Plastic (Shade)
Finish Type	Polished
Special Features	Color Changing, Dimmable, Lightweight, Rechargeable, Touch Activated
Indoor/Outdoor Usage	Indoor
UPC	080313064425

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Bell+Howell website. Keep your proof of purchase for warranty claims.

Official Product Videos

No relevant official seller videos were found for this product in the provided data.

© 2024 Bell+Howell. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHFXSPQW

More documents and user manuals: **https://manuals.plus/**