TCL RC813

TCL RC813 Google TV Remote Control User Manual

Model: RC813

Introduction

This manual provides instructions for the TCL RC813 Google TV Remote Control. This remote is designed to enhance your entertainment experience with seamless control and voice command capabilities for compatible TCL Google TV models.



Front view of the TCL RC813 Google TV Remote Control.

Compatibility

The RC813 remote is compatible with various TCL Google TV models, including S3/S4/S5/Q5/Q6/Q7/QM7/QM8 Series. Specific compatible models include:

- TCL GTV 55Q670G, 65Q670G, 75Q670G, 85Q670G
- TCL GTV 85Q650G, 75Q650G, 65Q650G, 55Q650G
- TCL GTV 55Q750G, 65Q750G, 75Q750G, 85Q750G
- TCL GTV 65QM850G, 75QM850G, 85QM850G, 98QM850G
- TCL GTV 32S370G, 40S370G, 43S370G
- TCL GTV 55S470G, 43S470G, 50S470G, 58S470G, 65S470G, 70S470G, 75S470G, 85S470G
- TCL GTV 43S450G, 50S450G, 55S450G, 58S450G, 65S450G, 75S450G, 85S450G

This remote is specifically designed for TCL Google TVs with voice functionality. It is not compatible with TCL Fire TVs, TCL Roku TVs, or older TCL Android TVs without Google TV integration.

Setup and Pairing

The TCL RC813 remote control is designed for easy setup. No complex programming is required.

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery cover.
3. Insert two AAA batteries, ensuring correct polarity (+ and -).
4. Close the battery cover securely.





Image showing the battery compartment of the RC813 remote control.

2. Initial Pairing (Automatic)

For most compatible TCL Google TVs, the remote will automatically pair upon battery installation and turning on the TV. Simply pull the battery tab (if present) and the remote should connect.

3. Manual Pairing (If needed)

If automatic pairing does not occur, follow these steps to manually pair your remote:

1. Ensure your TCL Google TV is powered on.
2. On the remote, **short press the Google Assistant button** (microphone icon) first.
3. Then, **press and hold the Home button and the OK button simultaneously**for a few seconds until a pairing message appears on your TV screen.
4. The TV screen will indicate "Pairing..." and then "Success!" once the remote is paired.

Your browser does not support the video tag.

Video demonstrating the pairing process for the TCL Google TV remote control.

Your browser does not support the video tag.

Video showing the functionality and ease of use of the TCL Google TV remote.

Operating Instructions

The RC813 remote control offers intuitive navigation and quick access to your favorite content.

Key Features and Buttons:

- **Power Button:** Located at the top right, turns the TV on or off.

- **Google Assistant Button:** Microphone icon, activates voice commands for searching content, launching apps, and controlling TV functions.
- **Navigation Pad (OK button):** Use the directional arrows to navigate menus and the central OK button to select.
- **Home Button:** Returns to the main Google TV home screen.
- **Back Button:** Returns to the previous screen or menu.
- **Volume Buttons (+/-):** Adjusts the TV volume. Located on the side of the remote.
- **Mute Button:** Mutes or unmutes TV audio. Located on the side of the remote.
- **Channel Buttons (CH +/-):** Changes TV channels.
- **Quick Access Buttons:** Dedicated buttons for popular streaming platforms like Netflix, Prime Video, YouTube, TCL Channel, and Apple TV.





Side view of the RC813 remote, highlighting the volume and mute controls.





Back view of the RC813 remote control.

Your browser does not support the video tag.

Video demonstrating the various buttons and their functions on the TCL Google TV remote.

Voice Control Functionality

The integrated Google Assistant allows for convenient voice control. Press the Google Assistant button and speak your command clearly into the remote's microphone.
Examples of voice commands:

- "Open Netflix"
- "Search for action movies"
- "Turn up the volume"
- "Switch to HDMI 1"

Your browser does not support the video tag.

Video illustrating how to use voice control to open Netflix on a TCL Google TV.

Maintenance

- **Cleaning:** Wipe the remote with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always use new AAA batteries and dispose of old batteries responsibly.
- **Storage:** Store the remote in a dry place away from extreme temperatures and direct sunlight.

Troubleshooting

Problem	Solution
Remote not responding.	Check battery installation and replace if necessary. Ensure there are no obstructions between the remote and the TV. Re-pair the remote if needed (see Setup section).
Voice control not working.	Ensure the remote is properly paired. Speak clearly into the microphone. Check TV settings to ensure Google Assistant is enabled.
Buttons are unresponsive or sticky.	Clean the remote surface. If the issue persists, the remote may require replacement.
Remote does not control TV.	Verify TV compatibility (see Compatibility section). Ensure the remote is paired correctly.

Specifications

- **Model Number:** RC813
- **Connectivity Technology:** Infrared (IR) and Bluetooth (for voice control and advanced features)
- **Power Source:** 2 x AAA Batteries
- **Control Range:** Up to 40 feet (approx. 12 meters)
- **Response Time:** Under 0.2 seconds
- **Dimensions:** 9.69 x 1.81 x 0.75 inches (approx. 24.6 x 4.6 x 1.9 cm)
- **Item Weight:** 2.39 ounces (approx. 67.7 grams)

Warranty and Support

For warranty information or technical support, please refer to your TCL TV's original documentation or visit the official TCL support website. This replacement remote typically carries a standard manufacturer's warranty against defects.
Manufacturer: TCL
Date First Available: December 9, 2024

© 2026 TCL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question