topzee AF200EDK

topzee Small Compact Air Fryer 2.1QT (Model AF200EDK) User Manual

Your guide to safe and efficient operation

1. Important Safety Information

Please read all instructions carefully before using your topzee Compact Air Fryer. Retain this manual for future reference.

- Always place the air fryer on a stable, heat-resistant surface, away from walls and other appliances, to ensure proper air circulation.
- Do not immerse the main unit, cord, or plug in water or other liquids.
- Supervise children closely when the appliance is in use.
- Do not operate the air fryer if the cord or plug is damaged, or if the appliance malfunctions. Contact customer support for assistance.
- Avoid using accessories not recommended by the manufacturer, as this may cause injury or damage.
- Do not block any ventilation openings.
- Exercise extreme caution when moving an appliance containing hot oil or other hot liquids.
- Unplug the air fryer from the outlet when not in use and before cleaning. Allow it to cool completely before handling parts.
- This appliance is for household use only. Do not use outdoors.

2. Product Overview

The topzee 2.1QT Compact Air Fryer (Model AF200EDK) is designed for efficient and healthy cooking, offering multiple functions in a small footprint. It is ideal for 1-2 people, perfect for preparing snacks, sides, and small meals with significantly less oil.



Image: The topzee 2.1QT Compact Air Fryer, showcasing its sleek red design and digital control panel.

Key Features:

- **2.1 Quart Capacity:** Suitable for single servings or meals for two.
- **4-in-1 Functionality:** Air Fry, Bake, Roast, and Reheat.
- **Reduced Oil Usage:** Achieves crispy textures with up to 98% less oil compared to traditional frying methods.

- **Compact and Portable:** Lightweight design saves counter space, ideal for small kitchens, dorms, or RVs.
- **Adjustable Temperature Control:** Precise temperature settings for various recipes.
- **60-Minute Timer:** Convenient timer with automatic shut-off.
- **Quiet Operation:** Designed for minimal noise during use.
- **Nonstick & Dishwasher Safe Basket:** Easy to clean components.
- **BPA-Free Materials:** Ensures food safety.



Image: Diagram illustrating the air fryer's precise temperature control and 360-degree airflow technology for optimal cooking results.



Image: Visual representation of the 2.1QT capacity, showing it can accommodate items like chicken wings and french fries, suitable for 1-2 people.

3. Setup and First Use

Unpacking:

1. Carefully remove all packaging materials from the air fryer.
2. Remove any stickers or labels from the appliance.
3. Inspect the air fryer for any signs of damage. Do not use if damaged.

Cleaning Before First Use:

1. Wash the air fryer basket and crisping tray with hot water, dish soap, and a non-abrasive sponge.
2. Rinse thoroughly and dry all parts completely.
3. Wipe the inside and outside of the main unit with a damp cloth.

Placement:

1. Place the air fryer on a flat, stable, heat-resistant surface.
2. Ensure there is at least 6 inches (15 cm) of clear space around the back and sides of the appliance for proper ventilation.
3. Plug the power cord into a grounded electrical outlet.

4. Operating Instructions

The topzee Compact Air Fryer features a user-friendly digital control panel for easy operation.



Image: The topzee air fryer with its digital control panel and a visual guide to various cooking presets.

Basic Operation:

1. **Prepare Food:** Place your ingredients into the air fryer basket. Do not overfill.
2. **Insert Basket:** Slide the basket firmly into the air fryer.

3. **Power On:** Plug in the air fryer. The display will illuminate.
4. **Set Temperature and Time:** Use the digital controls to adjust the desired cooking temperature and time. Refer to recipe guidelines or the quick reference guide on the appliance.
5. **Start Cooking:** Press the Start/Pause button to begin the cooking cycle.
6. **Shake/Flip (Optional):** For even cooking, some foods may require shaking or flipping halfway through the cooking time. The air fryer may alert you to do this. Simply pull out the basket, shake/flip, and reinsert. The cooking will resume automatically.
7. **Finish Cooking:** The air fryer will beep when the timer expires. Carefully pull out the basket and remove food using heat-resistant tongs.

4-in-1 Functions:

This air fryer offers versatile cooking modes:



Image: Visual representation of the four cooking functions: Air Fry, Reheat, Roast, and Bake, with example foods and suggested cooking times.

- **Air Fry:** For crispy foods like fries, chicken wings, and vegetables.
- **Bake:** Ideal for small cakes, muffins, or bread.
- **Roast:** Perfect for meats and larger vegetables.
- **Reheat:** Quickly warms up leftovers while maintaining texture.

Cooking Tips:

- For best results, preheat the air fryer for 3-5 minutes before adding food.
- Lightly spray or toss food with a small amount of oil for extra crispiness.
- Do not overcrowd the basket; cook in batches if necessary to ensure even airflow.
- Adjust cooking times and temperatures based on food quantity and desired crispiness.



Image: A pile of golden french fries, illustrating how the air fryer can cook frozen foods to a crispy finish in minutes.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

Cleaning Steps:

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.
2. **Basket and Tray:** The nonstick basket and crisping tray are dishwasher safe. Alternatively, wash them with hot water, dish soap, and a non-abrasive sponge. Avoid metal scouring pads or harsh detergents that can damage the nonstick coating.
3. **Interior:** Wipe the interior of the air fryer with a damp cloth or sponge. For stubborn food residue, use a mild dish soap.
4. **Exterior:** Clean the exterior with a damp cloth. Do not use abrasive cleaners.
5. **Heating Element:** Gently clean the heating element with a soft brush to remove any food particles.
6. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling or storing the air fryer.



Image: Demonstration of the air fryer basket and crisping tray being cleaned in a dishwasher and manually under running water, highlighting their dishwasher-safe and easy-to-clean properties.

6. Troubleshooting

If you encounter issues with your topzee Compact Air Fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet issue; appliance malfunction.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. If the issue persists, contact customer support.
Food is not cooked evenly.	Basket overcrowded; food not shaken/flipped; incorrect temperature/time.	Cook in smaller batches. Shake or flip food halfway through cooking. Adjust temperature and time as needed.
Food is not crispy.	Too much moisture; not enough oil; basket overcrowded.	Pat food dry before cooking. Lightly spray or toss with oil. Do not overcrowd the basket. Increase cooking time or temperature slightly.
White smoke coming from the air fryer.	Grease residue from previous use; high-fat food.	Clean the basket and crisping tray thoroughly after each use. For high-fat foods, drain excess fat during cooking.
Appliance smells during first use.	Normal for new appliances.	This is normal and will dissipate after a few uses. Ensure good ventilation.

7. Specifications

Feature	Detail
Model Name	AF200EDK
Capacity	2.1 Quarts
Product Dimensions (D x W x H)	9.4" x 9.4" x 12"
Item Weight	5.79 pounds
Output Wattage	1000 Watts
Control Method	Touch (Manual Controller Type)
Material	Plastic (Polypropylene Outer Material)
Special Feature	Programmable
Nonstick Coating	Yes
Dishwasher Safe Parts	Yes (Basket and Tray)
Air Frying Technology	Convection

8. Warranty Information

For information regarding the product warranty, please refer to the warranty card included with your purchase or contact topzee customer support directly. Keep your proof of purchase for warranty claims.

9. Customer Support

If you have any questions, require assistance, or need to report an issue with your topzee Compact Air Fryer, please contact our customer support team.



Image: An icon representing customer support with the email address.

Email: Support@topzee.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question