Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bonnlo G57000742+G57000743

Bonnlo 4 Burner Portable Propane Griddle Instruction Manual

Model: G57000742+G57000743

1. Important Safety Information

Please read and understand all safety warnings and instructions before assembling, operating, or servicing this griddle. Failure to follow these instructions could result in fire, explosion, or burn hazard, which could cause property damage, personal injury, or death.

- **Outdoor Use Only:** This griddle is designed for outdoor use only. Do not operate indoors or in an enclosed area.
- **Ventilation:** Ensure adequate ventilation. Do not obstruct the flow of combustion and ventilation air.
- **Propane Gas Only:** Use only propane gas. Do not connect to a natural gas supply.
- **Leak Testing:** Always perform a leak test on all gas connections before initial use and after any cylinder change.
- **Clearance:** Maintain minimum clearances from combustible materials: 24 inches from sides and back.
- **Children and Pets:** Keep children and pets away from the griddle at all times.
- **Flammable Materials:** Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- **Hot Surfaces:** The griddle surfaces become extremely hot during use. Use heat-resistant gloves and appropriate tools.
- **Regulator:** Use only the pressure regulator and hose assembly supplied with this appliance.

2. Product Overview

The Bonnlo 4 Burner Portable Propane Griddle is designed for versatile outdoor cooking. It features four independent stainless steel burners, providing a total of 40,000 BTUs for efficient and even heating. The griddle includes an enameled cooking surface, side shelves for convenience, and a portable design with wheels for easy transport.



Figure 2.1: Overview of the Bonnlo 4 Burner Portable Propane Griddle, showcasing its main components including the griddle top, control panel, side shelves, and wheeled cart.

Key Features:

- **Efficient High Heat:** Four independent burners, each delivering 10,000 BTUs, totaling 40,000 BTUs for rapid and consistent heating.
- **Durable Construction:** Made with high-quality stainless steel and sturdy iron for longevity and an elegant appearance.
- **Easy to Operate:** Features a durable stainless steel control panel and a quick-start electronic ignition system.
- **Wide Cooking Space:** Offers 426 square inches of cooking area (30" x 14.2") for various cooking needs.
- **Portable Design:** Equipped with built-in wheels for easy movement and storage.

3. Assembly and Setup

The griddle is designed for simple assembly. Follow these steps carefully to ensure proper setup.



Figure 3.1: Exploded view showing the main components of the griddle for assembly, including the griddle top, burner unit, side shelves, cart frame, wheels, and regulator hose.

Assembly Steps:

1. Unpack all components and verify against the parts list provided in your package.
2. Attach the legs to the main burner unit, ensuring they are securely fastened.
3. Install the bottom shelf and the middle storage rack onto the leg assembly.
4. Secure the wheels to the designated leg side for portability.
5. Mount the side shelves to the main burner unit.
6. Place the enameled griddle top onto the burner unit.
7. Connect the regulator hose to the griddle's gas inlet and to a standard 20 lb propane tank (not included). Ensure all connections are tight.
8. Perform a leak test on all gas connections using a soapy water solution. Bubbles indicate a leak. Tighten connections or replace parts as necessary.

4. Operating Instructions

Follow these steps for safe and effective operation of your Bonnlo griddle.



Figure 4.1: Detail of the control panel, showing the individual burner control knobs and the electronic ignition button for precise temperature management and easy startup.

Ignition Procedure:

1. Ensure the propane tank valve is fully open.
2. Turn one burner control knob to the 'MAX' position.
3. Immediately press and hold the electronic ignition button. You should hear a clicking sound and see the burner ignite.
4. Once ignited, release the ignition button.
5. Repeat for other burners as needed.
6. If a burner does not ignite within 5 seconds, turn the control knob to 'OFF', wait 5 minutes for gas to dissipate, and then repeat the ignition procedure.

Temperature Control:

Each burner has an independent control knob, allowing you to adjust the flame size from 'MIN' to 'MAX'. This enables precise temperature control across different cooking zones on the griddle surface.

5. Cleaning and Maintenance

Regular cleaning and maintenance will extend the life of your griddle and ensure optimal performance.



Figure 5.1: Illustration of the griddle's oil leak hole and the removable grease cup, highlighting features designed for easy cleaning and maintenance.

After Each Use:

- Allow the griddle to cool completely.
- Scrape off any food residue from the griddle surface using a griddle scraper.
- Empty and clean the grease drip tray and enamel tray. These are designed to collect excess grease for easy disposal.

- Wipe down the griddle surface with a damp cloth. For stubborn residue, use a mild soap and water solution.
- Clean the exterior surfaces with a soft cloth and mild detergent.

Storage:

When not in use, store the griddle in a dry, protected area. Disconnect the propane tank and store it upright in a well-ventilated area, away from direct sunlight or heat sources.

6. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Burner fails to ignite	No gas flow; Clogged burner port; Faulty igniter	Check propane tank connection and level; Clean burner ports; Check igniter electrode and wire.
Uneven heating	Clogged burner ports; Low gas pressure	Clean burner ports; Ensure propane tank is not low and regulator is functioning correctly.
Gas leak detected (smell of gas)	Loose connections; Damaged hose/regulator	Immediately turn off gas supply. Perform a leak test. Tighten connections or replace faulty components. Do not operate if a leak is present.
Low flame, even on MAX setting	Low propane level; Regulator bypass activated	Replace or refill propane tank. Reset regulator by turning off all burner knobs, closing tank valve, disconnecting regulator, waiting 1 minute, reconnecting, slowly opening tank valve, then igniting.

7. Specifications

Detailed specifications for the Bonnlo 4 Burner Portable Propane Griddle.



Figure 7.1: Dimensional overview of the Bonnlo 4 Burner Portable Propane Griddle, including overall dimensions and cooking surface area.

Feature	Detail
Model Number	G57000742+G57000743
Brand	Bonnlo
Fuel Type	Propane
Total BTU	40,000 BTU (4 x 10,000 BTU per burner)
Cooking Surface Dimensions	30" L x 14.2" W (426 sq. inches)
Overall Dimensions	52.4" L x 15.4" W x 32.5" H
Material	Iron, Stainless Steel
Color	Black

Feature	Detail
Ignition Type	Electronic (Piezo)
Special Feature	Portable wheels
Included Components	Propane Griddle with Cart, Regulator, Instruction Manual

8. Warranty and Support

Warranty Information:

For specific warranty details regarding your Bonnlo 4 Burner Portable Propane Griddle, please refer to the warranty card included with your product or contact the manufacturer directly. Warranty terms typically cover defects in materials and workmanship under normal use.

Customer Support:

If you have any questions, require assistance with assembly, operation, or troubleshooting, or need to report a damaged or missing part, please contact Bonnlo customer support. Have your model number (G57000742+G57000743) and purchase information ready when contacting support.

- **Manufacturer:** Bonnlo
- **Contact Information:** Please refer to the contact details provided in your product packaging or visit the official Bonnlo website for the most current support information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHKR2NVG

More documents and user manuals: **https://manuals.plus/**