Skil MS6306-00

SKIL 10 Amp 7-1/4" Single Bevel Miter Saw Instruction Manual

Model: MS6306-00

Introduction

The SKIL 10 Amp 7-1/4 In. Single Bevel Sliding Miter Saw is designed for precise cutting of various materials, including baseboards, casing, crown moulding, and planks. Its advanced features ensure accuracy and efficiency for both professional and DIY projects.



Figure 1: Overall view of the SKIL 10 Amp 7-1/4 inch Single Bevel Miter Saw.

Safety Information

Always prioritize safety when operating power tools. Read and understand all instructions before use. Failure to follow safety guidelines can result in serious injury.

- Wear appropriate personal protective equipment (PPE), including safety glasses, hearing protection, and a dust mask.
- Ensure the workpiece is securely clamped before cutting.
- Keep hands and fingers clear of the blade path.
- Disconnect power before making adjustments or changing blades.
- Maintain a clean and well-lit work area.
- Do not operate the saw in damp or wet conditions.

Components and Features

Familiarize yourself with the main components and key features of your miter saw:

LED Shadow Line



This feature projects a precise shadow of the blade onto the workpiece, indicating the exact cut line. It offers greater accuracy compared to traditional laser guides.

Quick Miter Lock



Allows for quick and accurate adjustments of miter angles, enhancing efficiency during repetitive cuts.

Compact Rail System



Minimizes the saw's footprint, enabling flush cutting against walls and saving valuable workspace.

10 Amp Motor



Provides up to 4,800 RPM for fast and detailed cuts through various wood types.

Quick Work Clamp

Securely holds materials in place for safer and more stable cutting operations.

Lightweight Design

Facilitates easy transport and storage of the miter saw.

Single Bevel

Allows for bevel cuts from 0 to 45 degrees to the left.

Setup

Before operating your miter saw, ensure proper setup:

1. **Unpacking:** Carefully remove all components from the packaging. Verify that all listed parts are present, including the dust bag, double-ended Allen wrench, quick clamp, and 7-1/4-inch 24T carbide blade.
2. **Mounting:** Securely mount the miter saw to a stable workbench or a compatible miter saw stand (e.g., SKIL Rolling Stand SRS0001, sold separately). Use appropriate fasteners to prevent movement during operation.
3. **Blade Installation:** Ensure the saw is unplugged. Follow the instructions in the manual to safely install the 7-1/4 inch 24T carbide blade. Verify the blade is oriented correctly for cutting.
4. **Dust Bag Attachment:** Attach the dust bag to the designated port to help manage sawdust during operation. For better dust collection, connect to a shop vacuum system if available.
5. **Initial Calibration Check:** While the saw is designed for accuracy out of the box, it is recommended to perform a quick check of the blade's squareness to the fence and table at 0 and 90 degrees. Adjust if necessary according to the detailed instructions in the full product manual.

Operating Instructions

Follow these steps for safe and effective operation of your SKIL miter saw:

1. **Prepare Workpiece:** Place the material to be cut firmly against the fence and on the miter saw table.
2. **Secure Workpiece:** Use the quick work clamp to securely hold the material in place. This prevents movement and kickback during cutting.
3. **Adjust Miter Angle:** For miter cuts, release the quick miter lock and adjust the miter table to the desired angle. Re-engage the lock to secure the setting.
4. **Adjust Bevel Angle (if needed):** For bevel cuts, adjust the saw head to the desired angle (0 to 45 degrees left). Lock the bevel adjustment.
5. **Align Cut:** Lower the blade slightly to engage the LED shadow line. Align the shadow with your marked cut line on the workpiece.
6. **Start Saw:** With the blade clear of the workpiece, press the trigger to start the motor and allow the blade to reach full speed.
7. **Make Cut:** Slowly and steadily lower the blade through the material. For sliding cuts (on wider materials), push the saw head forward through the material while maintaining downward pressure.
8. **Complete Cut:** Once the cut is complete, release the trigger and allow the blade to stop spinning before raising the saw head.
9. **Remove Workpiece:** Carefully remove the cut material from the saw table.

Cutting Capacity: This saw can cross-cut lumber up to 2x10 at 90 degrees and 2x6 lumber at 45 degrees.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your miter saw:

- **Cleaning:** After each use, unplug the saw and use a brush or compressed air to remove sawdust and debris from the motor vents, blade guard, and table.
- **Blade Inspection:** Periodically inspect the blade for sharpness, damage, or missing teeth. Replace dull or damaged blades promptly.
- **Lubrication:** Apply a light coat of machine oil to the sliding rails to ensure smooth operation. Refer to the full manual for specific lubrication points and frequency.

- **Cord Inspection:** Check the power cord for any signs of damage, fraying, or cuts. Replace damaged cords immediately.
- **Fastener Check:** Ensure all nuts, bolts, and screws are tight. Re-tighten as needed.

Troubleshooting

Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
Saw does not start	No power, faulty switch, tripped circuit breaker	Check power connection, test outlet, reset breaker, contact service if switch is faulty.
Cuts are not accurate/square	Blade not square to fence/table, dull blade, loose components	Calibrate saw, replace blade, tighten all fasteners.
Excessive dust	Dust bag full or improperly attached, dust port clogged	Empty and reattach dust bag, clear dust port. Consider connecting to a shop vacuum.
Blade binds or smokes	Dull blade, improper feed rate, workpiece not secured	Replace blade, reduce feed rate, ensure workpiece is clamped firmly.

Specifications

Attribute	Detail
Brand	Skil
Model Number	MS6306-00
Power Source	Corded Electric
Motor Amperage	10 Amp
Blade Diameter	7-1/4 inches
Blade Material	Carbide
No-Load Speed	Up to 4,800 RPM
Bevel Capacity	0 to 45 degrees Left
Product Dimensions (L x W x H)	25.98"L x 18.11"W x 14.76"H
Item Weight	36.6 pounds
Included Components	10 Amp 7-1/4 In. Single Bevel Sliding Miter Saw, Dust Bag, Double-ended Allen Wrench, Quick Clamp, 7-1/4-inch 24T Carbide Blade

Warranty and Support

For warranty information, product registration, or technical support, please refer to the official Skil website or contact their customer service. Keep your purchase receipt for warranty claims.
You can visit the official Skil Store for more information:Skil Store on Amazon

Protection plans are also available for extended coverage:

- 3-Year Protection Plan: $33.99
- 4-Year Protection Plan: $44.99
- Complete Protect: $16.99/month (covers all eligible past and future purchases)

© 2025 Skil. All rights reserved.