Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Effireli YK-J1-06

Effireli J1-06(E) Replacement Remote Control User Manual

For Hisense Air Conditioners

1. Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Effireli J1-06(E) replacement remote control for Hisense Air Conditioners. This remote is designed to function without any programming or complex setup, offering a straightforward user experience.

Compatible Models:

- AP10CW2G
- AP12CR1SEPS
- AP13HR1SEJS00
- AP-14DR1SFJS2
- AP-13HR1SEJS00
- AP-08CR1SEJS
- AP12CR1G
- AP14DR1G
- AP14CR1WG
- AP10CR1W
- AP13HR1G
- AP08CR1SEJSC
- AP14DR1SFJS2
- AP10CW1G
- AP10CR1SEPS
- AP-10CR1SEPS
- AP10CR1SEJS
- AP08CR1W
- AP14DR1SFJS2
- AP-10CR1SEJS
- AP-12CR1SEJS
- AP-12CR1SEPS
- AP14CR2WG

- AP08CR2W
- AP10CR2W
- AP12CR2G
- AP13HR2G

Note: If your specific air conditioner model number is not listed above or your original remote control appears different, please contact customer support to confirm compatibility before use.

2. Setup

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

2.2 Initial Use

This replacement remote control requires no programming or pairing. Once batteries are installed, it is ready for immediate use. Simply point the remote towards your Hisense Air Conditioner and begin operation.

3. Operating Instructions

Familiarize yourself with the buttons and display on your remote control:



Figure 1: Effireli J1-06(E) Replacement Remote Control Layout. This image shows the full remote control with its display screen at the top and various function buttons arranged below it. The display shows temperature '24' and time '00:00'. Key buttons include ON/OFF, MODE, FAN, SWING, SLEEP, SUPER, SMART, IFEEL, DIMMER, TIMER ON, TIMER OFF, CLOCK, and temperature adjustment buttons.

3.1 Button Functions

Button	Function
ON/OFF	Powers the air conditioner on or off.
MODE	Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
FAN	Adjusts the fan speed (e.g., Low, Medium, High, Auto).
▲ / ▼ (Temperature)	Increases (▲) or decreases (▼) the set temperature.
SWING (top)	Activates or adjusts the vertical louver swing function.
SWING (bottom)	Activates or adjusts the horizontal louver swing function.
SLEEP	Activates the sleep mode, which adjusts temperature for comfortable sleep and energy saving.
SUPER	Engages the powerful cooling/heating mode for rapid temperature change.
SMART	Activates the smart mode, which automatically selects the optimal operating mode based on room temperature.
IFEEL	Activates the iFeel function, which senses the temperature at the remote's location for more precise control.
DIMMER	Adjusts the brightness of the air conditioner's display panel.
TIMER ON	Sets a timer for the air conditioner to turn on automatically.
TIMER OFF	Sets a timer for the air conditioner to turn off automatically.
CLOCK	Sets the current time on the remote control's display.

3.2 Display Indicators

- **Temperature Display:** Shows the set temperature (e.g., "24").
- **Time Display:** Shows the current time or timer settings (e.g., "00:00").
- **Mode Icons:** Icons indicating the current operating mode (e.g., snowflake for cooling, fan icon for fan mode).
- **Fan Speed Indicator:** Bars or icons indicating the selected fan speed.

4. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's range decreases or the display becomes dim. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and corrosion. Store in a cool, dry place.
- **Avoid Exposure:** Do not expose the remote control to direct sunlight, high temperatures, humidity, or strong impacts.

5. Troubleshooting

Problem	Possible Cause	Solution
Remote not responding	Dead or incorrectly inserted batteries. Obstruction between remote and AC unit. Remote out of range.	Replace batteries, ensuring correct polarity. Remove any obstructions. Move closer to the AC unit.
Display is dim or blank	Low battery power.	Replace batteries.
Specific function not working	Air conditioner model may not support that specific function.	Refer to your air conditioner's original manual to confirm supported features.

6. Specifications

Feature	Detail
Model Number	YK-J1-06
Product Dimensions	5.98 x 1.97 x 0.51 inches
Item Weight	2.26 ounces
Connectivity Technology	Infrared
Compatible Devices	Hisense Air Conditioners (specific models listed in Introduction)
Special Feature	No Programming Required
Max Number of Supported Devices	1

7. Warranty and Support

7.1 Warranty Information

Your Effireli J1-06(E) replacement remote control comes with a**30-day money-back guarantee** from the date of purchase. Additionally, it is covered by a **12-month warranty** against manufacturing defects. Returns and exchanges are accepted within this warranty period for eligible issues.

7.2 Customer Support

For any questions, troubleshooting assistance, or warranty claims, please contact Effireli customer support. Refer to your purchase documentation for specific contact details or visit the official Effireli website.
Note: When contacting support, please have your product model number (YK-J1-06) and purchase information ready.

© 2024 Effireli. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHW3KY4F

More documents and user manuals: **https://manuals.plus/**