Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ikarao Break X1

Ikarao Break X1 Karaoke Machine User Manual

Model: Break X1

1. Introduction

Thank you for choosing the Ikarao Break X1 Karaoke Machine. This all-in-one portable karaoke system features a 13.3-inch touchscreen, integrated streaming apps, dual wireless microphones with automatic charging, and powerful audio output. This manual provides essential information for setting up, operating, and maintaining your device to ensure optimal performance and enjoyment.



Figure 1.1: Ikarao Break X1 Karaoke Machine Overview

2. What's in the Box

Please check the package contents carefully. If any items are missing or damaged, contact customer support.

- Ikarao Break X1 Karaoke Machine (Main Unit)
- 2 x Wireless Microphones
- Power Adapter
- Shoulder Strap
- User Manual (this document)

3. Setup

3.1 Unpacking

1. Carefully remove all components from the packaging.
2. Retain the packaging for future transport or storage.

3.2 Initial Charging

Before first use, fully charge the Ikarao Break X1 and its wireless microphones.

1. Connect the power adapter to the AC input port on the rear of the main unit.
2. Plug the power adapter into a wall outlet. The charging indicator will illuminate.
3. Place the wireless microphones into their designated charging slots on top of the main unit (under the touchscreen when folded down). They will begin charging automatically.
4. Allow approximately 4-6 hours for a full charge of the main unit and microphones.



Figure 3.1: Smart Power System and Charging Ports

4. Operating Instructions

4.1 Power On/Off

- **To Power On:** Press and hold the Power button (usually located on the side or top panel) for a few seconds until the screen illuminates.
- **To Power Off:** Press and hold the Power button again until a power-off prompt appears on the screen, then confirm.

4.2 Touchscreen Navigation

The Ikarao Break X1 features a 13.3-inch HD touchscreen with a 180-degree rotation capability. Navigate the Android-based interface by tapping, swiping, and using on-screen controls similar to a smartphone or tablet.



Figure 4.1: 13.3" HD Screen with Rotation

4.3 Microphone Usage

The two wireless microphones connect automatically when powered on and removed from their charging slots.

- **Power On/Off:** Press the power button on each microphone.
- **Volume Control:** Use the +/- buttons on the microphone or the main unit's controls.
- **Sound Effects:** Access microphone settings on the main unit's touchscreen to adjust reverb, treble, bass, and select from various voice effects (e.g., Original, Karaoke, Super, Popular, Profession, Cartoon, Monster, Custom).



Figure 4.2: Microphone Modes and EQ Settings

4.4 Audio Input/Output & Connectivity

The Break X1 offers multiple connection options:

- **Bluetooth:** Enable Bluetooth on your external device (smartphone, tablet) and select

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHZM8P16

More documents and user manuals: **https://manuals.plus/**