JVC HANP40TG

JVC nearphones Open Ear True Wireless Headphones User Manual

Model: HANP40TG

Product Overview

The JVC nearphones are open-ear true wireless headphones designed for comfort and awareness of your surroundings. Featuring a Pivot Motion Mechanism for a secure fit, 16mm large drivers for clear sound, Bluetooth 5.4 for stable connectivity, and an IPX4 water-resistant rating, these headphones are suitable for various activities. The included charging case provides extended battery life.



Image: A pair of JVC nearphones in green, showcasing their open-ear design and ear hooks.

What's in the Box

- JVC nearphones (Left and Right)
- Wireless Charging Case
- USB Charging Cable

Setup Guide

1. Charging the Headphones and Case

Before first use, fully charge the headphones and the charging case. Place the headphones into the charging case. Connect the USB charging cable to the case and a power source. The indicator light on the case will show charging status. A full charge provides up to 26 hours of total playback (7.5 hours from headphones + 18.5 hours from case).



Image: Illustration showing the JVC nearphones in their charging case, highlighting the 26-hour total battery life.

2. Pairing with a Bluetooth Device

1. Ensure the headphones are charged.
2. Open the charging case. The headphones will automatically enter pairing mode (indicator lights will flash).
3. On your device (smartphone, tablet, etc.), go to Bluetooth settings and turn Bluetooth on.
4. Select "JVC HANP40T" from the list of available devices.
5. Once connected, the indicator lights on the headphones will stop flashing.

The headphones support Bluetooth 5.4 for a stable and efficient connection.

Operating Instructions

Wearing the Headphones

The JVC nearphones feature a Pivot Motion Mechanism and are designed to fit securely and comfortably over your ear

without blocking the ear canal. This open-ear style allows you to hear ambient sounds while enjoying your audio, enhancing safety in outdoor environments.



Image: A diagram illustrating how the Pivot Motion Design of the JVC nearphones allows for a secure and natural fit around the ear.



Image: A woman performing crunches while wearing the JVC nearphones, demonstrating their secure fit during physical activity.

Touch Controls

The nearphones feature intuitive touch controls on each earbud for managing playback, calls, and sound modes.

Action	Function
Single Tap (Left/Right)	Play/Pause, Answer/End Call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (Left/Right)	Activate Voice Assistant
Long Press (Left/Right)	Cycle Sound Modes (Normal, Bass, High)

Sound Modes

The headphones offer three distinct sound modes to customize your listening experience:

- **Normal:** Balanced audio for everyday listening.
- **Bass:** Enhanced bass for a richer, more impactful sound.
- **High:** Accentuated treble for clearer vocals and instruments.

Cycle through these modes using the long press touch control.

Single Ear Use

Either the left or right earbud can be used independently for mono listening. Simply remove one earbud from the case and leave the other in, or place one back into the case while using the other.

Maintenance and Care

Water Resistance (IPX4)

The JVC nearphones are rated IPX4, meaning they are resistant to splashing water from any direction. This makes them suitable for workouts and light rain. However, they are not designed for submersion in water. Do not expose them to strong jets of water or prolonged immersion.



Image: The JVC nearphones shown with water splashing around them, illustrating their IPX4 splashproof rating.

Cleaning

Wipe the headphones and charging case with a soft, dry cloth. Do not use abrasive cleaners or solvents. Ensure the charging contacts are clean and dry before placing the headphones back into the case for charging.

Troubleshooting

Problem	Possible Cause	Solution
Headphones not pairing	Not in pairing mode, device Bluetooth off, out of range.	Ensure headphones are in pairing mode (open case), turn device Bluetooth on/off, move closer to device.
No sound from one earbud	Earbud not connected, low battery.	Place both earbuds back in case, close and reopen. Check battery level.
Low volume	Device volume too low, sound mode setting.	Increase volume on your device. Try different sound modes (Normal, Bass, High).
Headphones not charging	Cable issue, dirty contacts, power source issue.	Check USB cable connection. Clean charging contacts on headphones and case. Try a different power source.

Specifications

Model Name: NEARPHONES (HANP40T)

Brand: JVC

Connectivity Technology: Wireless (Bluetooth 5.4)

Bluetooth Range: 10 Meters

Ear Placement: Open Ear

Audio Driver Size: 16 Millimeters

Frequency Response: 20000 Hz

Impedance: 16 Ohm

Battery Life (Headphones): Up to 7.5 Hours

Battery Life (with Charging Case): Up to 26 Hours

Charging Case Battery Capacity: 420 Milliamp Hours

Charging Case Charging Time: 2 Hours

Water Resistance Level: IPX4 (Splashproof)

Control Type: Touch Control, Voice Control

Item Weight: 4.9 ounces

Product Dimensions: 2.99 x 1.81 x 5.79 inches

Material: Plastic

Color: Green

Manufacturer: JVC

Country of Origin: China

Official Product Video

Your browser does not support the video tag.

Video: An official product video showcasing the features and benefits of the JVC nearphones, including their open-ear design, secure fit, long battery life, touch controls, and splashproof rating.

Warranty and Support

For warranty information and customer support, please refer to the official JVC website or contact their customer service department. Keep your proof of purchase for any warranty claims.

Additional protection plans may be available for purchase to extend coverage beyond the standard manufacturer's warranty. Please check with your retailer for details on available plans.
For further assistance, visit the JVC Store on Amazon.

© 2025 JVC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question