Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

W-KING T9-2

W-KING T9-2 Bluetooth Speaker User Manual

Model: T9-2

Introduction

Thank you for purchasing the W-KING T9-2 Bluetooth Speaker. This manual provides detailed instructions for operating and maintaining your speaker. Please read this manual thoroughly before use to ensure proper operation and to maximize the product's lifespan.





Front view of the W-KING T9-2 Bluetooth Speaker, showcasing its dual illuminated woofers and robust design.

Safety Information

- Do not expose the speaker to extreme temperatures or direct sunlight for prolonged periods.
- Avoid dropping or subjecting the speaker to strong impacts.
- Keep the speaker away from water and liquids. While it is IPX5 water-resistant, it is not designed for submersion.
- Use only the specified 5V/2A power adapter for charging (not included).
- Do not attempt to disassemble, repair, or modify the speaker yourself. Contact qualified service personnel for assistance.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.

Package Contents

Please check the package contents upon unboxing:

- W-KING T9-2 Bluetooth Speaker
- 3.5mm AUX cable

- User Manual (this document)

Product Overview

Familiarize yourself with the components and controls of your W-KING T9-2 speaker.



Internal components of the W-KING T9-2, highlighting the 4.04-inch woofers, 1.2-inch tweeters, and the bass reflex tube for enhanced audio performance.

Key Features:

- **180W PEAK Power Output:** Delivers powerful and clear audio.
- **4 Drivers:** Two 4.04-inch subwoofers and two 1.2-inch tweeters for balanced sound.
- **DSP Technology:** Enhances sound quality for high-fidelity stereo.
- **Bass Reflex Tube:** Provides deeper and more natural bass.
- **IPX5 Water Resistant:** Protects against splashes and light rain.

- **24-Hour Playtime:** Extended battery life for prolonged use.
- **Vibrant LED Lights:** Dynamic light rings with multiple effects.
- **Multiple Playback Modes:** Bluetooth 5.0, AUX, TF Card, U-Disk.
- **EQ Modes:** Customize your listening experience.
- **Wireless Stereo Pairing:** Connect two T9-2 speakers for 360W PEAK stereo sound.

Setup

Charging the Speaker:

1. Locate the charging port on the speaker.
2. Connect a 5V/2A power adapter (not included) to the charging port.
3. The charging indicator light will show the charging status. It will turn off or change color when fully charged.
4. For optimal battery life, fully charge the speaker before first use.

Powering On/Off:

- **To Power On:** Press and hold the Power button for a few seconds until you hear an audible prompt and the LED lights illuminate.
- **To Power Off:** Press and hold the Power button again for a few seconds until you hear an audible prompt and the LED lights turn off.

Operating Instructions

Bluetooth Pairing:

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing Bluetooth indicator light).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "W-KING T9-2" from the list of devices.
4. Once connected, you will hear a confirmation sound, and the Bluetooth indicator light will become solid.

Wireless Stereo Pairing (TWS Function):

You can pair two W-KING T9-2 speakers together for a true wireless stereo experience.*Note: T9-2 speakers cannot be paired with T9 models.*

1. Ensure both T9-2 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press the TWS button (often indicated by two interlocking circles or a similar icon).
3. The speaker will search for another T9-2 speaker. Once found, they will automatically pair.
4. You will hear a confirmation sound when TWS pairing is successful. The primary speaker's Bluetooth indicator will flash, and the secondary speaker's will be solid.
5. Now, connect your device to the primary speaker via Bluetooth as described above. Audio will play through both speakers in stereo.



Illustration of two W-KING T9-2 speakers connected via True Wireless Stereo (TWS) for an enhanced audio experience.

Playback Modes (AUX, TF Card, U-Disk):

The T9-2 supports various playback options:



Side panel of the W-KING T9-2 speaker, illustrating the various input ports for Bluetooth, TF Card, AUX, and USB flash drives.

- **AUX Mode:** Insert the provided 3.5mm AUX cable into the AUX port on the speaker and connect the other end to your audio source (e.g., TV, laptop). The speaker will automatically switch to AUX mode.
- **TF Card Mode:** Insert a TF (microSD) card with audio files into the TF card slot. The speaker will automatically detect and play music from the card.
- **U-Disk Mode:** Insert a USB flash drive with audio files into the USB port. The speaker will automatically detect and play music from the drive.
- **Switching Modes:** Use the Mode button on the speaker to cycle through Bluetooth, AUX, TF Card, and U-Disk modes.

EQ Modes:

The T9-2 features EQ modes to optimize your listening experience. Press the EQ button to cycle through available sound profiles (e.g., Bass Boost, Vocal, Normal). Each mode adjusts the balance of mids, treble, and bass.

LED Light Control:

The speaker features dynamic LED light rings. Press the Light button to cycle through different light effects and colors. The lights can sync with the music beat for an immersive visual experience.



The W-KING T9-2 speaker displaying its dynamic LED party lights, which can change with the beat of the music.

Maintenance

- **Cleaning:** Use a soft, lint-free cloth to wipe the speaker's surface. For stubborn dirt, slightly dampen the cloth with water. Do not use harsh chemicals, solvents, or abrasive cleaners.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use, to maintain battery health.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery; Power button not held long enough.	Charge the speaker; Press and hold the Power button for 3-5 seconds.
Cannot pair via Bluetooth.	Speaker not in pairing mode; Device Bluetooth off; Too far from speaker.	Ensure speaker is flashing Bluetooth light; Turn on device Bluetooth; Move device closer (within 33ft/10m).
No sound.	Volume too low; Incorrect input mode; Device not playing audio.	Increase speaker/device volume; Switch to correct mode (Bluetooth, AUX, TF, U-Disk); Check audio playback on device.
TWS pairing fails.	Not two T9-2 speakers; Speakers too far apart; Already connected to a device.	Ensure both are T9-2 models; Place speakers close together; Disconnect any existing Bluetooth connections before TWS pairing.

Specifications

Feature	Detail
Model Name	T9-2
Speaker Type	Outdoor Portable Bluetooth Speaker
Peak Power Output	180W (Single Speaker), 360W (TWS Paired)
Drivers	2 x 4.04" Woofers, 2 x 1.2" Tweeters
Sound Pressure Level	105dB
Connectivity	Bluetooth 5.0, AUX (3.5mm), TF Card, U-Disk
Water Resistance	IPX5 (Splashproof)
Battery Life	Up to 24 Hours (Varies with volume and light usage)
Charging Input	5V/2A (Adapter not included)
Material	Metal
Included Components	3.5mm AUX cable

Warranty and Support

The W-KING T9-2 Bluetooth Speaker comes with a limited warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact W-KING customer service through the retailer where you purchased the product or visit the official W-KING website.

Manufacturer: W-KING

Item Model Number: T9-2

Date First Available: September 27, 2024

© 2024 W-KING. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DJ2Z6FT8

More documents and user manuals: **https://manuals.plus/**