oneisall C61

oneisall Dog Clippers with Double Blades (Model: C61)

Cordless Small Pet Hair Grooming Trimmer User Manual

Introduction

Thank you for choosing the oneisall Dog Clippers. This cordless grooming trimmer is designed for precise and gentle trimming of pet hair around small, sensitive areas such as paws, eyes, ears, face, and rump. Featuring double blades and a low-noise design, it ensures a comfortable grooming experience for your pet. Please read this manual thoroughly before first use to ensure proper operation and maintenance.



Image: The oneisall Dog Clippers set, showing two clippers, two different sized blades, two USB charging cords, two cleaning brushes, and two small oil bottles. One clipper is shown in use on a dog's paw.

Safety Information

Please observe the following safety precautions to prevent injury or damage to the device:

- Keep blades away from eyes and face during operation.
- Do not use this device on infants or near water sources.
- Always unplug the device and allow it to cool before cleaning or performing maintenance.
- Follow all recommended maintenance procedures outlined in this manual.
- Store the clippers in a dry place, out of reach of children and pets.

Package Contents

Your oneisall Dog Clipper set includes the following items:

- oneisall Dog Clipper (x2)
- Small Blade (pre-installed or separate, x2)
- Middle Blade (x2)
- Cleaning Brush (x2)
- USB Charging Cord (x2)

Setup

1. Charging the Clippers

Before first use, fully charge the clippers. Connect the USB charging cord to the charging port on the clipper and plug the other end into a compatible USB power adapter (not included). The indicator light will show charging status. A full charge takes approximately 2 hours and provides about 2 hours of working time.



Image: A close-up of the oneisall clipper being charged via a USB cable, with text indicating "Long Lasting Battery" and "Working Time 2 Hours, Charging Time 2 Hours".

2. Attaching/Changing Blades

The clippers come with two blade sizes: a small blade for very detailed work and a middle blade for slightly larger small areas. To attach or change a blade, align the blade with the clipper head and gently push until it clicks into place. To remove, twist the blade counter-clockwise and pull it off.



Image: Diagrams illustrating how to remove and attach the clipper blade by twisting and pulling, and showing the blade being washed under water.

Operating Instructions

1. Preparing Your Pet

Before grooming, ensure your pet's fur is clean and dry. Brush out any tangles or mats. It is recommended to introduce the clippers to your pet gradually, allowing them to get used to the sound and vibration before actual trimming.



Image: Two sleeping kittens next to the oneisall clipper, illustrating its low noise level (≤60dB) compared to a louder 80dB clipper.

2. Powering On and Speed Adjustment

Press the power button to turn on the clippers. The clippers feature two adjustable speeds: 5000 RPM and 5700 RPM. Press the power button again to switch between speeds. Start with the lower speed for sensitive areas or nervous pets, and increase as needed.



Image: A hand pressing the power button on the clipper, with text indicating "Powerful Motor 2 Speeds Adjustable" and showing 5000 rpm and 5700 rpm settings.

3. Trimming Specific Areas

Hold the clipper at a slight angle against the fur and gently glide it through the hair. Always trim in the direction of hair growth for a smoother finish and to prevent irritation. The small blade is ideal for intricate areas.

- **Paws:** Carefully trim hair between paw pads to prevent matting and improve traction.
- **Ears:** Trim hair around the ear canal and outer ear for hygiene and comfort.
- **Eyes/Face:** Use extreme caution when trimming around the eyes and face to avoid injury.
- **Rump:** Trim hair around the sanitary area for cleanliness.



Image: A collage showing "Before" and "After" grooming results for paw, ear, face, and hip areas on various pets, demonstrating the clipper's effectiveness for small area trimming.



Image: A four-step visual guide on "How to Groom Your Pets Paws," showing oiling the blade, letting the pet get used to noise/vibration, trimming with the paw trimmer, and rewarding the pet with treats.

4. Cordless and Corded Use

The clippers can be used wirelessly after charging, or while plugged in and charging, offering flexibility during grooming sessions.



Image: Two images demonstrating the clipper's use: one showing wireless operation on a dog's paw, and another showing the clipper being used while plugged in for charging.

Maintenance

1. Cleaning the Blades

After each use, turn off the clippers and remove the blade. Use the provided cleaning brush to remove any trapped hair from the blade and the clipper head. The ceramic blade is washable; you can rinse it under running water. Ensure the blade is completely dry before reattaching or storing.

2. Oiling the Blades

Regularly apply a few drops of clipper oil (included) to the blades to maintain their sharpness and ensure smooth operation. Do this before or after each grooming session, especially if the clippers feel sluggish.

3. Storage

Store the clippers and all accessories in a cool, dry place, away from direct sunlight and moisture. Keep them out of reach of children and pets.

Troubleshooting

Problem	Possible Cause	Solution
Clipper not turning on.	Low battery; power button not pressed correctly.	Charge the clipper fully. Ensure the power button is pressed firmly.
Blades pulling hair or not cutting effectively.	Blades are dull, dirty, or not oiled; hair is tangled.	Clean and oil the blades. Ensure pet's hair is clean and tangle-free before grooming. Consider replacing blades if excessively dull.
Clipper making unusual noise.	Blades are not properly attached; internal issue.	Re-attach the blade securely. If the issue persists, contact customer support.
Short battery life.	Battery not fully charged; aging battery.	Ensure the clipper is charged for the full 2 hours. Battery performance may decrease over time.

Specifications

- **Model:** C61
- **Brand:** oneisall
- **Power Source:** Battery Powered (USB Rechargeable)
- **Battery Life:** Approx. 2 hours working time after 2 hours charging
- **Motor Speeds:** 5000 RPM, 5700 RPM
- **Noise Level:** ≤60dB
- **Blade Material:** Ceramic (movable blade) and Stainless Steel (fixed blade)
- **Item Weight:** 15.5 ounces (for the pack of 2)
- **Dimensions:** 7.87 x 4.92 x 1.73 inches (Package Dimensions)
- **Color:** White
- **Specific Uses:** Trimming hair around paws, eyes, ears, face, rump.

Warranty and Support

oneisall products are designed for quality and durability. Your oneisall Dog Clippers come with a **2-Year Warranty** from the date of purchase, covering manufacturing defects.

For any questions, concerns, or warranty claims, please contact our customer service team. We offer **24-hour Customer Service** to assist you.

Please visit the official oneisall website or refer to your purchase documentation for specific contact details.

© 2024 oneisall. All rights reserved.