kangten AH-D11

kangten 1200W Air Fryer (Model: AH-D11) Instruction Manual

Your guide to safe and efficient operation of your new air fryer.

Introduction

Thank you for purchasing the kangten 1200W Air Fryer. This appliance utilizes infrared convection and 360° vertical heating to prepare a variety of meals efficiently. This manual provides essential information for safe operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your air fryer.

Important Safety Instructions

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the voltage matches your power supply. Do not immerse the main unit (top part with controls) in water or any other liquid.
- **Hot Surfaces:** The air fryer generates heat and steam during operation. Do not touch hot surfaces directly. Always use oven mitts or handles.
- **Placement:** Place the appliance on a stable, heat-resistant surface, away from walls and other appliances to allow for proper ventilation.
- **Children and Pets:** Keep the appliance out of reach of children and pets. Close supervision is necessary when the appliance is used near children.
- **Power Cord:** Do not let the power cord hang over the edge of a table or counter, or touch hot surfaces.
- **Automatic Shut-off:** The air fryer automatically cuts off power if the handle is lifted during operation. Lower the handle to resume cooking.
- **Protection Features:** The product includes overheat, overcurrent, and short-circuit protection functions for enhanced safety.
- **Maintenance:** Refer to the "Maintenance and Cleaning" section for proper care. Do not attempt to repair the appliance yourself. Contact qualified service personnel.

Product Components

Familiarize yourself with the parts of your kangten Air Fryer.



Figure 1: All components of the kangten Air Fryer, including the main heating unit, glass bowl, high rack, low rack, and power cord.



Figure 2: Assembled kangten Air Fryer with main heating unit, glass bowl, and handles. Dimensions are approximately 37cm (14.6 inches) wide and 42cm (16.5 inches) high.



Figure 3: Close-up of the control panel, featuring a timer knob

(0-60 minutes) and a temperature knob (125°C-250°C).

1. **Main Heating Unit:** Contains the heating element, fan, and control panel.
2. **Glass Bowl:** Large capacity, transparent cooking vessel.
3. **High Rack:** For cooking items closer to the heating element.
4. **Low Rack:** For cooking items further from the heating element.
5. **Power Cord:** Detachable power supply.

Setup and First Use

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Cleaning:** Before first use, wash the glass bowl and racks with warm, soapy water. Rinse thoroughly and dry completely. Wipe the main heating unit with a damp cloth. Do not immerse the main heating unit in water.
3. **Assembly:** Place the glass bowl on a stable, heat-resistant surface. Insert the desired cooking rack (high or low) into the glass bowl. Place the main heating unit securely on top of the glass bowl.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the appliance's requirements (110V / 60HZ).
5. **Initial Burn-in (Optional but Recommended):** To eliminate any manufacturing odors, operate the air fryer empty for about 10-15 minutes at 180°C (350°F). Ensure good ventilation during this process.

Operating Instructions

The kangten Air Fryer features simple knob controls for temperature and time settings.



Figure 4: Visual representation of the simple time and temperature controls.

1. **Prepare Food:** Place your food directly on the rack or in an oven-safe dish within the glass bowl. Do not overfill the bowl to allow for proper air circulation.
2. **Set Temperature:** Turn the **Temperature Control** knob to your desired cooking temperature. The range is 60-250°C (140-482°F).
3. **Set Time:** Turn the **Timer Control** knob to your desired cooking time, up to 60 minutes. The air fryer will begin heating immediately. The "POWER" indicator light will illuminate.
4. **Cooking Process:** The "HEAT" indicator light will illuminate when the heating element is active. It will cycle on and off to maintain the set temperature.
5. **Automatic Pause/Resume:** If you lift the handle of the main heating unit during operation, the appliance will automatically pause. Lower the handle to resume cooking.
6. **Completion:** Once the set time has elapsed, the air fryer will automatically turn off, and a bell will sound. Carefully remove the main heating unit and then the cooked food using oven mitts.
7. **Cool Down:** Allow the appliance to cool completely before cleaning or storing.

Cooking Tips:

- For best results, preheat the air fryer for 3-5 minutes before adding food.
- Shake or flip food halfway through cooking for even browning.
- Lightly oiling food can enhance crispiness.
- Refer to air fryer recipes or conventional oven recipes, adjusting cooking times and temperatures as needed.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your air fryer.

1. **Unplug:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Glass Bowl and Racks:** The borosilicate glass pot and metal racks are dishwasher safe. Alternatively, wash them with warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry.
3. **Main Heating Unit:** Wipe the exterior of the main heating unit with a soft, damp cloth. For stubborn stains, use a mild detergent. Do not use abrasive cleaners or scouring pads. Never immerse the main heating unit in water or any other liquid.
4. **Interior of Heating Unit:** Gently wipe the interior, including the heating element and fan area, with a damp cloth to remove any food residue. Ensure no moisture enters the electrical components.
5. **Storage:** Once clean and dry, store the air fryer in a cool, dry place.

Troubleshooting

If you encounter any issues, please refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet malfunction; timer not set; handle not fully lowered.	Ensure the power cord is securely plugged into a working outlet. Turn the timer knob to the desired cooking time. Ensure the handle of the main heating unit is fully lowered and locked into place.
Food is not cooked evenly.	Overfilling the bowl; food not shaken/flipped; incorrect temperature/time.	Do not overfill the glass bowl. Shake or flip food halfway through cooking. Adjust temperature and time according to recipe recommendations.
White smoke coming from the appliance.	Excess oil/grease from food; food residue on heating element.	This is usually normal for fatty foods. Clean the appliance thoroughly after each use to prevent residue buildup. If smoke is excessive or black, unplug immediately and contact support.
Appliance suddenly stops during operation.	Handle lifted; safety feature activated (overheat, overcurrent).	Ensure the handle is fully lowered. If the appliance stopped due to a safety feature, unplug it, let it cool down for 30 minutes, then plug it back in and try again. If the problem persists, contact customer support.

Specifications

Model	AH-D11
Power	1200W
Voltage	110V / 60HZ

Capacity	17L (4.49 Gallons)
Temperature Range	60-250°C (140-482°F)
Timing Range	0-60 minutes
Heating Method	360° Vertical Heating, Infrared Convection
Main Materials	Borosilicate Glass, PC, Food-grade Metal
Product Dimensions (L x H)	37 x 42 cm (14.6 x 16.5 inches)
Is Dishwasher Safe	Glass bowl and racks only

Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your purchase receipt as proof of purchase.

© 2024 kangten. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question