DOOGEE

DOOGEE U11 Android 15 Tablet User Manual

Model: DOOGEE U11

1. Introduction

Welcome to the user manual for your new DOOGEE U11 Android 15 Tablet. This guide provides essential information on setting up, operating, maintaining, and troubleshooting your device. Please read this manual thoroughly to ensure optimal performance and longevity of your tablet.

2. Package Contents

Upon opening the package, please verify that all items are present and in good condition.

- DOOGEE U11 Android 15 Tablet
- USB-C Charging Cable
- Power Adapter
- SIM Eject Tool (if applicable for cellular models)
- Quick Start Guide
- Warranty Card

If any items are missing or damaged, please contact DOOGEE customer support immediately.

3. Device Overview

Familiarize yourself with the physical components of your DOOGEE U11 Tablet.



Figure 3.1: Front and rear view of the DOOGEE U11 Tablet, showcasing its sleek design and camera module.

Key Components:

- **11-inch IPS Ultra-clear Display:** The primary interface for interaction, offering a resolution of 1280x800 pixels and a 90Hz refresh rate for smooth visuals.
- **Front Camera (5MP):** Located on the bezel, used for video calls and selfies.
- **Rear Camera (13MP):** Located on the back, used for capturing photos and videos.
- **Power Button:** Used to turn the tablet on/off or wake/sleep the screen.
- **Volume Buttons:** Used to adjust the audio volume.
- **USB-C Port:** For charging and data transfer.
- **Speaker Grilles:** For audio output, featuring stereo-enhanced dual speakers.
- **MicroSD Card Slot:** For expanding storage capacity up to 2TB.

4. Initial Setup

4.1 Charging the Tablet

Before first use, it is recommended to fully charge your DOOGEE U11 Tablet.

1. Connect the USB-C cable to the tablet's USB-C port.
2. Connect the other end of the USB-C cable to the provided power adapter.
3. Plug the power adapter into a wall outlet.
4. The battery icon on the screen will indicate charging status. A full charge may take several hours.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the DOOGEE logo appears on the screen.
- **To Power Off:** Press and hold the Power button until the power options menu appears. Select "Power off" and confirm.
- **To Restart:** From the power options menu, select "Restart" and confirm.

4.3 Initial Configuration

Upon first power-on, the tablet will guide you through the initial setup wizard. Follow the on-screen prompts to:

- Select your language.
- Connect to a Wi-Fi network.
- Sign in with your Google Account or create a new one.
- Set up screen lock (PIN, pattern, password).
- Review and accept terms and conditions.

5. Operating Instructions

5.1 Navigating Android 15



Figure 5.1: The Android 15 system interface, offering a smarter, smoother, and safer user experience.

The DOOGEE U11 runs on Android 15, providing an intuitive and customizable user experience.

- **Home Screen:** Your central hub for apps, widgets, and shortcuts.
- **App Drawer:** Swipe up from the home screen to access all installed applications.
- **Notification Panel:** Swipe down from the top of the screen to view notifications and quick settings.
- **Multitasking:** Tap the square navigation button (or swipe up and hold from the bottom if using gestures) to view recently opened apps.

5.2 Display Features



Figure 5.2: The 11-inch IPS display, highlighting its 90Hz refresh rate, 1280x800 resolution, and 16.7 million screen colors.

The 11-inch IPS display offers vibrant colors and smooth interactions.

- **Brightness Adjustment:** Adjust screen brightness from the quick settings panel or Display settings.
- **Dark Theme:** Enable Dark Theme for a more comfortable viewing experience in low light.
- **Eye Comfort Shield:** Reduce blue light emission to minimize eye strain.

5.3 Storage Management



Figure 5.3: Visual representation of the tablet's 128GB internal storage, expandable up to 2TB with a microSD card.

Your tablet comes with 128GB of internal storage and supports expansion up to 2TB via a microSD card.

- **Checking Storage:** Go to Settings > Storage to view storage usage.
- **Inserting MicroSD Card:** Locate the card slot, insert the SIM eject tool into the small hole to open the tray, and place the microSD card correctly.

5.4 Performance and Processor




Figure 5.4: Close-up of the Unisoc T606 Octa-core processor, indicating its 1.6GHz clock speed and Mali-G57 GPU.

The DOOGEE U11 is powered by a Unisoc T606 Octa-core processor, ensuring smooth performance for daily tasks and multimedia.

- **App Management:** Close background apps to free up RAM and improve performance.
- **Software Updates:** Keep your system updated to benefit from performance enhancements and security patches.

5.5 Audio and Camera




Figure 5.5: The tablet's stereo-enhanced dual speakers providing immersive audio for gaming and media consumption.

Experience rich audio with the stereo-enhanced dual speakers and capture moments with the integrated cameras.



Figure 5.6: Illustration of the 13MP main camera and 5MP front camera capabilities for capturing clear images.

- **Volume Control:** Use the physical volume buttons or the on-screen slider.
- **Camera App:** Open the Camera app to switch between front and rear cameras, select modes (photo, video), and adjust settings.

6. Maintenance

6.1 Cleaning Your Tablet

To maintain the tablet's appearance and functionality:

- Use a soft, lint-free cloth to wipe the screen and body.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner.
- Avoid using harsh chemicals, abrasive materials, or aerosol sprays.

6.2 Battery Care

The DOOGEE U11 features an 8580mAh battery. To prolong battery life:

- Avoid extreme temperatures.
- Do not let the battery drain completely before recharging regularly.
- Unplug the charger once the battery is full.
- Manage background app usage and screen brightness to conserve power.



Figure 6.1: The 8580mAh battery, illustrating its long standby time (1509 hours), music playing (28.3 hours), video watching (9.2 hours), and web browsing (6.7 hours) capabilities.

6.3 Software Updates

Regularly check for and install software updates to ensure your tablet has the latest features, security patches, and performance improvements. Go to Settings > System > System update.

7. Troubleshooting

This section addresses common issues you might encounter with your DOOGEE U11 Tablet.

Problem	Possible Solution
Tablet won't turn on.	Ensure the tablet is charged. Connect to the charger for at least 30 minutes, then try powering on again. If unresponsive, perform a forced restart by holding the Power button for 10-15 seconds.
Wi-Fi connection issues.	Restart your Wi-Fi router. Forget the network on your tablet and reconnect. Ensure you are within range of the Wi-Fi signal.
Apps are crashing or running slowly.	Close unnecessary background apps. Clear app cache (Settings > Apps > [App Name] > Storage > Clear cache). Ensure sufficient free storage space. Restart the tablet.
Screen is unresponsive.	Perform a forced restart. If the issue persists, consider a factory reset (backup data first).
Battery drains quickly.	Reduce screen brightness. Disable unused features like Bluetooth or GPS. Limit background app refresh. Check battery usage in Settings to identify power-hungry apps.

For issues not covered here, please refer to the DOOGEE support website or contact customer service.

8. Specifications

Detailed technical specifications for the DOOGEE U11 Android 15 Tablet:

Feature	Specification
Model Name	DOOGEE U11
Operating System	Android 15
Display Size	11 Inches
Display Type	IPS Ultra-clear Display
Display Resolution	1280 x 800 pixels
Refresh Rate	90Hz
Processor	Unisoc T606 Octa-core (1.6GHz)
RAM	16GB (4GB physical + 12GB virtual RAM expansion)
Internal Storage	128GB
Expandable Storage	Up to 2TB via MicroSD card
Rear Camera	13 MP
Front Camera	5 MP
Battery Capacity	8580mAh
Dimensions (LxWxH)	10.12 x 6.68 x 0.31 inches
Weight	1.98 pounds

Feature	Specification
Connectivity	Wi-Fi (5G WiFi support), Bluetooth

9. Warranty and Support

Your DOOGEE U11 Tablet comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including warranty period and coverage details.
For technical support, troubleshooting assistance, or warranty claims, please contact DOOGEE customer service through their official website or the contact information provided in your warranty documentation.
DOOGEE Official Website: www.doogee.cc (Please check your specific region's website for localized support.)

© 2025 DOOGEE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question