Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NutriChef NCHS60ZB

NutriChef Electric Pressure Cooker 6 Quart User Manual

Model: NCHS60ZB

INTRODUCTION

Thank you for choosing the NutriChef Electric Pressure Cooker. This appliance is designed to simplify your cooking process with its versatile functionality and efficient performance. Featuring a 6-quart capacity and 9 preset modes, it allows you to cook, bake, steam, roast, broil, and braise with precision. This manual provides essential information for safe operation, maintenance, and troubleshooting to ensure you get the most out of your new pressure cooker.



The NutriChef Electric Pressure Cooker in black, showcasing its sleek design and digital control panel.

Important Safety Instructions

Please read all instructions carefully before using your NutriChef Electric Pressure Cooker. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance cooks under pressure. Improper use may result in scalding injury. Make certain unit is properly closed before operating.
- Never force open the pressure cooker. Ensure internal pressure is completely released before opening.

Product Components

Your NutriChef Electric Pressure Cooker comes with the following components:



An illustration showing the NutriChef Electric Pressure Cooker and its included accessories: a measuring cup, a rice spoon, and a power cable.

- **Electric Pressure Cooker Unit:** The main appliance with control panel and lid.
- **Inner Cooking Pot:** Multi-layer non-stick pot for cooking.
- **Measuring Cup:** For precise ingredient measurement.
- **Rice Spoon:** Designed for serving rice and other cooked foods.
- **Power Cable:** To connect the appliance to an electrical outlet.

Initial Setup

Before first use, follow these steps to prepare your pressure cooker:

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Wash the inner cooking pot, measuring cup, and rice spoon with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the pressure cooker on a stable, level, heat-resistant surface, away from walls and cabinets to allow for proper ventilation. Ensure the power cord is not obstructed.
4. **Insert Inner Pot:** Place the clean, dry inner cooking pot into the main unit. Ensure it sits correctly and is level.
5. **Lid Assembly:** Ensure the sealing gasket is properly seated inside the lid. Close the lid by aligning the arrow on the lid with the arrow on the base, then rotate clockwise until it locks into place.

Operating Instructions

The NutriChef Electric Pressure Cooker features a smart digital control panel for easy operation.



The digital LED display and touch control panel, allowing for precise adjustments to cooking settings.

Digital Control Panel

The intuitive LCD touch interface allows you to customize cooking settings with a simple touch. Key features include:

- **Preset Modes:** Access 9 versatile cooking functions for various dishes.
- **Adjustable Time & Temperature:** Fine-tune cooking parameters for optimal results.
- **Re-Heat / Keep Warm Function:** Automatically keeps food warm after cooking or reheats it.
- **Kitchen Timer Alarm Notification:** Provides alerts for cooking stages.
- **Auto Power-Off Function:** Enhances safety by automatically shutting down the unit.
- **Delay Start:** Program cooking to begin at a later time.

Cooking Modes

The pressure cooker offers 9 preset modes for a wide range of recipes:



An overview of the 12-in-1 multi-function capabilities, illustrating various dishes that can be prepared.

- Multi Grain
- Soup
- Porridge
- Steam
- Beans
- Risotto
- Beef/Poultry
- Meat/Stew
- Pork Ribs
- Bake
- Fish
- Dessert

Open Lid Cooking Innovation

The unique 'Open Lid' mode adds versatility, allowing for cooking methods that do not require pressure, such as sautéing or browning ingredients before pressure cooking, or simmering after pressure release.



The pressure cooker operating with its lid open, showcasing its versatility for various cooking techniques.

Efficient Steam Cooking

Utilize the steam function for quick and healthy cooking, retaining nutrients and flavors in your food.



The pressure cooker releasing steam, highlighting its efficient steam cooking capability.

Care and Maintenance

Proper care ensures the longevity and optimal performance of your NutriChef Electric Pressure Cooker.

Cleaning the Inner Pot

The multi-layer non-stick inner cooking pot is designed for easy cleaning. It is also dishwasher safe.



The multi-layered non-stick cooking pot, designed for easy cooking and cleanup.

- After each use, allow the pot to cool completely.
- Wash with warm, soapy water using a non-abrasive sponge or cloth.
- For stubborn food residues, soak the pot in warm water before cleaning.
- The inner pot is dishwasher safe for convenience.

Cleaning the Lid and Sealing Gasket

- Remove the sealing gasket from the lid. Wash both the lid and gasket with warm, soapy water.
- Ensure the gasket is thoroughly cleaned and free of food particles.
- Dry all parts completely before reassembling.
- Periodically check the sealing gasket for wear and tear. Replace if damaged to ensure proper pressure sealing.

Cleaning the Exterior

- Wipe the exterior of the main unit with a damp cloth.
- Do not use abrasive cleaners or scourers, as they may damage the finish.
- Never immerse the main unit in water or any other liquid.

Troubleshooting

If you encounter issues with your pressure cooker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Pressure not building	Lid not properly closed; Sealing gasket not seated correctly; Steam release valve open.	Ensure lid is fully locked. Check and reposition sealing gasket. Close the steam release valve.
Food undercooked	Insufficient cooking time; Not enough liquid; Incorrect pressure setting.	Increase cooking time. Ensure minimum liquid requirements are met. Verify correct preset or manual settings.
Error code on display	Specific internal issue.	Refer to the specific error code in a more detailed manual (if available) or contact customer support. Unplug and replug the unit.
Burning smell	Food stuck to bottom; Insufficient liquid.	Immediately turn off and unplug. Allow to cool, then check inner pot for burnt food and add more liquid if necessary.

If the problem persists after attempting these solutions, please contact NutriChef customer support for further assistance.

Product Specifications

Here are the technical specifications for your NutriChef Electric Pressure Cooker:

- **Brand:** NutriChef
- **Model Number:** NCHS60ZB
- **Capacity:** 6 Quarts
- **Material:** Stainless steel (housing), Iron metal alloy, Engineered ABS
- **Color:** Black
- **Product Dimensions:** 13.1"D x 11.4"W x 11.6"H
- **Wattage:** 1000 watts
- **Item Weight:** 12 Pounds
- **Control Method:** Touch
- **Operation Mode:** Manual, Programmable
- **Special Features:** Automatic Shut-Off, Dishwasher Safe (inner pot), Keep Warm Setting, Locking Lid, Programmable
- **UPC:** 842893164823

Warranty Information

For specific warranty details and terms, please refer to the warranty card included with your product or visit the official NutriChef website. The manufacturer, NutriChef, typically provides a limited warranty against defects in materials and workmanship under normal household use.

Customer Support

If you have any questions, require technical assistance, or need to report an issue with your NutriChef Electric Pressure Cooker, please contact NutriChef customer support. You can typically find contact information on the product packaging, the official NutriChef website, or by visiting the NutriChef Store on Amazon.

© 2025 NutriChef. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DJ9GFZ3M

More documents and user manuals: **https://manuals.plus/**