Lovehoney Deluxe Mini Massage Wand

Lovehoney Deluxe Rechargeable Mini Massage Wand (Glow in the Dark)

Model: Deluxe Mini Massage Wand | Brand: Lovehoney

1. Introduction

This manual provides essential information for the safe and effective use of your Lovehoney Deluxe Rechargeable Mini Massage Wand. Please read these instructions carefully before first use and retain for future reference.

2. Key Features

- **Mini Massage Wand Vibrator:** Designed for external stimulation, offering powerful vibrations in a compact form.
- **10 Intensity Levels & 7 Patterns:** Provides a wide range of customizable pleasure sensations.
- **Wide Domed Head:** Features a smooth, rounded head and a super flexible neck to effectively deliver vibrations.
- **USB Rechargeable:** Conveniently recharges via USB, suitable for use anywhere.
- **Glow in the Dark Design:** Unique aesthetic feature for enhanced visual appeal.



Image: The Lovehoney Deluxe Mini Massage Wand, highlighting its multispeed functionality and glow-in-the-dark design.

3. Setup and Charging

Before first use, fully charge the device. The device is powered by 1 Lithium Ion battery (included).

1. Locate the charging port at the base of the wand.
2. Connect the provided USB charging cable to the charging port.
3. Plug the USB end of the cable into a compatible USB power adapter (not included) or a computer USB port.
4. Charge for approximately 90 minutes for a full charge. The indicator light will show charging status.



Image: The USB charging cable connected to the wand's charging port.

Your browser does not support the video tag.

Video: Demonstration of charging and basic operation of a Lovehoney Mini Massager.

4. Operating Instructions

The Lovehoney Deluxe Mini Massage Wand features simple push-button controls.

1. **Power On/Off:** Press and hold the power button (usually indicated by a circle with a vertical line) for a few seconds to turn the device on or off.
2. **Change Intensity:** Use the '+' and '-' buttons to increase or decrease the vibration intensity. There are 10 intensity levels.
3. **Change Pattern:** Use the wave-pattern button (often indicated by a wavy line) to cycle through the 7 different vibration patterns.



Image: Simple-to-use push button controls for power, intensity, and patterns.

Your browser does not support the video tag.

Video: Demonstration of charging and basic operation of a Lovehoney Mini Massager with a leopard print design.

5. Maintenance and Care

- **Cleaning:** The device is waterproof. Clean thoroughly after each use with warm water and a mild soap or a specialized toy cleaner. Rinse well and pat dry with a lint-free cloth.
- **Lubrication:** Always use with a water-based lubricant to enhance comfort and prolong the life of the product. Do not use silicone-based lubricants as they can damage the silicone material.
- **Storage:** Store in a cool, dry place away from direct sunlight and extreme temperatures. Keep away from other toys made of different materials to prevent damage or discoloration.

6. Safety Information

- **External Use Only:** This product is designed for external use only. Not for anal use.

- **Discontinue Use:** If you experience any discomfort, irritation, or pain, discontinue use immediately.
- **Keep Out of Reach of Children:** This product is not a toy and should be kept out of reach of children.
- **Medical Conditions:** Consult a healthcare professional before use if you have any medical conditions or concerns.

7. Troubleshooting

Problem	Solution
Device does not turn on.	Ensure the device is fully charged. Press and hold the power button for a few seconds.
Device is not charging.	Check if the USB cable is securely connected to both the device and the power source. Try a different USB port or power adapter.
Vibrations are weak.	Ensure the device is fully charged. Increase the intensity using the '+' button.

8. Specifications

- **Manufacturer:** Lovehoney
- **Model Name:** Deluxe Mini Massage Wand
- **Product Dimensions:** 22 x 7 x 5 cm; 159 g
- **Battery:** 1 Lithium Ion battery (included)
- **Charging:** USB Rechargeable
- **Color:** Glow in the Dark
- **Country of Origin:** China

9. Warranty and Support

For warranty information or product support, please refer to the packaging or contact Lovehoney customer service directly. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question