Music Sound BTSPKMSVERTICAL242

Music Sound VERTICAL Bluetooth Speaker Instruction Manual

Model: BTSPKMSVERTICAL242

Introduction

Thank you for choosing the Music Sound VERTICAL Bluetooth Speaker. This manual provides essential information for the safe and efficient use of your new speaker. Please read these instructions carefully before using the product and retain them for future reference.

Safety Information

- Do not expose the speaker to water, moisture, or extreme temperatures. This product is not waterproof.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not attempt to disassemble, repair, or modify the speaker yourself. Contact qualified service personnel for assistance.
- Keep the speaker away from heat sources, direct sunlight, and flammable materials.
- Dispose of batteries according to local regulations. Do not expose batteries to excessive heat.
- Use only the provided charging cable or a certified equivalent.

Package Contents

Please check the package for the following items:

- Music Sound VERTICAL Bluetooth Speaker
- USB-C Charging Cable
- Instruction Manual

Product Overview

Familiarize yourself with the speaker's controls and ports:




MIC
LED
M



Image: Front view of the speaker displaying the control panel with buttons for volume, mode selection, and play/pause, along with a microphone and LED indicator.



Image: Side view of the speaker with the protective flap open, revealing the USB, Micro SD card, USB-C charging, and AUX input ports.

Controls and Indicators:

- **Volume Up** / **Next Track Button:** Press briefly to increase volume. Press and hold to skip to the next track.
- **Mode (M) Button:** Press to switch between Bluetooth, AUX, USB, and Micro SD modes.
- **Play/Pause** / **Call Button:** Press briefly to play or pause music. Press briefly to answer or end a call. Press and hold to reject an incoming call.
- **Volume Down** / **Previous Track Button:** Press briefly to decrease volume. Press and hold to go to the previous track.
- **Power Button:** Press and hold to power on or off the speaker.
- **MIC:** Built-in microphone for hands-free calls.

- **LED Indicator:** Shows power status, charging status, and Bluetooth pairing status.

Ports:

- **USB-C Port:** For charging the speaker.
- **USB Port:** For playing music from a USB flash drive.
- **Micro SD Card Slot:** For playing music from a Micro SD card.
- **AUX Input:** For connecting external audio devices via a 3.5mm audio cable.

Setup

1. Charging the Speaker

1. Connect the supplied USB-C charging cable to the speaker's USB-C port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show the charging status. It typically turns off or changes color when fully charged.
4. A full charge provides up to 4 hours of playtime.

2. Powering On/Off

- **To Power On:** Press and hold the Power button until the LED indicator lights up and you hear an audible prompt.
- **To Power Off:** Press and hold the Power button until the LED indicator turns off and you hear an audible prompt.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode (the LED indicator will flash, indicating it's ready for pairing). If not, press the 'M' (Mode) button to switch to Bluetooth mode.
2. Enable Bluetooth on your smartphone, tablet, or other audio device.
3. Search for available Bluetooth devices. You should see "VERTICAL" in the list.
4. Select "VERTICAL" to connect. The LED indicator will stop flashing and remain solid, and you will hear a confirmation sound once paired successfully.
5. The speaker will automatically attempt to reconnect to the last paired device when powered on.

4. Other Connectivity Options

- **AUX Input:** Connect a 3.5mm audio cable from your external device to the speaker's AUX port. Press the 'M' button to switch to AUX mode.
- **USB Playback:** Insert a USB flash drive containing MP3 audio files into the USB port. Press the 'M' button to switch to USB mode.
- **Micro SD Card Playback:** Insert a Micro SD card containing MP3 audio files into the Micro SD card slot. Press the 'M' button to switch to Micro SD mode.

Operating Instructions

Music Playback

- **Play/Pause:** Press the Play/Pause button briefly.
- **Next Track:** Press and hold the Volume Up button.
- **Previous Track:** Press and hold the Volume Down button.
- **Volume Up:** Press the Volume Up button briefly.
- **Volume Down:** Press the Volume Down button briefly.

Hands-Free Calling

- **Answer Call:** When an incoming call rings, press the Play/Pause button briefly to answer.
- **End Call:** During a call, press the Play/Pause button briefly to end the call.
- **Reject Call:** When an incoming call rings, press and hold the Play/Pause button to reject the call.

Maintenance

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the speaker in a cool, dry place when not in use.
- If the speaker will not be used for an extended period, charge it periodically to maintain battery health.

Troubleshooting

Problem	Solution
Speaker does not power on.	Ensure the speaker is charged. Connect it to a power source using the USB-C cable.
Cannot pair via Bluetooth.	◦ Ensure the speaker is in Bluetooth pairing mode (flashing LED). ◦ Make sure Bluetooth is enabled on your device. ◦ Move the speaker closer to your device. ◦ Forget "VERTICAL" from your device's Bluetooth list and try pairing again.
No sound.	◦ Check the volume level on both the speaker and your connected device. ◦ Ensure the correct input mode (Bluetooth, AUX, USB, Micro SD) is selected. ◦ If using AUX, ensure the cable is fully inserted and functional.
Poor audio quality.	◦ Move the speaker closer to your Bluetooth device to avoid interference. ◦ Ensure there are no obstructions between the speaker and the device. ◦ Try playing a different audio file or source.

Specifications

Feature	Detail
Brand	Music Sound
Model Name	VERTICAL
Model Number	BTSPKMSVERTICAL242
Output Power	5 Watts
Bluetooth Version	5.0
Playtime	Up to 4 hours
Connectivity	Bluetooth, USB, Micro SD, AUX (3.5mm), USB-C (charging)
Power Source	Battery Powered (1 Lithium-ion battery included)
Dimensions (L x W x H)	7 x 7 x 16 cm

Feature	Detail
Weight	380 grams
Microphone	Integrated for hands-free calls

Warranty and Support

The Music Sound VERTICAL Bluetooth Speaker comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included with your purchase or visit the official Music Sound website.

For technical support, troubleshooting assistance, or service inquiries, please contact Music Sound customer support through their official channels. Contact information can typically be found on the product packaging or their website.