Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bewinner Bewinnerf4wicg2ap6-12

Bewinner Over-Ear Stereo Headphones User Manual

Model: Bewinnerf4wicg2ap6-12

Brand: Bewinner

1. Introduction

This user manual provides comprehensive instructions for the Bewinner Over-Ear Stereo Headphones, Model Bewinnerf4wicg2ap6-12. Please read this manual carefully before using the product to ensure proper operation and to maximize your listening experience. Keep this manual for future reference.

2. Product Overview

2.1 Package Contents

Upon unpacking, please ensure all items listed below are present:

- Bewinner Over-Ear Stereo Headphones
- USB Charging Cable
- 3.5mm Audio Cable
- User Manual (this document)

2.2 Key Features

- **Advanced Bluetooth 5.3 Connectivity:** Offers stable and low-latency wireless connection up to 10 meters.
- **Impressive Sound Quality:** Equipped with 40mm speakers and a frequency range of 20Hz-20KHz for rich audio.
- **Dual Mode Use:** Supports both wireless (Bluetooth) and wired (3.5mm audio cable) connections.
- **Long Battery Life:** Built-in 200mAh lithium-ion battery for extended playback.
- **Memory Card Support:** Integrated slot for up to 32GB memory card (not included) for direct music playback.
- **Comfortable Design:** Lightweight ABS material for comfortable wear during extended use.

2.3 Headphone Diagram

Familiarize yourself with the various parts and controls of your headphones.



Figure 1: Bewinner Over-Ear Stereo Headphones (Khaki)

This image displays the overall design of the Bewinner Over-Ear Stereo Headphones in Khaki, highlighting the earcups and adjustable headband.



Figure 2: Control Panel and Ports

A detailed view of the headphone earcup, illustrating the location of the 3.5mm audio input, the charging port, and the memory card slot for direct media playback.

3. Setup

3.1 Charging the Headphones

1. Connect the provided USB charging cable to the charging port on the headphones.
2. Connect the other end of the USB cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
3. The indicator light will illuminate during charging and turn off or change color when fully charged.
4. A full charge typically takes approximately 2-3 hours.

3.2 Powering On/Off

- **To Power On:** Press and hold the Power button (usually indicated by a power icon) for approximately 3-5 seconds until an indicator light flashes or an audible prompt is heard.
- **To Power Off:** Press and hold the Power button again for approximately 3-5 seconds until the indicator light turns off or an audible prompt is heard.

3.3 Pairing via Bluetooth 5.3 (Wireless Mode)

1. Ensure the headphones are powered off.
2. Press and hold the Power button until the indicator light flashes rapidly (often blue and red alternately), indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Bewinnerf4wicg2ap6-12" (or similar name) from the list of found devices.
5. Once paired, the indicator light will typically flash slowly or turn solid blue, and an audible confirmation may be heard.

3.4 Using 3.5mm Audio Cable (Wired Mode)

- Insert one end of the 3.5mm audio cable into the audio input jack on the headphones.
- Insert the other end into the 3.5mm audio output jack of your audio source device.
- The headphones will automatically switch to wired mode. No power is required for basic audio playback in wired mode, though some functions may be limited.

3.5 Inserting a Memory Card

- Locate the memory card slot on the headphone earcup.
- Gently insert a compatible memory card (up to 32GB, not included) into the slot until it clicks into place. Ensure the card is oriented correctly.
- The headphones will automatically detect the memory card and may begin playing audio files stored on it.

4. Operating Instructions

The headphones feature intuitive controls for managing audio playback and calls.

4.1 Basic Controls (Wireless Mode)

- **Play/Pause:** Press the Multi-function button (often the Power button or a dedicated play/pause button) once.
- **Volume Up:** Press the Volume + button.
- **Volume Down:** Press the Volume - button.
- **Next Track:** Press and hold the Volume + button (or a dedicated next track button).
- **Previous Track:** Press and hold the Volume - button (or a dedicated previous track button).

4.2 Call Management (Wireless Mode)

- **Answer Call:** Press the Multi-function button once when an incoming call is received.
- **End Call:** Press the Multi-function button once during a call.
- **Reject Call:** Press and hold the Multi-function button for approximately 2 seconds when an incoming call is received.

4.3 Memory Card Playback

- Once a memory card is inserted, the headphones will automatically switch to memory card playback mode.
- Use the Play/Pause, Volume +, and Volume - buttons to control playback as described in section 4.1.

5. Maintenance

Proper care and maintenance will extend the lifespan of your headphones.

- **Cleaning:** Use a soft, dry cloth to wipe the surfaces of the headphones. Do not use abrasive cleaners, solvents, or harsh chemicals.
- **Storage:** When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. The foldable design allows for compact storage.
- **Battery Care:** To preserve battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not used for extended periods.
- **Water Exposure:** These headphones are not waterproof. Avoid exposure to water, moisture, or rain.



Figure 3: Foldable Design for Storage

This image demonstrates the headphones in their folded configuration, highlighting their portability and ease of storage.

6. Troubleshooting

If you encounter issues with your headphones, refer to the following common problems and solutions:

Problem	Possible Solution
Headphones do not power on.	Ensure the headphones are fully charged. Connect to a power source and try again.
Cannot pair with device.	◦ Ensure headphones are in pairing mode (flashing indicator light). ◦ Make sure Bluetooth is enabled on your device. ◦ Move headphones closer to your device. ◦ Forget previous pairings on your device and try pairing again.
No sound in wireless mode.	◦ Check volume levels on both headphones and your device. ◦ Ensure headphones are successfully paired. ◦ Try restarting both the headphones and your device.
No sound in wired mode.	◦ Ensure the 3.5mm audio cable is fully inserted into both the headphones and the audio source. ◦ Test with a different 3.5mm cable if available. ◦ Check the audio source device's volume.
Memory card not detected or playing.	◦ Ensure the memory card is inserted correctly and fully. ◦ Verify the memory card is formatted correctly and contains compatible audio files. ◦ Try a different memory card if possible.

7. Specifications

Detailed technical specifications for the Bewinner Over-Ear Stereo Headphones.

Feature	Specification
Model Number	Bewinnerf4wicg2ap6-12
Connectivity	Bluetooth 5.3
Wireless Distance	Up to 10m / 32.8ft
Supported Protocols	A2DP, AVRCP, HSP, HFP
Speaker Diameter	40mm
Sensitivity	121±3dB
Impedance	32Ω±15%
Frequency Response	20Hz-20KHz
3.5mm Audio Input	Supported

Feature	Specification
Memory Card Support	Up to 32GB (Card not included)
Battery Type	Built-in 200mAh Lithium-Ion Battery
Material	ABS (Acrylonitrile Butadiene Styrene)
Item Weight	9.4 ounces
Color	Khaki

8. Warranty and Customer Support

Bewinner products are designed for reliability and performance. For warranty information or technical assistance, please refer to the retailer's return policy or contact Bewinner customer support through the official channels where the product was purchased.

Please retain your proof of purchase for any warranty claims.

© 2026 Bewinner. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DJL79KR3

More documents and user manuals: **https://manuals.plus/**