topzee K-AFT11001-UL

TOPZEE 11-QT Large Air Fryer Instruction Manual

Model: K-AFT11001-UL

Brand: topzee

Product Overview

The TOPZEE 11-QT Large Air Fryer is a versatile 8-in-1 appliance designed for efficient and healthy cooking. It features a unique flexible basket design, allowing seamless switching between a large 11-quart capacity for family meals and two 5.5-quart baskets for simultaneous cooking of different dishes. This air fryer supports various cooking modes including Preheat, Air Fry, Roast, Broil, Bake, Reheat, Dehydrate, and French Fries, offering precise temperature control from 90°F to 400°F. Its non-stick, dishwasher-safe components ensure easy cleanup.



Image: The TOPZEE 11-QT Large Air Fryer, showcasing its sleek black design with silver accents and a digital control panel. The main basket is shown with a divider, allowing for two separate cooking compartments.

Safety Instructions

- Always place the air fryer on a stable, heat-resistant surface away from walls and other appliances.
- Ensure proper ventilation around the appliance during operation.
- Do not immerse the main unit, cord, or plug in water or other liquids.
- Keep hands and face clear of the hot air vents.
- Always use oven mitts when handling hot baskets or accessories.
- Unplug the air fryer when not in use and before cleaning.
- Do not block any air vents.
- Supervise children when the appliance is in use.

What's in the Box

- TOPZEE 11-QT Large Air Fryer Main Unit
- 11-QT Basket (main cooking drawer)
- Removable Divider (for dual cooking)
- Crisper Plate (for optimal air circulation)
- User Manual
- Recipe Booklet (17 easy-to-follow recipes)

Setup & First Use

1. Unpack all components and remove any packaging materials.
2. Wash the basket, divider, and crisper plate with warm, soapy water. Rinse thoroughly and dry completely.
3. Wipe the exterior of the main unit with a damp cloth.
4. Place the air fryer on a stable, level, heat-resistant surface.
5. Insert the crisper plate into the basket. If using the divider, insert it into the designated slot.
6. Plug the air fryer into a grounded electrical outlet.
7. For first use, it is recommended to run an empty cycle (e.g., Air Fry at 350°F for 10 minutes) to eliminate any manufacturing odors.

Operating Instructions

Basic Operation

1. Press the power button to turn on the air fryer.
2. Select your desired cooking function (e.g., Air Fry, Roast, Bake) from the touch panel.
3. Adjust the temperature using the TEMP up/down arrows.
4. Adjust the cooking time using the TIME up/down arrows.
5. Press the Start/Pause button to begin cooking.

Flexible Basket Design

The air fryer offers unparalleled flexibility. Use the full 11-QT basket for large batches, or insert the removable divider to create two independent 5.5-QT cooking zones.



Image: The air fryer's basket with the removable divider inserted, showcasing the two distinct cooking compartments. This allows for cooking different foods simultaneously.



Image: The air fryer's basket without the divider, demonstrating the full 11-quart capacity suitable for larger items like a whole chicken or family-sized portions.

Dual Cooking Modes

When using the divider, you can set independent temperatures and times for each 5.5-QT basket. The "Finish Together" function intelligently staggers the start times so both items complete cooking simultaneously.



Image: The air fryer on a kitchen counter, showing the dual baskets with different foods cooking. The digital display indicates separate temperature and time settings for each side, highlighting the "Finish Together" feature.

The "Sync Cook" mode allows you to apply identical settings to both baskets with a single touch, ideal for cooking larger quantities of the same food.



Image: The air fryer with both baskets containing the same type of food, illustrating the "Sync Cook" function where both compartments operate under identical settings for consistent results.

8-in-1 Functions

This appliance offers a wide range of cooking capabilities:

- **Preheat:** Warms the air fryer to the desired temperature before adding food.
- **Air Fry:** Circulates hot air for crispy results with less oil.
- **Roast:** Ideal for meats and vegetables.
- **Broil:** Uses direct heat for browning and crisping.
- **Bake:** Perfect for pastries, cakes, and other baked goods.
- **Reheat:** Quickly warms up leftovers.
- **Dehydrate:** Removes moisture from food for preservation.
- **French Fries:** Optimized setting for perfectly crispy fries.

Image: A visual representation of the eight cooking functions available on the TOPZEE Air Fryer, including Preheat, Air Fry, Roast, Broil, Bake, Reheat, Dehydrate, and French Fries, each with an illustrative food item.

Official Product Videos

Your browser does not support the video tag.

Video: An official TOPZEE store video showcasing the 11-QT Large Air Fryer and its various features and cooking capabilities.

Your browser does not support the video tag.

Video: An official TOPZEE store video demonstrating the 11-QT Air Fryer's suitability for family use, highlighting its capacity and ease of use for preparing meals.

Cleaning & Maintenance

- Always unplug the air fryer and allow it to cool completely before cleaning.
- The 11-QT basket, removable divider, and crisper plate are non-stick and dishwasher-safe for convenient cleanup.
- For stubborn residue, soak components in warm, soapy water before washing.
- Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or scouring pads.
- Ensure all parts are completely dry before reassembling and storing the air fryer.

Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on	Not plugged in; Power outlet malfunction	Ensure plug is securely inserted; Test outlet with another appliance.
Food not cooked evenly	Overcrowding the basket; Not shaking/flipping food	Cook in smaller batches; Shake or flip food halfway through cooking.
White smoke coming from air fryer	Grease from previous use; High-fat food cooking	Clean the basket and crisper plate thoroughly; Drain excess fat from food.
E4 Error Code	Internal malfunction (as reported by some users)	Unplug the unit for 5 minutes and plug back in. If error persists, contact customer support.

Specifications

- **Model Name:** K-AFT11001-UL
- **Capacity:** 11 Quarts (total) / 2 x 5.5 Quarts (with divider)
- **Product Dimensions:** 15.7"D x 15.4"W x 12"H
- **Color:** Black
- **Material:** Plastic, Metal
- **Output Wattage:** 1700 Watts
- **Temperature Range:** 90°F to 400°F
- **Control Method:** Touchscreen
- **Non-stick Coating:** Yes
- **Dishwasher Safe Parts:** Basket, Divider, Crisper Plate
- **Item Weight:** 17.6 Pounds

- **Country of Origin:** China

Warranty & Support

For warranty information, product support, or any questions not covered in this manual, please contact TOPZEE customer support.

Email: Support@topzee.com



Image: A graphic displaying "CUSTOMER SUPPORT" and the email address "Support@topzee.com" for assistance.

Please refer to the original product packaging or the official TOPZEE website for the most up-to-date warranty details and terms of service.

Visit the TOPZEE Store on Amazon for more products and information.