Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

topzee K-AFT11001-UL

topzee 11-QT Large Air Fryer Instruction Manual

Model: K-AFT11001-UL | Brand: topzee

1. Introduction

Thank you for choosing the topzee 11-QT Large Air Fryer. This appliance is designed to provide a versatile and efficient cooking experience with its 8-in-1 functions and flexible basket design. This manual provides essential information for safe operation, proper maintenance, and effective use of your new air fryer. Please read it thoroughly before first use and keep it for future reference.

2. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for other than intended use.
- Ensure the air fryer is placed on a stable, heat-resistant surface with adequate ventilation around it.
- Do not block any ventilation openings.
- Do not overfill the baskets.

3. Product Overview

The topzee 11-QT Large Air Fryer features a sleek design with dual baskets and an intuitive touch control panel. It is equipped with a removable divider to convert between two 5.5-QT baskets and a single 11-QT basket.



Figure 3.1: Front view of the topzee 11-QT Large Air Fryer, showcasing its dual basket design and touch control panel with gold accents.



Figure 3.2: Close-up of the air fryer's digital touch control panel, displaying temperature, time, and various cooking function buttons.

Components:

- Main Unit with Touch Control Panel
- Dual 5.5-QT Baskets
- Removable Divider for 11-QT Capacity
- Crisper Plates (inside baskets)

4. Setup and First Use

Unpacking:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Remove all accessories from the packaging.

Cleaning Before First Use:

- Wash the baskets and crisper plates in hot, soapy water or in the dishwasher. The baskets are dishwasher safe.
- Wipe the inside and outside of the main unit with a clean, damp cloth.
- Ensure all parts are completely dry before use.

Placement:

- Place the air fryer on a stable, level, heat-resistant surface.
- Ensure there is at least 6 inches (15 cm) of space around the back and sides of the unit for proper air circulation.
- Do not place the appliance directly against a wall or other appliances.

5. Operating Instructions

General Operation:

1. Plug the air fryer into a grounded electrical outlet.
2. Press the Power button to turn on the display.
3. Select your desired cooking function, temperature, and time using the touch controls.
4. Press the Start/Pause button to begin cooking.

8-in-1 Versatile Cooking Functions:

Your topzee Air Fryer offers 8 preset cooking modes for various dishes:



Figure 5.1: Visual representation of the eight versatile cooking functions: Preheat, Roast, Broil, Bake, Air Fry, Reheat, Dehydrate, and

French Fries.

- **Air Fry:** For crispy results with little to no oil.
- **Roast:** Ideal for meats and vegetables.
- **Broil:** For quick browning and melting.
- **Bake:** Perfect for cakes, pastries, and more.
- **Reheat:** To warm up leftovers efficiently.
- **Dehydrate:** For making dried fruits, jerky, etc.
- **French Fries:** Optimized setting for perfectly crispy fries.
- **Preheat:** Ensures the air fryer reaches the desired temperature before adding food.

Flexible Basket Design & Full Basket Mode:

The air fryer can be used with two separate 5.5-QT baskets or converted into a single 11-QT basket by removing the divider. This is ideal for larger meals.



Figure 5.2: The air fryer basket with the divider removed, demonstrating the 11-QT full capacity for cooking larger quantities of food.

Dual Cooking & Finish Together:

Prepare two different meals simultaneously at unique temperatures and have them finish at the same time. This feature ensures everything is ready to enjoy together.



Figure 5.3: The air fryer operating with two separate baskets, illustrating the 'Cook Separately Finish Together' function for synchronized meal completion.

Sync Cook Mode:

Easily sync settings for both 5.5-quart baskets with one button, cooking 11 quarts of food at the same temperature, time, and function.



Figure 5.4: The air fryer's control panel highlighting the 'SYNC' button, which allows both baskets to cook with identical settings for convenience.

Fast and Oil Free Cooking:

Achieve deep-fried flavor with little to no oil, making your meals healthier and faster to prepare.



Figure 5.5: Food cooking inside one of the air fryer baskets, demonstrating the 'Fast and Oil Free' cooking method for healthier results.

Cooking Tips:

- For best results, shake or flip food halfway through cooking, especially for smaller items.
- Do not overfill the baskets to ensure even cooking and crispiness.
- Adjust cooking times and temperatures as needed based on food quantity and desired doneness.

6. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your topzee Air Fryer.

- Always unplug the air fryer and allow it to cool completely before cleaning.
- The baskets and crisper plates are dishwasher safe for easy cleaning. Alternatively, wash them with hot, soapy water and a non-abrasive sponge.
- Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the finish.

- Clean the interior of the air fryer with a damp cloth and mild detergent if necessary.
- Ensure all parts are thoroughly dry before storing or next use.

7. Troubleshooting

If you encounter issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet malfunction; unit malfunction.	Ensure the power cord is securely plugged into a working outlet. Try a different outlet. If the issue persists, contact customer support.
Food is not cooked evenly.	Baskets are overfilled; food not shaken/flipped.	Do not overfill the baskets. Shake or flip food halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; fatty ingredients.	Clean the basket and crisper plate thoroughly after each use. For fatty foods, drain excess oil during cooking.
Appliance emits a strange smell on first use.	Manufacturing residues burning off.	This is normal for initial uses and will dissipate. Ensure good ventilation.

8. Specifications

Feature	Specification
Model Name	K-AFT11001-UL
Brand	topzee
Capacity	11 Quarts (convertible to dual 5.5 Quarts)
Product Dimensions	15.7"D x 15.4"W x 12"H
Item Weight	17.6 Pounds
Color	Gold
Material	Metal, Plastic
Output Wattage	1700 Watts
Control Method	Touch
Nonstick Coating	No (referring to the main unit, baskets are non-stick)
Dishwasher Safe	Yes (baskets and crisper plates)

9. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or contact topzee customer service directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DJLPK91P

More documents and user manuals: **https://manuals.plus/**