topzee K- AFT11001-UL

TOPZEE 11-QT Large Air Fryer User Manual

Model: K-AFT11001-UL

Important Safety Information

Please read all instructions carefully before using this appliance to ensure safe and efficient operation. Keep this manual for future reference.

- Always place the air fryer on a stable, heat-resistant surface.
- Do not immerse the main unit, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance matches your local power supply.
- Supervise children closely when the appliance is in use.
- Do not block any ventilation openings.
- Unplug the air fryer when not in use and before cleaning.
- Allow the appliance to cool completely before handling or cleaning.
- Do not operate the appliance with a damaged cord or plug.
- Avoid using abrasive cleaning agents or steel wool.

Product Overview

The TOPZEE 11-QT Large Air Fryer is a versatile 8-in-1 appliance designed for various cooking methods. It features a unique flexible basket design, allowing for both large capacity cooking and simultaneous preparation of different dishes.



Figure 1: Front view of the TOPZEE 11-QT Large Air Fryer, showcasing the digital control panel and dual basket design.



Figure 2: The air fryer with its basket pulled out, illustrating the removable divider for flexible 11-QT or dual 5.5-QT capacity.

Key Features:

- **Flexible Basket Design:** Seamlessly switch between a generous 11-QT basket for large family feasts and two 5.5-QT baskets to cook different dishes simultaneously with varied settings. The included divider lets you take full control of your cooking.
- **Family-Sized Cooking Mode:** Unlock the 11-QT capacity using the FULL BASKET function to prepare hearty, family-sized meals effortlessly. Perfect for cooking large portions in one go.
- **Cook & Serve Together:** Prepare two different meals simultaneously at unique temperatures, and have them finish at the same time. Keep everything piping hot and ready to enjoy all at once—no waiting, just great meals.
- **Sync Cook Mode:** Easily sync settings for both 5.5 quarts baskets with one button, cooking 11 quarts of food at the same temperature, time, and function.
- **8-in-1 Versatile Cooking:** Explore 8 cooking modes in one convenient appliance—Air Fry, Roast, Broil, Bake, Reheat, Dehydrate, French Fries, and Preheat.

Setup and First Use

Unpacking:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Inspect the air fryer for any damage. Do not use if damaged.
3. Wipe the exterior with a damp cloth.
4. Wash the baskets and divider with warm soapy water, rinse thoroughly, and dry completely. These parts are dishwasher safe.

Placement:

- Place the air fryer on a stable, level, heat-resistant surface.
- Ensure there is at least 6 inches (15 cm) of space around the back and sides of the appliance for proper air circulation.
- Do not place the air fryer near flammable materials or heat sources.

Before First Use:

It is recommended to run the air fryer empty for about 10-15 minutes on a high setting (e.g., Air Fry at 400°F) to burn off any manufacturing residues. A slight odor may be present during this initial use; this is normal and will dissipate.

Operating Instructions

The TOPZEE Air Fryer features an intuitive touch control panel. Familiarize yourself with the main functions:

- **Power Button:** Turns the unit on/off.
- **Temperature Controls (TEMP):** Adjusts cooking temperature.
- **Time Controls (TIME):** Adjusts cooking time.
- **Cooking Modes:** Air Fry, Roast, Broil, Bake, Reheat, Dehydrate, French Fries, Preheat.
- **SYNC BUTTON:** Synchronizes settings for both baskets.
- **LEFT BASKET / RIGHT BASKET:** Selects individual baskets for independent cooking.
- **FULL BASKET:** Activates 11-QT capacity mode.
- **FINISH TOGETHER:** Ensures both baskets complete cooking at the same time.
- **START/PAUSE:** Begins or pauses the cooking cycle.

Basic Operation (Single Basket):

1. Place food in the desired basket (Left or Right). Ensure the divider is removed if using the full 11-QT capacity.
2. Insert the basket(s) firmly into the air fryer.
3. Press the Power Button to turn on the display.
4. Select a cooking mode (e.g., Air Fry).
5. Adjust the temperature using the TEMP controls.
6. Adjust the cooking time using the TIME controls.
7. Press START/PAUSE to begin cooking.
8. Shake or flip food halfway through cooking for even results, if necessary.
9. The air fryer will beep when cooking is complete. Carefully remove the basket.

Dual Basket Operation:

To cook two different foods simultaneously, ensure the divider is in place, creating two 5.5-QT baskets.

1. Place food in both the Left and Right baskets.
2. Insert both baskets into the air fryer.
3. Press the Power Button.
4. **For independent cooking:** Select LEFT BASKET, choose mode, temp, and time. Then select RIGHT BASKET, choose its mode, temp, and time. Press START/PAUSE.
5. **For Sync Cook (same settings for both):** Select SYNC BUTTON, choose mode, temp, and time. Press START/PAUSE.
6. **For Finish Together:** Select LEFT BASKET, choose mode, temp, and time. Select RIGHT BASKET, choose mode, temp, and time. Then press FINISH TOGETHER. The air fryer will automatically adjust the start times so both baskets finish simultaneously. Press START/PAUSE.

Maintenance and Cleaning

Proper cleaning ensures the longevity and optimal performance of your air fryer.

General Cleaning:

1. Always unplug the air fryer and allow it to cool completely before cleaning.
2. Wipe the exterior of the appliance with a damp cloth. Do not use harsh chemicals or abrasive materials.
3. Clean the interior of the air fryer with a damp cloth and mild detergent if necessary.

Basket and Divider Cleaning:

- The baskets and divider are **dishwasher safe** for convenient cleaning.
- Alternatively, wash them with warm, soapy water using a non-abrasive sponge.
- For stubborn food residue, soak the baskets in warm soapy water for 10-15 minutes before cleaning.
- Ensure all parts are thoroughly dry before reassembling or storing the air fryer.

Troubleshooting

If you encounter issues with your air fryer, consult the table below for common problems and solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet issue; unit malfunction.	Ensure plug is securely in a working outlet. Try a different outlet. If problem persists, contact customer support.
Food is not cooked evenly.	Overcrowding the basket; not shaking/flipping food.	Cook in smaller batches. Shake or flip food halfway through cooking.
White smoke coming from appliance.	Grease from previous use; high-fat food.	Clean the basket and interior thoroughly. For high-fat foods, drain excess fat during cooking.
Appliance smells like burning plastic.	First use residue; foreign object inside.	This is normal for first use. If it persists, unplug and inspect for foreign objects. Contact support if concerned.

Specifications

Feature	Detail
Brand	TOPZEE
Model Name	K-AFT11001-UL
Capacity	11 Quarts (flexible to dual 5.5 Quarts)
Color	Purle
Product Dimensions	15.7"D x 15.4"W x 12"H
Item Weight	17.6 Pounds
Material	Metal, Plastic
Output Wattage	1700 Watts
Control Method	Touch
Nonstick Coating	No
Dishwasher Safe	Yes (Baskets and Divider)
UPC	860013778453

Warranty and Support

For warranty information or technical support, please contact TOPZEE customer service. Refer to your purchase documentation for specific warranty terms and conditions.

Manufacturer: TOPZEE

Online Store: Visit the TOPZEE Store on Amazon

Please have your model number (K-AFT11001-UL) and purchase date ready when contacting support.

© 2025 TOPZEE. All rights reserved.