ZdalaMit RRMCGA081AWSA

ZdalaMit RRMCGA081AWSA Replacement Remote Control User Manual

For Sharp Micro Component Systems XL-UH240, XL-UH240W, XL-UH242, CP-UH240

Introduction

This manual provides instructions for the proper use and maintenance of your ZdalaMit RRMCGA081AWSA replacement remote control. This remote is designed to function seamlessly with various Sharp Micro Component Systems, offering a direct replacement without the need for programming.
Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.

Product Overview

The ZdalaMit RRMCGA081AWSA is a dedicated replacement remote control for specific Sharp Micro Component System models. It features a standard layout for easy navigation and control of your audio system's functions.





Image: Front view of the ZdalaMit RRMCGA081AWSA replacement remote control, showing all buttons and their labels.

Setup

Battery Installation

The remote control requires two (2) 1.5V AAA alkaline batteries (not included). No programming is required for this remote control; simply install the batteries, and it will be ready for use.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Angled view of the remote control, showing its ergonomic design and button layout.

Important: Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.

Operating Instructions

This remote control provides full functionality for your compatible Sharp Micro Component System. Point the remote control directly at the system's infrared receiver for optimal performance.

Key Functions:

- **ON/STAND-BY:** Powers the system on or off.
- **Number Buttons (0-9, +10):** Direct selection for tracks, radio presets, or inputting numbers.
- **MEMORY:** Stores radio station presets.
- **DISC SELECT (1-5):** Selects a specific disc in a multi-disc changer (if applicable).
- **TUNING (Up/Down Arrows):** Adjusts radio frequency or navigates menus.
- **PRESET (Left/Right Arrows):** Navigates through stored radio presets or tracks.
- **CD Playback Controls (Play, Pause, Stop, Skip):** Controls CD playback.
- **VIDEO/AUX/USB:** Selects input sources.
- **TUNER (BAND):** Switches between AM/FM bands.
- **RANDOM:** Enables random playback for CDs or USB media.
- **USB/II:** Controls USB playback or other secondary functions.
- **CLEAR:** Clears current selections or entries.
- **DIMMER:** Adjusts display brightness.
- **DISPLAY:** Changes display information.
- **FOLDER:** Navigates through folders on USB media.
- **CLOCK/TIMER:** Accesses clock and timer settings.
- **EQUALIZER/MODE:** Selects sound equalizer presets or sound modes.
- **X-BASS/DEMO:** Activates X-Bass feature or demonstration mode.
- **VOLUME (+/-):** Adjusts the system's volume level.



Image: Top-down view of the remote control, highlighting the arrangement of buttons for various functions.

Compatible Models

This ZdalaMit RRMCGA081AWSA replacement remote control is compatible with the following Sharp Micro Component System models:

- Sharp XL-UH240
- Sharp XL-UH240W
- Sharp XL-UH242
- Sharp CP-UH240

This remote functions as a direct replacement for the original RRMCGA081AWSA and GA081AWSA remotes.



Image: A comparison image showing the ZdalaMit replacement remote control next to an original Sharp remote, illustrating their similar design and button layout.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Remote control does not operate the system.	• Batteries are depleted or incorrectly installed. • Obstruction between remote and system. • Remote control is too far from the system.	• Replace batteries with new 1.5V AAA alkaline batteries. Ensure correct polarity. • Remove any objects blocking the line of sight to the system's IR receiver. • Move closer to the system and ensure the remote is pointed directly at it.
Intermittent response from the remote.	• Low battery power. • Interference from strong light sources.	• Replace batteries. • Ensure no strong light sources (e.g., direct sunlight, fluorescent lights) are interfering with the IR signal.

Specifications

- **Model:** RRMCGA081AWSA / GA081AWSA
- **Brand:** ZdalaMit
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Color:** Black
- **Dimensions:** Approximately 8.34 x 1.99 x 0.55 inches (21.2 x 5.05 x 1.4 cm)
- **Weight:** Approximately 1.41 ounces (40 grams) without batteries
- **Compatibility:** Sharp Micro Component Systems XL-UH240, XL-UH240W, XL-UH242, CP-UH240





Image: The remote control shown with its approximate length and width measurements for reference.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Disposal:** Dispose of used batteries according to local regulations. Do not dispose of batteries in

household waste.

Warranty and Support

For information regarding warranty coverage or technical support, please refer to the retailer or manufacturer's official website where the product was purchased. Keep your purchase receipt as proof of purchase.