GIGABYTE Z890 AORUS MASTER

GIGABYTE Z890 AORUS Master Motherboard User Manual

Comprehensive guide for setup, operation, and maintenance.

1. Product Overview

The GIGABYTE Z890 AORUS Master is an ATX motherboard designed to support Intel Core Ultra (Series 2) processors with the LGA 1851 socket. It features advanced power delivery, extensive thermal solutions, and cutting-edge connectivity for high-performance computing.



Figure 1: GIGABYTE Z890 AORUS Master Motherboard and its retail packaging.

Key features include DDR5 memory support, multiple PCIe 5.0 and M.2 slots, dual Thunderbolt 4 ports, WIFI7, and 10GbE LAN. The board is built with DIY-friendly features like M.2 EZ-Latch and PCIe EZ-Latch for simplified assembly.

2. Setup

2.1 CPU Installation

The Z890 AORUS Master utilizes the LGA 1851 socket, specifically designed for Intel Core Ultra (Series 2) processors. Ensure proper alignment of the CPU with the socket before gently lowering it into place. The socket features a new plastic nub design to prevent incorrect chip insertion.



Figure 2: Top-down view of the motherboard highlighting the LGA 1851 CPU socket.

The new socket design also incorporates improved dampening to reduce stress on the CPU over time when clamped down. LGA 1700 coolers should generally fit, but contact frames may not be compatible due to shifted holes and a new nub at the bottom of the socket.

2.2 RAM Installation

This motherboard supports DDR5 memory across four DIMM slots, with XMP Memory Module Support. It can be equipped with up to 256GB of RAM. For optimal performance, install RAM modules in the designated dual-channel slots as indicated in the

motherboard manual (typically A2 and B2 first).

2.3 Storage Installation

The Z890 AORUS Master provides five M.2 slots (two PCIe 5.0 and three PCIe 4.0) and four SATA 6Gb/s connectors for storage. The M.2 slots are covered by massive heatsinks for thermal management, which are tool-less and can be easily unclipped for installation or removal of M.2 drives.




Figure 3: EZ-Latch designs simplify the installation of M.2 drives and PCIe cards.

2.4 PCIe Devices

The motherboard features one PCIe 5.0 x16 slot, one PCIe 4.0 x4 slot, and one PCIe 4.0 x1 slot. The PCIe 5.0 x16 slot is reinforced with "Ultra Durable PCIe Armor" for enhanced durability and supports the latest high-performance graphics cards and Gen5 SSDs simultaneously, thanks to 20 PCIe 5.0 lanes.

2.5 Power Connections

Connect the 24-pin ATX power connector and two 8-pin CPU power connectors from your power supply unit (PSU) to the corresponding ports on the motherboard. Ensure all connections are secure to provide stable power to your system components.

2.6 Front Panel Connections

Connect your case's front panel cables (power button, reset button, HDD LED, power LED, USB ports, audio jacks) to the clearly labeled headers on the motherboard. The G-Connector included in the box can simplify this process.




Figure 4: Detailed diagram of motherboard headers and rear I/O ports.

3. Operating

3.1 BIOS/UEFI

The motherboard features a user-friendly BIOS/UEFI interface. You can update the BIOS using the Q-Flash Plus button on the rear I/O panel, which allows updating without a CPU, RAM, or graphics card installed. The Clear CMOS button is also available for resetting BIOS settings.

For performance tuning, the BIOS includes GIGABYTE PerfDrive, a one-click accelerator that enhances CPU and DDR5 performance. It offers various settings like "Baseline," "Performance," and "Extreme" to optimize your system. It also includes a safe overclocking protection system against over-voltage and short circuits.

3.2 Software

Install the GIGABYTE Control Center software from the official GIGABYTE website. This utility allows you to monitor system status, adjust fan speeds, manage RGB lighting (RGB FUSION), and apply various system optimizations directly from your operating system.

4. Maintenance

4.1 Thermal Management

The Z890 AORUS Master is equipped with an 18+1+2 phase, 110A Smart Power Stage VRM design, complemented by VRM Thermal Armor and M.2 Thermal Guard heatsinks. These robust thermal solutions ensure stable operation and efficient heat dissipation, even under heavy loads.



Figure 5: Overview of the comprehensive thermal design, including VRM and M.2 heatsinks.

Regularly check and clean dust from your PC case and motherboard components to maintain optimal airflow and thermal performance. Ensure all fans are functioning correctly.

4.2 Cleaning Recommendations

To clean the motherboard, first power down and unplug your PC. Use compressed air to remove dust from heatsinks, fan blades, and other components. For stubborn dirt, a soft brush or lint-free cloth lightly dampened with isopropyl alcohol can be used. Avoid excessive moisture and ensure components are completely dry before powering on.

5. Troubleshooting

If you encounter issues, refer to the EZ-Debug Zone on the motherboard, which provides diagnostic LEDs to indicate the status of key components (CPU, RAM, GPU, Boot Device) during startup. This can help pinpoint the source of a problem quickly.

- **No Power/No Boot:** Double-check all power connections (24-pin ATX, 8-pin CPU). Ensure the PSU is switched on.
- **No Display:** Verify the graphics card is properly seated and connected to power. Check monitor cables. If using integrated graphics, ensure your CPU supports it and connect to the motherboard's display output.
- **RAM Issues:** Reseat RAM modules. Try booting with one stick of RAM at a time. Ensure RAM is installed in the correct slots for dual-channel operation.
- **Component Not Detected:** Reseat the component (e.g., M.2 SSD, PCIe card). Check relevant cables (SATA). Update

drivers or BIOS if necessary.

- **Overheating:** Ensure CPU cooler is properly installed with thermal paste. Check fan operation and case airflow. Monitor temperatures using GIGABYTE Control Center.

For persistent issues, consult the detailed troubleshooting section in the full product manual available on the GIGABYTE support website.

6. Specifications

Feature	Detail
Brand	GIGABYTE
Model Name	Z890 AORUS MASTER
CPU Socket	LGA1851
Compatible Processors	Intel Core Ultra 200 Processors (Series 2)
RAM Memory Technology	DDR5
RAM Memory Maximum Size	256 GB
Memory Clock Speed	5600 MHz (Supports higher via XMP)
Chipset Type	Intel Z890
PCIe Slots	1x PCIe 5.0 x16, 1x PCIe 4.0 x4, 1x PCIe 4.0 x1
M.2 Slots	5 (2x PCIe 5.0, 3x PCIe 4.0)
SATA Ports	4x SATA 6Gb/s
USB Connectivity	Dual Thunderbolt 4, Front USB-C, multiple USB 3.2 Gen2/Gen1 ports
Networking	WIFI7, 10GbE LAN
Power Design	18+1+2, 110A Smart Power Stage
Dimensions	13.43 x 10.87 x 3 inches (Package)
Weight	5.59 pounds

7. Warranty and Support

The GIGABYTE Z890 AORUS Master Motherboard comes with a 5-year limited warranty, covering defects in materials and workmanship under normal use. For detailed warranty terms and conditions, please refer to the official GIGABYTE website or the warranty card included with your product.

For technical support, driver downloads, BIOS updates, and additional product information, visit the official GIGABYTE support

page. You can also find FAQs and community forums for further assistance.

© 2025 GIGABYTE. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question