Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Havells Havells Air-Oven Avanza (Model GHCAFEFK170)

Havells Air-Oven Avanza 15L Instruction Manual

Model: GHCAFEFK170

1. Introduction

This instruction manual provides essential information for the safe and efficient operation of your Havells Air-Oven Avanza 15L. Please read this manual thoroughly before first use and retain it for future reference. This appliance combines multiple cooking functions, including air frying, baking, grilling, toasting, dehydrating, and convection oven capabilities, designed to simplify your cooking experience.

2. Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs. Always use oven mitts or gloves when handling hot materials.
- To protect against electric shock, do not immerse the cord, plugs, or the main unit in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control to 'off', then remove the plug from the wall outlet.
- Do not use the appliance for other than intended use.
- Ensure adequate ventilation around the appliance during operation.
- The appliance features an automatic shut-off function for safety, powering down after cooking is complete. The cool-

touch handle ensures safe access to food.

3. Product Overview

3.1 Components

The Havells Air-Oven Avanza 15L comes with the following components:

- 1 N Main Unit (Air Oven)
- 1 N Baking Tray
- 2 N Mesh Trays
- 1 N Rectangular Frying Basket with Detachable Handle
- 1 N Skewer Set
- 1 N Rotisserie Fork



Image: Front view of the Havells Air-Oven Avanza 15L, showcasing the digital control panel and the interior cooking chamber with food on a rotisserie.



Image: Various accessories included with the Air-Oven, such as a frying basket with handle, skewer set, rotisserie fork, and mesh/baking tray, displayed alongside example dishes.

3.2 Key Features

- **Powerful 1700W Performance:** Ensures fast, efficient, and even cooking with powerful heat circulation.
- **15L Large Capacity:** Cook generous portions, suitable for families and gatherings.
- **14 Pre-Set Functions:** Includes modes for air frying, grilling, baking, toasting, dehydrating, and more for one-touch convenience.
- **Aerocrisp Technology:** Achieves crispy results with up to 85% less oil through rapid, even circulation of hot air.
- **Digital Touch Control:** User-friendly digital display and intuitive touch controls for setting time, temperature, and selecting pre-sets.
- **Triple-Layer Borosilicate Glass Window:** Heat-resistant and durable window for monitoring cooking progress without opening the door.
- **6-in-1 Functionality:** Replaces multiple appliances, functioning as an air fryer, oven, grill, toaster, dehydrator, and

convection oven.

- **Interior Lighting:** Built-in light allows easy monitoring of food during cooking.
- **Auto Shut-Off & Cool-Touch Handle:** Safety features for automatic power-off and safe handling.



Image: Illustration of the 6-in-1 functionality of the Air-Oven, highlighting Convection, Grill, Toaster, Dehydrator, OTG, and Air Fryer modes, along with 15L capacity and 1700W performance.



Image: Visual representation of Aerocrisp Technology, showing hot air circulation for healthier, crispier frying results.

4. Setup

4.1 Unpacking

1. Carefully remove all packaging materials from the appliance and its accessories.
2. Check that all components listed in Section 3.1 are present and undamaged.
3. Remove any promotional stickers or labels.

4.2 Initial Cleaning

1. Wipe the exterior of the appliance with a damp cloth.

2. Wash all accessories (baking tray, mesh trays, frying basket, skewer set, rotisserie fork) with warm, soapy water. Rinse thoroughly and dry completely.
3. Before first use, it is recommended to run the air oven empty for about 10-15 minutes at 180°C (350°F) to burn off any manufacturing residues. A slight odor may be present, which is normal. Ensure good ventilation during this process.

4.3 Placement

- Place the appliance on a stable, heat-resistant, and level surface.
- Ensure there is at least 10-15 cm (4-6 inches) of clear space on all sides and above the appliance for proper air circulation.
- Do not place the appliance near flammable materials or heat sources.

4.4 Power Connection

- Ensure the appliance is unplugged during setup.
- Plug the power cord into a grounded electrical outlet. The appliance operates on 230 Volts.

5. Operating Instructions

5.1 Digital Touch Control Panel

The Havells Air-Oven Avanza features an intuitive digital touch control panel for easy operation.



Image: Close-up of the digital touch control panel with LED display, showing options for temperature, time, and various functions.

5.2 Using Pre-set Functions

The appliance includes 14 pre-set cooking modes for common dishes. These pre-sets automatically adjust time and temperature for optimal results.

1. Place food inside the air oven using the appropriate accessory (e.g., frying basket for fries, baking tray for cake).
2. Close the door securely.
3. Press the Power button to turn on the appliance.
4. Select the desired pre-set function from the control panel. The display will show the default time and temperature for that pre-set.
5. You may adjust the time and temperature manually if needed using the dedicated controls.
6. Press the Start/Pause button to begin cooking.
7. The interior light can be turned on/off to monitor progress through the triple-layer borosilicate glass window.

8. The appliance will automatically shut off when the cooking cycle is complete.



Image: A visual guide to the 14 pre-set cooking menus available on the Havells Air-Oven Avanza, including French Fries, Steak, Pizza, Cake, and Dehydrate.

5.3 Manual Cooking

For dishes not covered by pre-sets, you can manually set the cooking time and temperature.

1. Place food and close the door.
2. Press the Power button.
3. Use the Temperature control to set the desired temperature (up to 200°C).
4. Use the Time control to set the desired cooking duration (up to 60 minutes).
5. Press the Start/Pause button to begin.

5.4 Special Functions

- **Rotisserie:** Use the rotisserie fork for roasting whole chickens or larger cuts of meat. Ensure the food is securely fastened and balanced.
- **Dehydrate:** This function uses low heat and consistent airflow to remove moisture from food, ideal for fruits, vegetables, and jerky.
- **Keep Warm:** Maintains food at a warm temperature after cooking.
- **Pre-Heat:** Heats the oven to the desired temperature before adding food, ensuring more accurate cooking times.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your appliance.

6.1 Before Cleaning

- Always unplug the air oven from the power outlet.
- Allow the appliance to cool down completely before cleaning any part.

6.2 Cleaning the Main Unit

- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- Clean the interior with a damp cloth and mild detergent. For stubborn stains, a non-abrasive sponge can be used.
- Do not immerse the main unit in water or any other liquid.

6.3 Cleaning Accessories

- All included accessories (baking tray, mesh trays, frying basket, skewer set, rotisserie fork) feature a durable non-stick coating for easy cleaning.
- Wash accessories with warm, soapy water using a soft sponge. Rinse thoroughly and dry completely before storing or reusing.
- While the feature bullets mention 'dishwasher safe accessories', the overall product specification indicates 'Is Dishwasher Safe: No'. To ensure longevity, hand washing is recommended for all components.

7. Troubleshooting

If you encounter issues with your Havells Air-Oven Avanza, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the power cord is securely plugged into a working outlet. Check your home's circuit breaker.
Food is not cooking evenly.	Overcrowding; incorrect temperature/time; food not rotated.	Do not overcrowd the cooking chamber. Ensure food is in a single layer. Adjust temperature and time as needed. For best results, rotate or flip food halfway through cooking.

Problem	Possible Cause	Solution
White smoke coming from the appliance.	Grease residue from previous use; high-fat food.	Clean the appliance and accessories thoroughly after each use. For high-fat foods, drain excess fat during cooking.
Food is not crispy.	Too much moisture; insufficient oil (for air frying); overcrowding.	Pat food dry before cooking. A light coating of oil can enhance crispiness. Avoid overcrowding.

If the problem persists after attempting these solutions, please contact Havells customer support.

8. Specifications

Feature	Detail
Model Name	AWANZA AIR-OVEN
Item Model Number	GHCAFEFK170
Capacity	15 litres
Output Wattage	1700 Watts
Voltage	230 Volts
Max Temperature Setting	200 Degrees Celsius
Control Method	Touch
Product Dimensions (D x W x H)	47D x 42W x 42H Centimeters
Item Weight	4 kg 500 g
Material	Acrylonitrile Butadiene Styrene
Special Features	14 Auto pre-set option, Automatic Shut-Off, Programmable, Temperature Control, Timer
Nonstick Coating	Yes
Dishwasher Safe	No (for main unit)
Manufacturer	HAVELLS INDIA LIMITED
Country of Origin	China

9. Warranty and Support

9.1 Warranty Information

The Havells Air-Oven Avanza 15L comes with a**2-year warranty** from the date of purchase. Please retain your purchase receipt as proof of warranty. The warranty covers manufacturing defects under normal use conditions.

9.2 Customer Support

For any product-related queries, service requests, or warranty claims, please contact Havells customer support:

- **Manufacturer:** HAVELLS INDIA LIMITED
- **Registered Office:** 904, Surya Kiran Building, K.G. Marg, New Delhi - 110001 (INDIA)
- For further assistance, visit the official Havells website or contact their customer service helpline.

10. Video Resources

No official product videos were available for embedding in this manual. Please refer to the manufacturer's official website or product page for any available video demonstrations or guides.

© 2024 Havells. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DJS9ZK73

More documents and user manuals: **https://manuals.plus/**