Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EUARY V10

EUARY V10 Cordless Stick Vacuum Cleaner Instruction Manual

Model: V10

1. Product Overview

The EUARY V10 Cordless Stick Vacuum Cleaner is a powerful and versatile cleaning device designed for various surfaces. It features a 550W motor, providing up to 50KPa of suction power, and incorporates an H13 HEPA filtration system for efficient dust capture.

Key Features

- **Powerful Suction:** 550W motor with up to 50KPa suction for deep cleaning.
- **Long Runtime:** Up to 60 minutes of continuous operation on a single charge.
- **Advanced Filtration:** H13 HEPA filtration system captures 99.99% of microscopic particles.
- **Multi-Surface Cleaning:** Effective on hardwood, carpets, stairs, and mattresses.
- **Versatile Design:** Easily converts to a handheld vacuum for targeted cleaning.
- **LED Display:** All-in-one LED display shows battery level, suction mode, and alerts.
- **Self-Standing Design:** Conveniently stands upright for storage.



The EUARY V10 Cordless Stick Vacuum Cleaner with its main components and attachments.

2. Safety Instructions

Please read all safety instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

General Safety

- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer’s recommended attachments.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.

- Do not use without dust cup and/or filters in place.

Electrical Safety

- Do not handle plug or appliance with wet hands.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners.
- Keep cord away from heated surfaces.
- Unplug from outlet when not in use and before servicing.

Battery Safety

- Use only the charger specified by the manufacturer.
- Do not store the appliance or battery pack where the temperature may reach or exceed 104°F (40°C).
- Do not incinerate the battery pack even if it is severely damaged or inoperable. The batteries can explode in a fire.
- Do not short-circuit the battery pack.

---

3. Package Contents

Please check the package contents to ensure all items are present and undamaged.

- Main Vacuum Unit
- Extension Tube
- Motorized Floor Brush with LED Lights
- Lithium-ion Battery Pack
- Wall Mount Bracket
- Power Adapter/Charger
- Crevice Tool
- 2-in-1 Brush Tool
- Cleaning Brush
- Instruction Manual

---

4. Setup

Assembly

1. Insert the extension tube into the main vacuum unit until it clicks into place.
2. Attach the motorized floor brush to the other end of the extension tube, ensuring it clicks securely.
3. For handheld use, attach desired accessories (crevice tool or 2-in-1 brush tool) directly to the main vacuum unit.

Video demonstrating the assembly and general use of the EUARY V10 vacuum cleaner.

Charging the Battery

1. Ensure the battery is properly inserted into the charging dock or the main vacuum unit.
2. Connect the power adapter to the charging dock/vacuum and plug it into a wall outlet.
3. The LED indicator on the battery or vacuum will show charging status. A full charge typically takes approximately 4-5

hours.

Video illustrating the battery charging process for the vacuum cleaner.



The powerful 2500mAh Lithium-ion battery provides up to 60 minutes of running time.

Wall Mount Installation

1. Choose a suitable location near a power outlet for convenient charging and storage.
2. Mark the drilling points on the wall using the wall mount bracket as a template.
3. Drill holes, insert wall plugs (if necessary), and secure the bracket with screws.
4. Hang the vacuum cleaner on the wall mount for storage and charging.



The self-standing design allows for easy storage and access.

5. Operating Instructions

Power On/Off and Suction Modes

1. Press the power button to turn the vacuum cleaner on or off.
2. Use the mode selection button to cycle through the 3 available suction power levels: Low, Medium, and High (Turbo).
3. The LED display will indicate the current suction mode and remaining battery life.



The all-in-one LED display provides real-time information on battery and suction settings.

Floor Cleaning

1. Attach the motorized floor brush for cleaning hard floors and carpets.
2. The integrated LED lights on the brush head illuminate dust and debris in dark areas.
3. Select the appropriate suction mode based on the floor type and level of dirt.



The vacuum is suitable for different floor materials, from hard wood to carpet.



Experience adjustable powerful suction up to 50KPa for thorough cleaning.

Using Attachments

1. Convert the vacuum to handheld mode by detaching the extension tube and floor brush.
2. Attach the crevice tool for narrow spaces, corners, and edges.
3. Use the 2-in-1 brush tool for upholstery, curtains, and delicate surfaces.



The versatile design allows for easy conversion to a handheld unit for cleaning furniture and pet hair.

6. Maintenance

Emptying the Dustbin

1. Ensure the vacuum is turned off and disconnected from the charger.
2. Locate the dustbin release button, usually near the bottom of the main unit.
3. Press the button to open the dustbin flap and empty contents into a trash can.

4. Close the dustbin flap securely until it clicks.

Cleaning the Brush Roll

1. Turn off the vacuum and detach the motorized floor brush.
2. Locate the brush roll release mechanism (often a latch or button) on the side of the brush head.
3. Remove the brush roll. Use the provided cleaning tool or scissors to cut away any tangled hair or debris.
4. Rinse the brush roll under running water if necessary, ensuring it is completely dry before reinserting.
5. Reinsert the brush roll and secure the release mechanism.

Video demonstrating the removal, cleaning, and reinstallation of the brush roll.

Filter Maintenance

1. Twist and pull to remove the dustbin from the main unit.
2. Remove the HEPA filter and metal filter from the dustbin.
3. Tap the filters gently to remove loose dust. Rinse them under cold water until the water runs clear.
4. Allow the filters to air dry completely for at least 24 hours before reassembling. Do not use a dryer or direct heat.
5. Reassemble the filters and dustbin, then attach the dustbin back to the main unit.



The H13 HEPA filtration system ensures clean air by intercepting microscopic particles.

7. Troubleshooting

If you encounter any issues with your EUARY V10 vacuum cleaner, please refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is not charged or not properly installed.	Charge the battery fully. Ensure the battery pack is securely clicked into place.
Low suction power	Dustbin is full, filters are clogged, or brush roll is obstructed.	Empty the dustbin. Clean or replace the filters. Remove any obstructions from the brush roll.
Brush roll not spinning	Brush roll is jammed by debris or not properly installed.	Remove any hair or debris from the brush roll. Ensure the brush roll is correctly installed and locked.
Vacuum stops unexpectedly	Battery is low or overheating.	Recharge the battery. Allow the vacuum to cool down before resuming use.
Unusual noise	Obstruction in the air path or brush roll.	Check for and remove any blockages in the nozzle, tube, or dustbin. Clean the brush roll.

8. Specifications

Detailed technical specifications for the EUARY V10 Cordless Stick Vacuum Cleaner.

Feature	Specification
Brand	EUARY
Model Number	V10
Product Dimensions (L x W x H)	22 x 24 x 110 cm
Item Weight	4.09 Kilograms
Motor Power	550W (0.74 horsepower)
Suction Power	Up to 50KPa
Number of Speeds	3
Battery Life (Runtime)	Up to 1 hour (60 minutes)
Power Source	Battery Powered
Cordless	Yes
Filter Type	HEPA Filter (H13)
Surface Recommendation	Hardwood, Stairs, Mattresses, Carpets

9. Warranty and Support

Your EUARY V10 Cordless Stick Vacuum Cleaner comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact EUARY customer service. Contact information can typically be found on the product packaging or the official EUARY website.

Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DJT1BCG1

More documents and user manuals: **https://manuals.plus/**