Lxlu LXZLJ1005-6

Lxlu Electric Spin Scrubber User Manual

Model: LXZLJ1005-6

1. Introduction

Thank you for purchasing the Lxlu Electric Spin Scrubber. This cordless cleaning brush is designed to make your cleaning tasks easier and more efficient, reaching various surfaces with its powerful motor and versatile brush heads. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.

2. Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before using the appliance.
- Do not immerse the main unit in water. The brush heads are washable, but the motor housing should be kept dry.
- Keep out of reach of children. This is not a toy.
- Use only the charging cable provided by the manufacturer.
- Do not operate the scrubber if it has been dropped, damaged, or immersed in water.
- Ensure the brush head is securely attached before operation.
- Avoid direct contact with eyes or skin when using cleaning solutions.
- Store the scrubber in a dry place when not in use.

3. Product Overview

The Lxlu Electric Spin Scrubber comes with a main unit, an extendable handle, and multiple interchangeable brush heads for various cleaning needs.



Figure 1: Components of the Electric Spin Scrubber. This image displays the main scrubber unit, an extendable handle, a USB charging cable, and seven different brush heads including flat brushes, corner brushes, and polishing pads, along with water splash effects indicating its use.

Package Contents:

- Electric Spin Scrubber Main Unit
- Extendable Handle

- USB Charging Cable
- 7 Replaceable Brush Heads (e.g., large flat brush, small flat brush, corner brush, dome brush, scouring pad, sponge pad, microfiber pad)
- User Manual (this document)

4. Setup and Charging

4.1 Initial Charging:

Before first use, fully charge the scrubber. Connect the USB charging cable to the charging port on the main unit and plug the other end into a standard USB power adapter (not included). The indicator lights will show charging status. A full charge typically takes 3-4 hours.

4.2 Assembling the Scrubber:

1. **Attach Brush Head:** Select the desired brush head. Align the brush head with the rotating shaft on the main unit and push firmly until it clicks into place.
2. **Attach Extendable Handle (Optional):** For extended reach, connect the main scrubber unit to the extendable handle. Align the connection points and twist to secure. To adjust the length, twist the handle sections to loosen, extend to the desired length, and twist to tighten.

5. Operating Instructions

5.1 Powering On/Off:

Press the power button on the handle to turn the scrubber on. Press it again to turn it off.

5.2 Selecting Brush Heads:

Choose the appropriate brush head for the surface and type of dirt you are cleaning:

- **Large Flat Brush:** Ideal for large flat surfaces like floors, tiles, and walls.
- **Small Flat Brush:** Suitable for smaller flat areas, countertops, or shower doors.
- **Corner Brush/Dome Brush:** Designed for corners, grout lines, and curved surfaces like sinks or bathtubs.
- **Scouring Pad:** For tough stains and stubborn grime.
- **Sponge Pad:** For gentle cleaning or polishing.
- **Microfiber Pad:** For delicate surfaces or buffing.

5.3 Cleaning Procedure:

1. Apply a suitable cleaning solution directly to the surface to be cleaned or to the brush head.
2. Turn on the scrubber.
3. Gently press the rotating brush head against the surface. Do not apply excessive pressure, as the motor's rotation does the work.
4. Move the scrubber slowly over the area, allowing the brush to scrub away dirt and grime.
5. After cleaning, wipe the surface with a clean cloth and rinse if necessary.

6. Care and Maintenance

6.1 Cleaning the Scrubber:

- After each use, remove the brush head.

- Rinse the brush heads thoroughly under running water to remove any dirt or cleaning solution residue. Allow them to air dry completely before storing.
- Wipe the main unit and handle with a damp cloth. **Do not immerse the main unit in water.**

6.2 Storage:

Store the scrubber and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the unit is fully charged before long-term storage to preserve battery life.

7. Troubleshooting

Problem	Possible Cause	Solution
Scrubber does not turn on.	Battery is low or depleted.	Charge the scrubber fully.
Brush head stops spinning or spins slowly.	Excessive pressure applied. Battery is low. Brush head is jammed.	Reduce pressure. Charge the scrubber. Check for obstructions and clear them.
Scrubber not charging.	Charging cable not properly connected. Faulty power adapter.	Ensure cable is securely connected. Try a different USB power adapter.

8. Specifications

Feature	Detail
Model Number	LXZLJ1005-6
Brand	Lxlu
Power Source	Rechargeable Battery (Cordless)
Brush Heads Included	7 (various types)
Handle Material	LXZLJ1005-6
Product Dimensions	1"L x 1"W x 1"H
Item Weight	1 pounds
Surface Recommendation	Floor, Wood, Glass, Tile, Plastic, Metal, Grout

9. Warranty and Support

For warranty information or technical support, please contact Lxlu customer service. Details can typically be found on the product packaging or the official Lxlu website.
Please retain your proof of purchase for any warranty claims.

© 2024 Lxlu. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question