joliker M301-pro

joliker M301-pro MP3 Player User Manual

Model: M301-pro

Introduction

This user manual provides comprehensive instructions for the operation, maintenance, and troubleshooting of your joliker M301-pro MP3 Player. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your user experience.



Image: The joliker M301-pro MP3 Player, showcasing its sleek black design and vibrant touchscreen interface with pre-installed applications.

Package Contents

Verify that all items are present in the package:

- 1x joliker M301-pro Music Player

- 1x USB Type-C Charging Cable
- 1x Wired Headphones
- 1x 64GB TF Card (pre-installed)
- 1x Screen Protective Film
- 1x Protective Case
- 1x User Manual (this document)



Image: A visual representation of all items included in the joliker M301-pro MP3 Player retail package.

Product Overview

The joliker M301-pro is an advanced MP3/MP4 player featuring Android 13, an 8-core MTK processor, and a 4.02-inch IPS touchscreen. It offers extensive storage and versatile connectivity options.

Key Features:

- **Operating System:** Android 13
- **Processor:** 8-core MTK chip
- **Memory:** 4GB RAM + 32GB ROM (internal), 64GB Micro SD card included (total 96GB)
- **Expandable Storage:** Up to 1TB via Micro SD card
- **Display:** 4.02-inch IPS Touchscreen (640x1136px resolution)
- **Connectivity:** Bluetooth 5.0, Wi-Fi, USB Type-C
- **Battery:** 2000mAh (up to 50 hours music playback, 8 hours video playback)
- **Pre-installed Apps:** Spotify, Deezer, Amazon Music, Google Play Store
- **Supported Video Formats:** AVI, MKV, RMVB, MP4, MPG, MOV



Image: Internal specifications of the joliker M301-pro, detailing its MTK 8-core processor, Android 13 OS, and memory configuration.

Setup

1. Initial Charge

Before first use, fully charge the device. Connect the included USB Type-C cable to the player's charging port and the other end to a USB power adapter (not included) or a computer's USB port.

- Charging Time: Approximately 2 hours for a full charge.
- Battery Indicator: The screen will display a charging icon.



Image: Battery specifications and performance metrics for the joliker M301-pro.

2. Power On/Off

- **Power On:** Press and hold the Power button (located on the side) until the screen lights up.
- **Power Off:** Press and hold the Power button, then select "Power off" from the options.
- **Screen On/Off:** Briefly press the Power button to turn the screen on or off without powering down the device.

3. Initial Setup Wizard

Upon first power-on, follow the on-screen prompts to:

- Select Language
- Connect to Wi-Fi network
- Set Date and Time
- Sign in to Google Account (optional, for Play Store access)



Image: The device's Wi-Fi connectivity and customizable app features, showing the Google Play Store for app downloads.

Operating Instructions

1. Navigation and Interface

- **Touchscreen:** Navigate by tapping, swiping, and pinching on the 4.02-inch IPS display.
- **Home Button:** The circular button below the screen returns you to the home screen.
- **Volume Buttons:** Located on the side, use to adjust audio volume.

2. Music Playback

The device comes with pre-installed music apps like Spotify, Deezer, and Amazon Music. You can also use the built-in music player for local files.

- **Adding Music:** Connect the player to a computer via USB-C cable. The device will appear as a removable storage device. Drag and drop music files (MP3, FLAC, WAV, etc.) into the "Music" folder.
- **Playing Music:** Open your preferred music application. Browse your library and select a song to play.
- **HiBy Music App:** The device features a powerful HiBy Music App for high-fidelity audio playback.

3. Video Playback

The M301-pro supports 1080P HD video playback and various formats.

- **Supported Formats:** AVI, MKV, RMVB, MP4, MPG, MOV.
- **Adding Videos:** Connect to a computer and transfer video files to the "Videos" folder.
- **Playing Videos:** Open a video player app (e.g., the default Gallery or a downloaded player) and select your video.



Image: The device's capability for 1080P HD video playback, showing a clear visual experience on its IPS touchscreen.

4. Bluetooth Connectivity

Connect to Bluetooth headphones, speakers, or other devices.

1. Go to **Settings** > **Connected devices** > **Bluetooth**.
2. Toggle Bluetooth **On**.
3. Ensure your Bluetooth device is in pairing mode.
4. Select your device from the list of available devices to pair.



Image: Demonstration of the upgraded Bluetooth 5.0 connection, enabling stable pairing with various audio devices.

5. Wi-Fi Connectivity and App Store

Connect to Wi-Fi for online streaming, app downloads, and web browsing.

1. Go to **Settings** > **Network & internet** > **Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired network and enter the password if prompted.

Once connected, you can use pre-installed apps or download new ones from the Google Play Store.

- **Google Play Store:** Tap the "Play Store" icon on the home screen to browse and download apps like Audible, YouTube Kids, Kindle, etc.

6. Storage Management

The device comes with 96GB of total storage (32GB internal + 64GB TF card) and supports expansion up to 1TB.

- **Checking Storage:** Go to **Settings** > **Storage** to view available space.
- **Inserting/Removing TF Card:** Locate the TF card slot on the side of the device. Gently insert or remove the card. Ensure the device is powered off before removing the card to prevent data corruption.



Image: Illustration of the 96GB large storage capacity and its expandability up to 1TB via a Micro SD card.

Maintenance

1. Cleaning the Device

- Use a soft, lint-free cloth to clean the screen and body.
- Do not use abrasive cleaners, alcohol, or solvents.
- Avoid getting moisture into ports or openings.

2. Battery Care

- Avoid extreme temperatures (hot or cold) as they can degrade battery life.
- Charge the device regularly, but avoid leaving it fully discharged for extended periods.
- If storing the device for a long time, charge it to about 50% before storage.

3. Software Updates

Periodically check for software updates to ensure optimal performance and security.

1. Go to **Settings** > **System** > **System update**.
2. Follow the on-screen instructions to download and install any available updates.

Troubleshooting

Problem	Possible Cause	Solution
Device won't turn on	Low battery; System crash	Charge the device for at least 30 minutes. If still unresponsive, press and hold the Power button for 10-15 seconds to force a restart.
Cannot connect to Wi-Fi	Incorrect password; Router issue; Out of range	Double-check password. Restart your Wi-Fi router. Move closer to the router. Try connecting to another Wi-Fi network.
Bluetooth pairing fails	Device not in pairing mode; Interference	Ensure the Bluetooth accessory is in pairing mode. Turn Bluetooth off and on again on the player. Clear previous Bluetooth connections.
Music/Video playback issues	Unsupported file format; Corrupted file; Low storage	Verify file format is supported. Try playing another file. Check available storage space. Re-transfer the file.
Device is slow/unresponsive	Too many apps running; Low memory	Close background applications. Restart the device. Consider uninstalling unused apps or clearing cache.

Specifications

Feature	Detail
Model Name	j-US M301-pro sample
Operating System	Android 13
Processor	8-core MTK chip
RAM	4GB
Internal Storage	32GB ROM

Feature	Detail
Included TF Card	64GB (Total 96GB)
Max Expansion	Up to 1TB (Micro SD)
Screen Size	4.02 Inches IPS Touchscreen
Resolution	640x1136px
Bluetooth Version	5.0
Connectivity	Wi-Fi, Bluetooth, USB Type-C
Battery Capacity	2000mAh Lithium Polymer
Music Playback Time	Up to 50 hours
Video Playback Time	Up to 8 hours
Charging Time	Approx. 2 hours
Dimensions	0.35 x 2.24 x 4 inches
Weight	3.09 ounces
Supported Video Formats	AVI, MKV, RMVB, MP4, MPG, MOV
Special Features	Built-In Speaker, Equalizer, FM Radio, Touch Screen, Video Playback, App Store

Warranty and Support

For warranty information and technical support, please refer to the warranty card included in your package or visit the official joliker website. Keep your purchase receipt as proof of purchase.
Customer Service Contact: Please refer to the contact information provided on the product packaging or the official joliker website for support inquiries.

© 2024 joliker. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What should I do if my joliker M301-pro MP3 Player is stuck on the 'Hello' screen and won't open any apps?

If your joliker M301-pro is stuck on the "Hello" screen (the initial setup or startup screen) and will not proceed to the main interface, follow these troubleshooting steps:Force a Restart: Press and hold the...

Read full answer

How can I reset the joliker M301-pro MP3 Player?

To reset or force a restart of your joliker M301-pro MP3 Player if it becomes unresponsive or crashes, follow these steps:Force Restart: Press and hold the Power button (located on the side of the...

Read full answer