LIKIMIO HK-DCD-03

LIKIMIO 8-Drawer Dresser User Manual

Model: HK-DCD-03

1. Product Overview

The LIKIMIO 8-Drawer Dresser is a versatile and stylish furniture piece designed to enhance your bedroom, living room, hallway, or entryway. It features ample storage with eight drawers, a convenient built-in charging station, and an additional storage bag for smaller items. Crafted from high-quality MDF, this dresser offers durability and a timeless design that complements various home decors.



Image: The LIKIMIO 8-Drawer Dresser in black, showcasing its elegant design and ample top surface for decor.

2. Key Features

- **Expansive Drawer Space:** Features 8 drawers, including 4 spacious ones that open wide, providing ample room for your belongings and making it easy to access and organize your items.
- **Convenient Charging Station:** A built-in charging station with plugs and USB ports allows for easy charging of electronic devices, providing added convenience without sacrificing style.
- **Durable Construction:** Crafted from high-quality MDF, this dresser is easy to clean and maintain, ensuring durability and a long-lasting presence in your home.
- **Elegant Timelessness:** This dresser's classic design, accented by beveled edges and a curved kickboard, infuses sophistication into your home. Its simple installation ensures a swift setup, making it an instant upgrade to any room's aesthetic.
- **Multi-Purpose Design:** This chest dresser serves as both a TV Stand and a stylish display surface, perfect for your

bedroom or living room, enhancing the aesthetic while keeping clutter at bay.



Image: The dresser functioning as a TV stand, demonstrating its multi-purpose design.

3. Setup and Assembly

Assembly of the LIKIMIO 8-Drawer Dresser is required. Please follow the included instruction manual carefully. It is recommended to have two people for assembly to ensure stability and ease of construction. All necessary hardware and tools are typically provided.

Assembly Steps (General Guidelines):

1. **Unpack and Verify:** Carefully unpack all components and compare them against the parts list in your instruction manual to ensure nothing is missing or damaged.
2. **Prepare Workspace:** Choose a clean, flat, and spacious area for assembly to prevent scratching or damaging the parts.

3. **Assemble Frame:** Begin by assembling the main frame of the dresser according to the step-by-step diagrams. Ensure all connections are secure.
4. **Install Drawer Slides:** Attach the drawer slides to the dresser frame and the drawer sides, paying close attention to their orientation (left/right, top/bottom).
5. **Construct Drawers:** Assemble each drawer box. Attach the drawer fronts and handles securely.
6. **Insert Drawers:** Carefully slide the assembled drawers into their respective slots on the dresser frame.
7. **Install Charging Station:** Integrate the charging station into the designated slot on the dresser top.
8. **Attach Storage Bag:** Secure the fabric storage bag to the side of the dresser as indicated in the manual.
9. **Final Checks:** Ensure all screws are tightened, drawers slide smoothly, and the dresser is stable.



Image: An illustration showing various components of the dresser, indicating parts for assembly.

4. Operating Instructions

Using the Drawers:

The dresser features eight drawers designed for smooth operation. To open a drawer, gently pull the handle. To close, push the drawer firmly until it is fully seated. Avoid overloading drawers to ensure smooth gliding and prevent damage to the slides.



Image: The dresser with several drawers partially open, illustrating the ample storage space available.

Utilizing the Charging Station:

The integrated charging station provides convenient access to power for your electronic devices. Simply plug the dresser's power cord into a standard wall outlet. Use the available AC outlets and USB ports to charge your phones, tablets, or other compatible devices. Ensure devices are properly connected to avoid damage.



Image: A detailed view of the charging station, highlighting the power outlets and USB ports.

Using the Storage Bag:

The removable fabric storage bag attached to the side of the dresser is ideal for organizing smaller items such as magazines, remote controls, or personal accessories. Simply place items into the bag for easy access and clutter reduction.

5. Maintenance and Care

To ensure the longevity and appearance of your LIKIMIO dresser, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the dresser surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the

wood finish.

- **Heat and Moisture:** Keep the dresser away from direct heat sources and areas of high humidity to prevent warping or cracking.
- **Hardware:** Periodically check and tighten all screws and hardware to maintain stability and prevent wobbling.

6. Troubleshooting

If you encounter any issues with your LIKIMIO dresser, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Drawers do not slide smoothly or get stuck.	Misaligned drawer slides, loose hardware, overloaded drawer.	Check that drawer slides are correctly installed and aligned. Tighten all screws on the slides and drawer boxes. Reduce the weight in the drawer.
Dresser wobbles or feels unstable.	Loose assembly screws, uneven floor.	Ensure all assembly screws are fully tightened. Use furniture pads or shims under the legs to level the dresser on uneven surfaces.
Charging station not working.	Not plugged in, power outlet issue, damaged cable.	Verify the dresser's power cord is securely plugged into a working wall outlet. Test the outlet with another device. Inspect the charging station cable for any visible damage.
Drawers do not close flush.	Drawer slides not fully extended or misaligned, obstruction.	Ensure nothing is obstructing the drawer's path. Check the alignment of the drawer slides and adjust if necessary. Make sure the drawer is not overloaded.

7. Product Specifications

Attribute	Detail
Brand	LIKIMIO
Model Name	HK-DCD-03
Product Dimensions	15.8"D x 59.1"W x 31.5"H
Color	Black
Mounting Type	Freestanding
Room Type	Bedroom, Living Room, Entryway, Hallway
Special Feature	8 drawers dresser, Built-in Charging Station
Assembly Required	Yes
Item Weight	108.5 Pounds
UPC	788046970517

Attribute	Detail
Manufacturer	LIKIMIO
Date First Available	October 15, 2024



Image: Detailed diagram showing the dimensions of the LIKIMIO 8-Drawer Dresser.

8. Warranty and Support

LIKIMIO is committed to providing high-quality products. While specific warranty details are not provided in this manual, please retain your proof of purchase for any potential warranty claims. For product support, assembly assistance, or to report any issues, please contact LIKIMIO customer service through the retailer where the product was purchased.
This product is eligible for 30-day easy returns through Amazon.com. For further assistance, please refer to the customer support options provided by your retailer.

© 2025 LIKIMIO. All rights reserved.