EUHOMY Countertop Ice Maker Machine with Handle

EUHOMY Countertop Ice Maker Machine User Manual

Model: Countertop Ice Maker Machine with Handle

Brand: EUHOMY

1. Product Overview

The EUHOMY Countertop Ice Maker Machine is designed to produce bullet-shaped ice cubes quickly and efficiently. This package also includes EUHOMY Ice Maker Cleaner & Descaler for optimal maintenance and performance.



Image 1.1: The EUHOMY Countertop Ice Maker Machine shown alongside the EUHOMY Ice Machine Cleaner & Descaler packets. The ice maker is silver with a clear lid, and the cleaner comes in individual blue packets.

The ice maker can produce 9 bullet-shaped ice cubes in approximately 6 minutes and has a daily ice production capacity of up to 26.3 lbs. It features a 1.2L water tank and can hold up to 1.3 lbs of ice at a time. The included cleaner is made of 100% Pure Non-GMO Citric Acid, formulated to safely remove scale and residue, ensuring the longevity and efficiency of your ice maker.

2. Safety Instructions

- Read all instructions before operating the appliance.
- Ensure the ice maker is placed on a stable, level surface away from direct sunlight and heat sources.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the ice maker from the power outlet before cleaning or when not in use.
- Keep children away from the ice maker during operation.

- Use only potable water in the water tank.
- Do not block ventilation openings.
- Only use the provided power cord.

3. Product Components

The EUHOMY Countertop Ice Maker Machine package typically includes the following:

- EUHOMY Countertop Ice Maker Machine
- Ice Basket
- Ice Scoop
- EUHOMY Ice Maker Cleaner & Descaler packets (24 uses)
- User Manual (this document)

4. Setup

4.1 Unpacking and Placement

1. Carefully remove all packaging materials.
2. Place the ice maker on a flat, stable surface. Ensure there is at least 4 inches (10 cm) of space around the unit for proper ventilation.
3. Clean the interior of the ice maker with a soft cloth and warm water before first use.

4.2 Initial Use

1. Open the lid and remove the ice basket.
2. Fill the water reservoir with potable water up to the MAX fill line. Do not overfill.
3. Replace the ice basket and close the lid.
4. Plug the ice maker into a grounded electrical outlet.
5. Press the "ON/OFF" button to start the ice making cycle. The indicator light will illuminate.
6. Discard the first 2-3 batches of ice to ensure cleanliness.

5. Operating Instructions

5.1 Making Ice

- Ensure the water reservoir is filled.
- Press the "ON/OFF" button. The ice maker will begin the ice production cycle.
- Ice cubes will be dispensed into the ice basket. The "ICE FULL" indicator light will turn on when the basket is full.
- If the "ADD WATER" indicator light flashes, it means the water level is low. Add more water to the reservoir.

5.2 Control Panel Indicators

- **ON/OFF:** Powers the unit on or off.
- **ICE FULL:** Illuminates when the ice basket is full, pausing ice production.

- **ADD WATER:** Flashes when the water reservoir needs refilling.
- **ICE/CLEAN:** Press for 3 seconds to activate the auto-cleaning function.

6. Maintenance

6.1 Regular Cleaning

- Unplug the ice maker before cleaning.
- Remove the ice basket and clean it with mild detergent and warm water. Rinse thoroughly.
- Wipe the interior and exterior of the ice maker with a soft, damp cloth.
- Ensure all parts are dry before reassembling and storing.

6.2 Auto-Cleaning Function

1. Ensure the ice maker is empty of ice and water.
2. Fill the water reservoir with clean water up to the MAX line.
3. Press and hold the "ICE/CLEAN" button for 3 seconds. The unit will enter a 30-minute automatic cleaning cycle.
4. Once the cycle is complete, drain the water from the reservoir by unplugging the drain plug at the bottom of the unit.
5. Rinse the interior with fresh water and drain again.

6.3 Descaling with EUHOMY Ice Maker Cleaner

Regular descaling is crucial to remove mineral buildup and maintain optimal performance and ice quality. Use the provided EUHOMY Ice Maker Cleaner & Descaler packets.

1. Ensure the ice maker is empty and unplugged.
2. Dissolve one packet of EUHOMY Ice Maker Cleaner & Descaler in approximately 1.2 liters of warm water.
3. Pour the solution into the water reservoir.
4. Plug in the ice maker and activate the auto-cleaning function (refer to 6.2).
5. After the cleaning cycle, drain the solution completely.
6. Rinse the reservoir and interior thoroughly with fresh water multiple times to remove any cleaner residue. Drain completely after each rinse.
7. Perform a final auto-cleaning cycle with fresh water only.

7. Troubleshooting

Problem	Possible Cause	Solution
Ice maker not turning on.	Not plugged in; power outage; faulty outlet.	Ensure unit is securely plugged in. Check power supply. Try a different outlet.
"ADD WATER" indicator flashing.	Water reservoir is empty or low.	Add potable water to the reservoir up to the MAX fill line.
"ICE FULL" indicator on, but basket not full.	Ice sensor is dirty or obstructed.	Clean the ice sensor with a soft cloth. Ensure ice is not blocking the sensor.

Problem	Possible Cause	Solution
Ice cubes are small or clumpy.	Water temperature too high; mineral buildup.	Use colder water. Perform a descaling cycle using EUHOMY Ice Maker Cleaner.
Unusual noise during operation.	Unit not level; internal component issue.	Ensure the ice maker is on a level surface. If noise persists, contact customer support.

8. Specifications

Feature	Detail
Model Name	Countertop Ice Maker Machine with Handle
Product Dimensions	9.25"D x 11.54"W x 11.61"H
Daily Ice Capacity	26.3 lbs (approx.)
Ice Production Time (per batch)	6 minutes (approx. for 9 cubes)
Water Tank Capacity	1.2 Liters
Ice Storage Capacity	1.3 lbs (approx.)
Wattage	170 watts
Noise Level	Under 45 dB
Cleaner Type	100% Pure Non-GMO Citric Acid

9. Warranty and Support

EUHOMY products are designed for reliability and performance. For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official EUHOMY website. Please have your model number and purchase date available when contacting support.

For further assistance, you may contact EUHOMY customer service through their official channels. Always ensure you are using official contact methods for support.

© 2024 EUHOMY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question