Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PIONOUS F166500

PIONOUS F166500 Black Toner Cartridge Instruction Manual

Model: F166500

Introduction

This manual provides essential instructions for the safe and effective use of your PIONOUS F166500 Black Toner Cartridge. Please read this manual thoroughly before installation and retain it for future reference. This cartridge is designed to deliver high-quality, consistent print results for compatible F166500 printers.

Safety Information

- Keep toner cartridges out of reach of children.
- Do not ingest toner powder. If swallowed, seek immediate medical attention.
- Avoid direct contact with toner powder. If toner gets on your skin or clothing, wash thoroughly with soap and cold water. Hot water may set the toner.
- Do not incinerate used toner cartridges. Residual toner powder may ignite, causing burns or fire.
- Store cartridges in a cool, dry place, away from direct sunlight and extreme temperatures.
- Handle cartridges carefully to prevent damage to the drum or other components.

Package Contents

Verify that your package contains the following items:

- 1 x PIONOUS F166500 Black Toner Cartridge



Image: The PIONOUS F166500 Black Toner Cartridge shown within its retail packaging, indicating the product and its box.

Compatible Printers

This PIONOUS F166500 Black Toner Cartridge is compatible with the following printer model:

- F166500 Printer



Image: A graphic displaying the text "Compatible printer models" and "F166500 Printer", confirming compatibility.

Setup and Installation

Follow these steps to install the toner cartridge into your printer:

1. **Power Off Printer:** Ensure your printer is turned off and unplugged before beginning installation.
2. **Open Printer Cover:** Open the front cover or access panel of your F166500 printer to expose the toner cartridge slot.
3. **Remove Old Cartridge (if applicable):** Carefully remove the old toner cartridge by pulling it straight out. Place it in a protective bag for recycling.
4. **Unpack New Cartridge:** Remove the new PIONOUS F166500 toner cartridge from its packaging.
5. **Gently Shake Cartridge:** Gently rock the cartridge horizontally 5-6 times to distribute the toner evenly inside.
6. **Remove Protective Seal:** Pull the protective sealing tape (if present) completely off the cartridge. Do not touch the drum surface.
7. **Insert New Cartridge:** Align the new cartridge with the guides inside the printer and push it firmly until it clicks into place.

8. **Close Printer Cover:** Close the printer cover or access panel.
9. **Power On Printer:** Plug in and power on your printer. The printer will typically perform a self-test.



Image: A PIONOUS F166500 toner cartridge positioned next to a compatible F166500 printer, illustrating the cartridge's readiness for installation.

Operating Instructions

Once installed, the PIONOUS F166500 toner cartridge operates automatically with your compatible printer. For optimal performance:

- **Print Quality:** This cartridge is designed to produce sharp text and clear graphics. If print quality degrades, refer to the troubleshooting section.
- **Page Yield:** The cartridge is rated for approximately 2,600 pages at 5% coverage. Actual page yield may vary based on print content, paper type, and environmental conditions.
- **Printer Software:** Utilize your printer's software for monitoring toner levels and adjusting print settings as needed.



Image: A visual representation highlighting the high page yield capability of 2,600 pages for the PIONOUS F166500 toner cartridge.

Maintenance

Minimal maintenance is required for the toner cartridge itself. For best results:

- **Storage:** Store unopened cartridges in their original packaging in a cool, dry place.
- **Printer Cleaning:** Regularly clean your printer according to its manufacturer's instructions to prevent dust and toner buildup, which can affect print quality.
- **Recycling:** When the cartridge is empty, dispose of it responsibly. Many manufacturers and retailers offer recycling programs for used toner cartridges.

Troubleshooting

If you encounter issues with your PIONOUS F166500 toner cartridge, consider the following:

Problem	Possible Cause	Solution
Poor Print Quality (faded, streaks, spots)	◦ Low toner level ◦ Uneven toner distribution ◦ Dirty printer components ◦ Damaged cartridge drum	◦ Gently rock the cartridge to redistribute toner. ◦ Replace the cartridge if toner is low. ◦ Clean the printer's internal components as per your printer manual. ◦ Ensure no protective seals remain on the cartridge.
"Cartridge Not Recognized" Error	◦ Cartridge not seated correctly ◦ Dirty electrical contacts	◦ Remove and reinsert the cartridge firmly. ◦ Clean the cartridge's electrical contacts and the printer's corresponding contacts with a lint-free cloth. ◦ Restart the printer.
Paper Jams	◦ Incorrect paper loading ◦ Paper type incompatibility ◦ Debris in paper path	◦ Refer to your printer manual for clearing paper jams. ◦ Ensure paper is loaded correctly and is compatible with your printer.

For further assistance, consult your printer's user manual or contact PIONOUS customer support.

Specifications

Feature	Detail
Model Number	F166500
Color	Black
Page Yield	Approx. 2,600 pages (at 5% coverage)
Special Feature	Spherical Toner for Sharp, Non-Fading Printouts
Item Weight	1.43 pounds
Product Dimensions	1 x 1 x 1 inches
Manufacturer	PIONOUS

Warranty and Support

PIONOUS is committed to providing high-quality products. For information regarding warranty coverage, returns, or technical support, please refer to the contact information provided with your purchase or visit the official PIONOUS website. Please have your product model number (F166500) and purchase details ready when contacting support.

© 2025 PIONOUS. All rights reserved.
This manual is for informational purposes only. PIONOUS reserves the right to make changes to product specifications without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DK4ZVF1F

More documents and user manuals: **https://manuals.plus/**