PULIVIA PL-802-black

PULIVIA Digital Stopwatch User Manual

Model: PL-802-black | Brand: PULIVIA

1. Introduction

The PULIVIA Digital Stopwatch is a versatile and professional timing device designed for athletes, coaches, referees, and anyone needing precise timekeeping. It is suitable for various sports activities including running, swimming, and football training. This manual will guide you through the features, setup, operation, and maintenance of your new stopwatch.



Image: Front view of the PULIVIA Digital Stopwatch, showing the display and attached lanyard.

2. Key Features

Your PULIVIA Digital Stopwatch comes equipped with several useful functions:

- **1/100-Second Accuracy:** Provides precise timing for competitive events.
- **Lap/Split Stopwatch:** Allows for recording multiple lap times and split times during an event.
- **Date/Clock/Alarm:** Functions as a daily clock with calendar display and an alarm feature.
- **Large Display:** Features a clear, easy-to-read digital display.
- **Durable Design:** Built to be shockproof and comfortable for handheld use.
- **Lanyard Included:** Comes with a 47-inch nylon lanyard for convenient carrying.



Image: Illustration highlighting the multi-functionality of the stopwatch, including stopwatch, clock/calendar, and alarm features.

3. Package Contents

Please check the package to ensure all items are present:

- 1 x PULIVIA Digital Stopwatch (Model: PL-802-black)
- 1 x Black Nylon Lanyard
- 1 x User Manual (this document)

4. Product Overview

Familiarize yourself with the physical components of your stopwatch:

- **Display:** Large LCD screen showing time, date, and stopwatch readings.
- **START/STOP Button:** Typically located on the right side, used to start and stop the timer.
- **SPLIT/RESET Button:** Typically located on the left side, used to record split times or reset the timer.

- **MODE Button:** Used to switch between different modes (Time, Stopwatch, Alarm, Calendar).
- **Lanyard Attachment Point:** Located at the top for securing the nylon lanyard.



Image: The stopwatch with indicated dimensions (7.5cm height, 5.8cm width) and weight (40g/1.4oz), highlighting its comfortable handheld size.

5. Setup

5.1 Initial Use

Upon first use, you may notice a protective film on the display. This is to prevent scratches during shipping. Gently peel off this screen protector for optimal display clarity.



Image: A hand demonstrating the removal of the protective screen film from the stopwatch display.

6. Operating Instructions

6.1 Switching Modes

Press the **MODE** button to cycle through the different functions: Time Mode, Stopwatch Mode, Alarm Mode, and Calendar Mode.

6.2 Time Mode (Clock & Calendar)

In Time Mode, the display shows the current time, day of the week, month, and date. To set the time and date:

1. From Time Mode, press and hold the **SPLIT/RESET** button until the seconds start flashing.
2. Press the **START/STOP** button to adjust the flashing value (seconds, minutes, hours, day, month, year).
3. Press the **MODE** button to move to the next setting.
4. Once all settings are adjusted, press **SPLIT/RESET** again to confirm and exit setting mode.
5. To switch between 12-hour and 24-hour format, press the **START/STOP** button while in Time Mode (not in setting mode).

6.3 Stopwatch Mode

This mode is used for timing events with 1/100-second accuracy.

1. Switch to Stopwatch Mode using the **MODE** button. The display will show 0:00:00.
2. Press **START/STOP** to begin timing.
3. To record a split time (lap time), press **SPLIT/RESET** while the stopwatch is running. The display will show the split time, while the internal timer continues. Press **SPLIT/RESET** again to return to the running time.
4. Press **START/STOP** again to pause the timer.
5. With the timer paused, press **SPLIT/RESET** to reset the stopwatch to 0:00:00.

6.4 Alarm Mode

To set and activate the alarm:

1. Switch to Alarm Mode using the **MODE** button.
2. Press and hold the **SPLIT/RESET** button until the alarm hour flashes.
3. Use the **START/STOP** button to adjust the hour.
4. Press **MODE** to move to the minutes, then use **START/STOP** to adjust.

5. Press **SPLIT/RESET** to confirm and exit setting mode.
6. To turn the alarm ON/OFF, press the **START/STOP** button while in Alarm Mode (not in setting mode). An alarm icon will appear/disappear on the display.



Image: The stopwatch being used in various sports training scenarios, including running, swimming, soccer, cycling, and basketball.



Image: A coach using the stopwatch during a training session, emphasizing its utility for coaching.



Image: The stopwatch being used to time swimming training, demonstrating its application in aquatic sports.

7. Maintenance

To ensure the longevity and optimal performance of your PULIVIA Digital Stopwatch, follow these maintenance guidelines:

- **Cleaning:** Wipe the stopwatch with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the device.
- **Water Resistance:** The stopwatch is water-resistant to dripping, splashing, and sweat.**It is NOT waterproof.** Do not immerse the stopwatch in water, expose it to heavy rain, or use it for swimming or diving.
- **Storage:** Store the stopwatch in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery:** The stopwatch uses a standard button cell battery. If the display becomes dim or unresponsive, the battery may need replacement. Consult a professional for battery replacement to avoid damaging the device.



Image: The stopwatch with graphic elements suggesting its shockproof and durable construction.

8. Troubleshooting

If you encounter any issues with your stopwatch, please refer to the following common problems and solutions:

- **Display is blank or dim:** The battery may be low or depleted. Replace the battery.
- **Buttons are unresponsive:** Ensure the stopwatch is not in a locked mode (if applicable, though this model typically does not have a lock). Try resetting the device by removing and reinserting the battery (consult a professional).
- **Incorrect time/date:** Follow the instructions in Section 6.2 to reset the time and date.
- **Stopwatch not starting/stopping:** Ensure you are pressing the correct **START/STOP** button firmly.

If the problem persists after attempting these solutions, please contact customer support.

9. Technical Specifications

Feature	Specification
Model Name	stopwatch (PL-802-black)
Brand	PULIVIA
Color	Black
Material	Nylon
Product Dimensions (D x W x H)	0.7" x 2.5" x 3.1"
Item Weight	40 Grams (1.4 oz)
Accuracy	1/100-second
Functions	Stopwatch (Lap/Split), Clock, Calendar, Alarm
Power Source	Button Cell Battery (not user-replaceable)
UPC	763971490255

10. Warranty and Customer Support

PULIVIA is committed to providing high-quality products and excellent customer service. While specific warranty details are not provided in this manual, if you encounter any issues or have questions regarding your stopwatch, please do not hesitate to contact us.

We offer 7 days/24 hours customer service. Please contact us via Amazon email for assistance.

Thank you for choosing PULIVIA.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I turn off the hourly beep on the PULIVIA PL-802-black stopwatch when the alarm icon is not visible?

To turn off the hourly beep (chime) on the PULIVIA PL-802-black (and similar YS-802 models), follow these steps while in the standard Time Mode:Press and hold the SPLIT/RESET button (left side).While holding SPLIT/RESET, press...

Read full answer

How do I install or replace the battery in the PULIVIA PL-802-black Digital Stopwatch?

The PULIVIA PL-802-black Digital Stopwatch uses a standard button cell battery. According to the manufacturer's manual, the battery is considered not user-replaceable.If the display becomes dim, blank, or unresponsive, the manual recommends the following:Consult...

Read full answer