Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vieta Pro Match 3

Vieta Pro Match 3 True Wireless Sport Earbuds User Manual

Model: Match 3 (VHP-TW71BK)

1. Introduction

Thank you for choosing the Vieta Pro Match 3 True Wireless Sport Earbuds. This manual provides essential information for the proper setup, operation, and maintenance of your earbuds. Please read it carefully before use to ensure optimal performance and longevity of your device.

2. Package Contents

- Vieta Pro Match 3 True Wireless Sport Earbuds
- Charging Case
- USB-C Charging Cable (not explicitly listed but implied by 'USB-C fast charging')
- User Manual

3. Product Overview

The Vieta Pro Match 3 earbuds are designed for active lifestyles, featuring secure ear hooks, Active Noise Cancellation (ANC), Transparency Mode, and IPX5 water resistance.



Image: Vieta Pro Match 3 earbuds and charging case, open to show both earbuds.



Image: An earbud in its charging case, illustrating key features like Bluetooth 5.3, 22h battery, ANC, and IPX5.



Image: Detailed view of a single earbud, highlighting the integrated ear hook for secure fit.

4. Setup

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated; the indicator lights on the earbuds will confirm charging.
2. Connect the USB-C charging cable to the charging port on the case and plug the other end into a USB power source (e.g., wall adapter, computer USB port).
3. The indicator lights on the charging case will show the charging status. Once fully charged, the lights will indicate completion or turn off.

A full charge provides up to 22 hours of total playback time with the charging case.



Image: Illustration of the 22-hour battery life and Bluetooth connectivity with a smartphone.

4.2 Bluetooth Pairing

To connect your earbuds to a device:

1. Open the charging case. The earbuds will automatically enter pairing mode, indicated by flashing lights (refer to specific light patterns in the quick start guide if available).
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for new devices.
3. Select "Vieta Pro Match 3" from the list of available devices.
4. Once connected, a voice prompt will confirm successful pairing, and the earbud indicator lights will change (e.g., turn off or solid blue).

The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

5. Operation

5.1 Power On/Off

- **Power On:** Open the charging case, and the earbuds will power on automatically. Alternatively, press and hold the touch control area on both earbuds for approximately 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will power off automatically. Alternatively, press and hold the touch control area on both earbuds for approximately 5 seconds.

5.2 Wearing the Earbuds

For optimal sound quality and a secure fit, especially during sports, ensure the earbuds are worn correctly.

1. Identify the left (L) and right (R) earbuds.
2. Gently insert the earbud into your ear canal.
3. Position the ear hook over the top of your ear, adjusting it for a snug and comfortable fit.



Image: Proper wearing of the earbud with the ear hook for a secure fit.

5.3 Touch Controls

The earbuds feature touch-sensitive controls on the outer surface of each earbud. Specific functions may vary slightly; refer to the quick start guide for precise commands.

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.

- **Reject Call:** Press and hold on either earbud for 2 seconds.
- **Activate Voice Assistant:** Press and hold on either earbud for 3 seconds (when not on a call).
- **ANC/Transparency Mode Switch:** Press and hold on the left earbud for 2 seconds to cycle through ANC, Transparency Mode, and Normal Mode.

5.4 Active Noise Cancellation (ANC) and Transparency Mode

The Vieta Pro Match 3 earbuds offer advanced audio modes:

- **Active Noise Cancellation (ANC):** Reduces external ambient noise by up to -25dB, allowing for a more immersive listening experience. Ideal for noisy environments.
- **Transparency Mode:** Allows ambient sounds to pass through, enabling you to hear your surroundings without removing the earbuds. Useful for awareness in urban environments or during conversations.

To switch between modes, use the designated touch control (typically press and hold the left earbud for 2 seconds).



Image: Visual representation of Active Noise Cancellation (ANC) in action, showing sound waves being suppressed.

6. Maintenance

6.1 Cleaning

Regular cleaning helps maintain sound quality and hygiene.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- For ear tips, remove them from the earbuds and clean with a mild soap solution if necessary, then rinse and dry thoroughly before reattaching.
- Do not use harsh chemicals, aerosols, or abrasive cleaners.

6.2 Water Resistance (IPX5)

The earbuds are rated IPX5, meaning they are resistant to water jets from any direction. This makes them suitable for workouts and light rain. However, they are not designed for submersion in water. Do not expose them to swimming, showering, or heavy rain.

6.3 Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

7. Troubleshooting

If you encounter issues, try the following solutions:

- **No Sound:** Ensure earbuds are charged, paired correctly, and volume is up on both the earbuds and your device.
- **Pairing Issues:** Turn off Bluetooth on your device, then turn it back on. Forget the device in your Bluetooth settings and attempt to re-pair. Ensure earbuds are in pairing mode.
- **One Earbud Not Working:** Place both earbuds back in the case, close the lid, wait a few seconds, then take them out again. This can resynchronize them.
- **Charging Problems:** Check the USB-C cable and power source. Ensure the charging contacts on the earbuds and case are clean and free of debris.
- **ANC Not Effective:** Ensure earbuds are properly seated in your ears to create a good seal. Cycle through ANC modes using the touch control.

7.1 Factory Reset

If problems persist, a factory reset may resolve them. Consult the quick start guide or manufacturer's website for specific reset instructions for the Vieta Pro Match 3 model.

8. Specifications

Model Name	Match 3
Model Number	VHP-TW71BK
Bluetooth Version	5.3
Active Noise Cancellation (ANC)	-25dB
Battery Life (Earbuds + Case)	Up to 22 hours
Water Resistance Rating	IPX5
Frequency Range	20 Hz to 20,000 Hz
Impedance	32 Ohm
Control Method	Touch
Material	Plastic

9. Warranty and Support

For warranty information, technical support, or further assistance, please refer to the official Vieta Pro website or contact their customer service. Keep your proof of purchase for warranty claims.

© 2025 Vieta Pro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DK79NFZJ

More documents and user manuals: **https://manuals.plus/**