Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Transformers G0485

Transformers Studio Series Dinobot Grimlock (G0485) Instruction Manual

Leader Class 8.5-Inch Converting Action Figure

Overview Setup Transformation Maintenance Troubleshooting Specifications Safety Information

1. Product Overview

The Transformers Studio Series Dinobot Grimlock action figure is a Leader Class collectible, standing 8.5 inches (21.5 cm) tall in robot mode. This figure converts between robot and dinosaur modes in 24 steps and includes a non-converting Autobot Wheelie mini action figure.

What's in the Box:

- Dinobot Grimlock Figure
- Autobot Wheelie Mini Figure
- Blaster Accessory

2. Initial Setup

Carefully remove all components from the packaging. Ensure all parts listed in the 'What's in the Box' section are present. No assembly is required beyond transformation.



Image: Dinobot Grimlock figure and accessories shown in its retail packaging.

3. Transformation Instructions

The Dinobot Grimlock figure converts between robot and dinosaur modes in 24 steps. Follow these instructions carefully to avoid damage to the figure.

3.1. Robot Mode



Image: Dinobot Grimlock in its robot form, holding a blaster accessory. The Autobot Wheelie mini figure is positioned near its feet.

In robot mode, Grimlock stands at 8.5 inches (21.5 cm) tall. The figure features multiple points of articulation for dynamic posing. The included blaster accessory can be held in either hand. The Autobot Wheelie mini figure can be placed on Grimlock's shoulder or hand in this mode.

3.2. Converting to Dinosaur Mode (24 Steps)

To convert Grimlock from robot to dinosaur mode, follow the steps outlined in the included visual guide (refer to the back of the packaging for a general overview, or detailed instructions if provided separately). The process involves folding and rotating various panels and limbs to form the Tyrannosaurus Rex mode.



Image: The back of the product packaging, illustrating Dinobot Grimlock in both robot and dinosaur modes, highlighting the 24 transformation steps.

Key Transformation Points:

1. Begin by detaching any accessories.
2. Fold the robot's arms and legs into the designated positions.
3. Rotate the torso and head to align with the dinosaur form.
4. Secure all panels and tabs firmly to ensure the dinosaur mode holds together.

3.3. Dinosaur Mode

Image: Dinobot Grimlock in its dinosaur (Tyrannosaurus Rex) form, with the Autobot Wheelie mini figure seated on its back.

In dinosaur mode, Grimlock takes the form of a powerful Tyrannosaurus Rex. The Autobot Wheelie mini figure can be securely placed on Grimlock's back in this mode.

4. Care and Maintenance

To maintain the condition of your figure:

- **Cleaning:** Wipe the figure with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the paint or plastic.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight and extreme temperatures to prevent discoloration or warping.
- **Handling:** Handle the figure by its main body parts during transformation to avoid stressing smaller joints or accessories.

5. Troubleshooting

If you encounter any issues with your Dinobot Grimlock figure, consider the following:

- **Parts not aligning during transformation:** Ensure all previous steps have been completed correctly. Gently re-align parts without forcing them. Refer to the visual guide for specific step-by-step assistance.
- **Loose joints:** Over time, joints may become slightly loose with repeated use. This is normal wear and tear.
- **Missing accessories:** Check the packaging thoroughly. If an accessory is genuinely missing upon purchase, contact customer support.

6. Product Specifications

Model Number	G0485
Product Dimensions	9.02 x 4.02 x 10 inches
Item Weight	1.17 pounds
Recommended Age	8 years and up
Transformation Steps	24
Manufacturer	Hasbro

7. Safety Information

WARNING: CHOKING HAZARD
Small parts may be generated. Not for children under 3 years. Adult supervision is recommended for younger users (8+).

8. Customer Support and Warranty

For product support, missing parts, or warranty inquiries, please contact Hasbro customer service. Refer to the official Hasbro website or product packaging for the most current contact information.
This product is covered by standard manufacturer warranties. Please retain your proof of purchase for any warranty claims.

© 2025 Hasbro, Inc. All Rights Reserved. TRANSFORMERS and HASBRO and all related trademarks and logos are trademarks of Hasbro, Inc.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DK7YBH7T

More documents and user manuals: **https://manuals.plus/**