BesLowe A923

BesLowe A923 Motion Sensor Outdoor Wall Lights Instruction Manual

Model: A923 | Brand: BesLowe

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your BesLowe A923 Motion Sensor Outdoor Wall Lights. These fixtures are designed to provide intelligent, energy-efficient illumination for outdoor spaces such as porches, patios, garages, and entryways. Please read this manual thoroughly before installation and retain it for future reference.



Image 1.1: Two BesLowe A923 bronze outdoor wall lights, showcasing their modern design and integrated motion sensors.

2. Safety Information

WARNING: Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation or servicing. All wiring connections must be in accordance with local and national electrical codes. If you are unfamiliar with electrical wiring, consult a qualified electrician.

- Ensure the power supply is turned off before beginning installation.
- Use only bulbs specified for this fixture (E26 base, 100W Max).
- Do not exceed the maximum wattage.
- Handle glass components with care to prevent breakage.
- Keep children away from the installation area.

3. Package Contents

Verify that all components are present before installation:

- BesLowe A923 Outdoor Wall Light Fixtures (2 units)
- Mounting Hardware (screws, wire nuts, mounting plate)
- Instruction Manual

Note: E26 base bulbs are not included and must be purchased separately.

4. Product Features

- **Advanced Motion and Photocell Sensors:** Integrated PIR motion sensor detects movement, and a photocell sensor detects ambient light levels for automatic operation.
- **3 Lighting Modes:** Offers Dual-bright, ON/OFF, and Manual Override modes to suit various needs.
- **Easy Mode Switching:** Features a simplified one-press method for changing lighting modes.
- **Adjustable Low Brightness:** In Dual-bright mode, the low brightness can be adjusted from 15% to 50%.
- **All-Weather Resistant:** Constructed from durable metal and sturdy glass to withstand rain, heat, storms, and snow.
- **E26 Base Socket:** Compatible with standard E26 base bulbs (100W Max).



Image 4.1: Comparison highlighting the sleek and discreet design of the BesLowe A923's motion sensor.

5. Installation Guide

The BesLowe A923 outdoor wall light is designed for easy installation. It comes pre-assembled with all necessary mounting hardware.

Tools Required (Not Included):

- Screwdriver (Phillips and Flathead)
- Wire Strippers
- Pliers
- Electrical Tape
- Safety Glasses

Installation Steps:

1. **Turn Off Power:** Locate the circuit breaker or fuse box and turn off the power to the junction box where the fixture will be installed.
2. **Prepare Mounting Plate:** Attach the mounting plate to the junction box using the provided screws. Ensure it is securely fastened.
3. **Make Electrical Connections:** Connect the fixture's wires to the house wires using the provided wire nuts.
    - Connect the black wire (live) from the fixture to the black wire from the junction box.
    - Connect the white wire (neutral) from the fixture to the white wire from the junction box.
    - Connect the green or bare copper wire (ground) from the fixture to the ground wire from the junction box.

    Ensure all connections are tight and secure. Wrap wire nuts with electrical tape for added safety.
4. **Mount the Fixture:** Carefully align the fixture with the mounting plate and secure it with the provided screws.
5. **Install Bulb:** Insert an E26 base bulb (not included, 100W Max) into the socket. Dimmable LED or incandescent bulbs are recommended for optimal performance in Dual-bright mode. The open-bottom design allows for easy bulb installation.
6. **Restore Power:** Turn the power back on at the circuit breaker or fuse box.



Image 5.1: Product dimensions for installation planning.

6. Operating Instructions

The BesLowe A923 features three distinct lighting modes, easily switchable with a single press on the integrated sensor button.

Mode Selection:

Press the sensor button located on the fixture to cycle through the modes:

- **Dual-bright Mode:** The light turns on at a low brightness (adjustable 15-50%) at dusk. When motion is detected, it brightens to 100% for a set duration, then returns to the low brightness. This mode is ideal for security and ambient lighting.
- **ON/OFF Mode:** The light remains off at dusk. When motion is detected, it turns on at 100% brightness for a set duration, then turns off completely. This mode is energy-saving and suitable for areas requiring light only when occupied.
- **Manual Override Mode:** To activate, quickly turn the wall switch 'off-on-off-on' within 2 seconds. The light will stay on

at 100% brightness for approximately 6-8 hours, then automatically revert to the previously selected motion sensor mode (Dual-bright or ON/OFF) at dawn. This mode is useful for extended periods of full illumination, such as during outdoor gatherings.



Image 6.1: Visual guide to the three lighting modes and their operation.

Adjusting Low Brightness (Dual-bright Mode Only):

While in Dual-bright mode, long-press the sensor button to adjust the low brightness level between 15%, 40% (default), and 50%. Release the button when the desired brightness is reached.



Image 6.2: Adjusting the low brightness setting in Dual-bright mode.

7. Maintenance

Regular maintenance ensures optimal performance and longevity of your outdoor wall lights.

- **Cleaning:** Clean the fixture periodically with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish or glass. Ensure the power is off before cleaning.
- **Bulb Replacement:** Due to the open-bottom design, bulb replacement is straightforward. Turn off power, unscrew the old E26 bulb, and screw in a new one (100W Max).
- **Weather Resistance:** The fixture is designed to be weather-resistant. However, inspect it occasionally for any signs of wear or damage, especially after severe weather conditions.



Image 7.1: The BesLowe A923 is built to withstand various weather conditions.

8. Troubleshooting

If you encounter issues with your BesLowe A923 lights, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on at night.	1. Power is off. 2. Bulb is faulty or not installed correctly. 3. Photocell sensor is obstructed or detecting too much light.	1. Check circuit breaker/fuse. 2. Replace bulb or ensure it's screwed in tightly. 3. Clear any obstructions from the sensor. Ensure the installation location is not affected by other light sources.

Problem	Possible Cause	Solution
Motion sensor not detecting movement.	1. Sensor is obstructed. 2. Sensor sensitivity is too low. 3. Incorrect mode selected.	1. Clear obstructions from the sensor lens. 2. Ensure the sensor is clean. The sensor sensitivity is fixed for optimal performance. 3. Ensure the light is in Dual-bright or ON/OFF mode.
Light stays on continuously.	1. Manual Override mode is active. 2. Constant motion detected. 3. Wiring issue.	1. Wait for 6-8 hours for Manual Override mode to expire, or cycle power to reset. 2. Ensure the sensor is not continuously triggered by moving objects (e.g., tree branches). 3. Consult a qualified electrician.
Light flickers or dims unexpectedly.	1. Loose wiring connection. 2. Incompatible bulb (for Dual-bright mode). 3. Faulty bulb.	1. Turn off power and check all wiring connections. 2. Ensure a dimmable LED or incandescent bulb is used for Dual-bright mode. 3. Replace the bulb.

9. Specifications

Feature	Detail
Brand	BesLowe
Model Name	A923
ASIN	B0DKF61KXN
Color	Bronze
Material	Glass, Metal
Style	Modern
Light Fixture Form	Sconce
Product Dimensions	5"L x 5"W x 13"H
Indoor/Outdoor Usage	Outdoor
Power Source	Hard-wired
Special Features	Motion Sensor, Waterproof
Voltage	120 Volts
Bulb Base	E26
Max Wattage	100W
Number of Items	2
Mounting Type	Wall Mount
Assembly Required	No (Pre-assembled)
Item Weight	8.45 pounds

10. Warranty and Support

Your BesLowe A923 Motion Sensor Outdoor Wall Lights come with an extended warranty. For specific warranty details, please refer to the warranty card included in your package or contact BesLowe customer service.
For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact BesLowe customer service through the retailer where the product was purchased or visit the official BesLowe website.
Contact Information:
Website: BesLowe Official Store on Amazon

© 2025 BesLowe. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question