**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### Xilecam M300D

# Xilecam Mini Action Cam 1080p (Model M300D) User Manual

## 1. Introduction

Thank you for choosing the Xilecam Mini Action Cam 1080p (Model M300D). This compact and versatile camera is designed for capturing your adventures and daily moments in 1080p resolution. Weighing only 26g and featuring a minimalist design, it offers easy portability and a range of mounting options. This manual provides essential information for setting up, operating, and maintaining your camera.




The Xilecam Mini Action Cam is remarkably small and lightweight, weighing only 26 grams.

### Key Features:

- **Portable Design:** Ultra-compact and lightweight (26g, 2.5 x 1.2 x 0.8 inches) for easy carrying.
- **1080p Video Recording:** Captures clear video at 1080p resolution.
- **Versatile Mounting:** Includes accessories for helmet, clip-on (360-degree rotation), and pet collar attachment. Features magnetic adhesion for metal surfaces.
- **Extended Battery Life:** Records continuously for up to 180 minutes on a full charge.
- **Expandable Storage:** Comes with a 32GB Micro SD card, supporting expansion up to 128GB.
- **Direct File Transfer:** Includes a multi-functional card reader for direct connection to Android smartphones.
- **1-inch HD Screen:** For basic viewing and operation.
- **Loop Recording:** Automatically saves videos in 5-minute segments with continuous loop recording.

## 2. What's in the Box

Verify that all items are present in your package:

- Xilecam Mini Action Cam (Model M300D)
- Accessory Kit (various mounts, clips, USB cable, card reader)
- 32GB Micro SD Card
- User Manual




The camera comes with a comprehensive accessory kit for diverse applications.

## 3. Product Overview

The Xilecam Mini Action Cam features a sleek, minimalist design with essential controls and a 1-inch HD screen for basic operation. Its compact form factor allows for discreet placement and easy handling.




The Xilecam Mini Action Cam is designed for simplicity and portability.

## Key Components:

- **Camera Lens:** Captures 1080p video.
- **1-inch HD Screen:** For status display and basic playback.
- **Micro SD Card Slot:** For memory card insertion.
- **USB Port:** For charging and data transfer.
- **Control Buttons:** For power and recording functions (specific button layout not detailed in product information, refer to included manual for exact button functions).
- **Integrated Clip:** Allows for easy attachment to clothing or backpacks, with 360-degree rotation.
- **Magnetic Base:** Enables attachment to metallic surfaces.




The integrated clip offers 360-degree rotation for optimal positioning.




The camera's magnetic base allows for secure attachment to metal surfaces.

## 4. Setup

### 4.1. Charging the Camera

1. Connect the camera to a USB power source (e.g., computer, wall adapter) using the provided USB cable.
2. The charging indicator light will illuminate.
3. Once fully charged (approximately 180 minutes of recording time), the indicator light may change or turn off.

### 4.2. Inserting the Micro SD Card

The camera requires a Micro SD card (Class 10, U1, V10 recommended) for storing recordings. A 32GB card is included, and the camera supports up to 128GB.

1. Locate the Micro SD card slot on the camera.
2. Gently insert the Micro SD card into the slot with the gold contacts facing the correct direction (refer to the camera's markings).

3. Push the card in until you hear a soft "click," indicating it is securely locked in place.
4. To remove the card, gently push it in again until you hear a "click," and it will spring out.

## 4.3. Attaching Accessories

The camera comes with various accessories for flexible mounting:

- **Back Clip:** Use the integrated clip to attach the camera to clothing, backpacks, or other fabric edges. The clip rotates 360 degrees for optimal angle adjustment.
- **Helmet Mounts:** Utilize the provided helmet mounts to securely attach the camera to helmets for action sports.
- **Pet Collar Mount:** Attach the camera to your pet's collar using the dedicated mount to capture their unique perspective.
- **Magnetic Adhesion:** For quick placement, the camera can magnetically attach to suitable metal surfaces.




The camera offers multiple mounting solutions, including backpack, helmet, and pet collar attachments.



Capture your pet's adventures from their perspective with the dedicated pet collar mount.

## 5. Operating Instructions

The Xilecam Mini Action Cam features a minimalist design with simplified controls. Refer to the included quick start guide for specific button functions if not detailed here.

### 5.1. Power On/Off

- **To Power On:** Press and hold the Power button (location varies, refer to product diagram in included manual) until the indicator light illuminates and the screen turns on.
- **To Power Off:** Press and hold the Power button again until the indicator light turns off and the screen goes blank.

### 5.2. Recording Video

- Ensure a formatted Micro SD card is inserted.
- Power on the camera.
- Press the Record button (refer to product diagram in included manual) to start recording. The indicator light will typically flash or change color to indicate recording is in progress.
- Press the Record button again to stop recording.
- Videos are recorded in 1080p resolution and saved in 5-minute segments. The camera supports continuous loop recording, overwriting the oldest files when the memory card is full.

### 5.3. Viewing and Transferring Files

To view or transfer your recorded videos:

1. **Using the Included Card Reader:** Remove the Micro SD card from the camera. Insert it into the provided multi-functional card reader. Connect the card reader to your computer or an Android smartphone (via OTG support) to access and transfer files.

2. **Direct USB Connection:** Connect the camera directly to your computer using the USB cable. The camera may appear as a removable disk, allowing you to access files.

## 6. Maintenance

Proper maintenance ensures the longevity and optimal performance of your Xilecam Mini Action Cam.

- **Cleaning:** Use a soft, dry cloth to clean the camera body. For the lens, use a specialized lens cleaning cloth and solution. Avoid abrasive materials or harsh chemicals.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Battery Care:** For long-term storage, charge the battery to about 50% to prolong its lifespan. Avoid fully discharging the battery for extended periods.
- **Water Resistance:** The camera is described as water-repellent. This means it can withstand splashes but is not designed for submersion. Avoid exposing it to heavy rain or water immersion.

## 7. Troubleshooting

If you encounter issues with your camera, refer to the following common solutions:

- **Camera Not Turning On:** Ensure the battery is charged. Connect the camera to a power source and try again.
- **Micro SD Card Not Detected:**
  - Ensure the card is inserted correctly and fully clicked into place.
  - Try formatting the card (this will erase all data, back up first).
  - Test with a different, compatible Micro SD card.
- **Poor Video/Audio Quality:**
  - Ensure the lens is clean and free from smudges.
  - Record in well-lit environments for best video quality.
  - For audio, ensure the microphone is not obstructed. Avoid windy conditions if possible.
- **Date/Time Not Saving:** Due to the minimalist design, some models may not retain date/time settings after power off or battery depletion. This is a design characteristic.
- **Cannot Transfer Files to Smartphone:** Ensure your Android smartphone supports OTG (On-The-Go) functionality and that the card reader is properly connected.
- **Camera Freezing/Unresponsive:** Try resetting the camera by pressing and holding the power button for an extended period (e.g., 10-15 seconds) until it powers off.

## 8. Specifications

| Feature | Specification |
| --- | --- |
| Brand | Xilecam |
| Model Name | M300D |

| Feature | Specification |
|---|---|
| Video Capture Resolution | 1080p |
| Photo Sensor Technology | CMOS |
| Flash Memory Type | Micro SD (up to 128GB, 32GB included) |
| Screen Size | 1 Inch |
| Connectivity Technology | USB |
| Color | Black |
| Special Features | Pet leash mount, Easy to carry, Thumb camera, Mini camera, Magnetic adhesion |
| Water Resistance Level | Water Repellent |
| Image Stabilization | Digital |
| Form Factor | Ultra Compact |
| Average Battery Life | 180 Minutes |
| Dimensions (DxWxH) | 64P x 21l x 32H mm |
| Compatible Devices | Personal Computer, Laptop, Smartphone, Tablet |

## 9. Warranty and Support

For warranty information and technical support, please refer to the documentation included with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for warranty claims.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0DKF8MGXK**

More documents and user manuals: **https://manuals.plus/**