RYOBI VACUUM

RYOBI ONE+ HP 18V Brushless Cordless High Capacity Stick Vacuum Kit

Model: VACUUM

Product Overview

The RYOBI 18V ONE+ HP High-Capacity Stick Vacuum Kit is designed for your convenience and maneuverability, weighing only 3 lbs. when in use, making it RYOBI's lightest weight in hand stick vacuum. This vacuum is Pet Rated, equipped with a Wrap Defense roller bar design that minimizes hair wrap up to 9 in. long. ONE+ HP Technology delivers more power, runtime, durability and speed utilizing intelligent brushless motors, advanced electronics and HIGH PERFORMANCE lithium technology for tackling dirt, debris and pet hair. From large debris pick-up to multi-surface cleaning on hard floors and carpets, this vacuum handles it all with ease. The large 1 liter bagless dust cup minimizes the need for frequent emptying. Plus, our tool-free removable dual-roller bars make maintenance a breeze, letting you focus on cleaning, not upkeep. The vacuum's self-standing design offers convenient storing. Illuminate every corner with the built-in LED light for ultimate visibility during your cleaning routine. Replacement filters and roller bars are available online to keep your vacuum running like new. Best of all, it is part of the RYOBI ONE+ system where any 18V ONE+ battery works with any 18-Volt ONE+ product.



Figure 1: The RYOBI ONE+ HP 18V Brushless Cordless High Capacity Stick Vacuum Kit, including the vacuum, battery, and charger.

Package Contents

Verify that all items are included in your package:



Figure 2: Included components: High-Capacity Stick Vacuum, 4Ah High Performance Battery, Charger, and Vacuum Maintenance Tool.

- RYOBI ONE+ HP High-Capacity Stick Vacuum
- 4.0 Ah Battery
- Charger
- Vacuum Maintenance Tool

Setup

1. Battery Charging and Installation

Before first use, fully charge the 4.0 Ah battery using the provided charger. Insert the battery into the designated slot on the vacuum until it clicks securely into place.

2. Assembly

The vacuum typically comes in a few main parts. Connect the handle to the main body, and then attach the floor head. Ensure all connections are firm and secure before operation.

Operating Instructions

Powering On/Off

Locate the power button on the handle. Press it once to turn the vacuum on. Press it again to turn it off.

Adjusting Power Modes

The vacuum features 3 power modes for versatile cleaning. Use the '+' and '-' buttons on the handle to cycle through the different suction strengths. Higher power modes are suitable for deep cleaning or stubborn debris, while lower modes conserve battery life for lighter tasks.

Cleaning Surfaces

This vacuum is designed for multi-surface use, including hard floors, carpets, and rugs. The Wrap Defense roller bar minimizes hair wrap, making it effective for pet hair pick-up.



Figure 3: The vacuum effectively picks up pet fur and hair from various surfaces, including rugs.



Figure 4: The vacuum is capable of picking up both dust and larger debris like cereal or pet food from hard floors.

Maintenance

Emptying the Dust Cup

The vacuum features a 1-liter bagless dust cup. To empty, detach the dust cup from the main unit and dispose of collected debris. It is recommended to empty the dust cup after each use or when it reaches its maximum fill line to maintain optimal suction.

Cleaning Filters

Regularly clean the vacuum's filters to ensure efficient operation. Refer to the specific filter cleaning instructions in the full manual for detailed steps. Replacement filters are available online.

Roller Bar Maintenance

The dual-roller bars are tool-free removable for easy maintenance. Periodically check the roller bars for tangled hair or debris and clean as necessary. This helps prevent hair wrap and maintains cleaning performance. Replacement roller bars are available online.

Troubleshooting

Problem	Possible Cause	Solution
Vacuum not turning on	Battery not charged or improperly installed.	Ensure battery is fully charged and correctly inserted.
Loss of suction	Dust cup full, filters clogged, or blockage in the hose/nozzle.	Empty dust cup, clean/replace filters, check for and remove blockages.
Roller bar not spinning	Hair or debris tangled around the roller bar.	Remove and clean the roller bar, removing any obstructions.

Specifications

Brand: RYOBI

Model Name: VACUUM

Special Feature: Cordless

Filter Type: Cyclonic

Included Components: Battery

Capacity: 1 Liter (Dust Cup)

Form Factor: Stick

Color: Green

Product Dimensions: 28"L x 10"W x 11"H

Item Weight: 14 pounds

Number of Power Levels: 3

Indoor/Outdoor Usage: Indoor

UPC: 033287218493

© 2023 RYOBI. All rights reserved.
For further support, please visit the official RYOBI website or contact customer service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why does my RYOBI ONE+ HP 18V Brushless Cordless Stick Vacuum start and then immediately quit after being used with excessive pet hair?

When your RYOBI ONE+ HP 18V Stick Vacuum starts and then quickly shuts off, it is often due to a safety feature that prevents the motor from overheating when there is a significant blockage...

Read full answer