RYOBI PBLSV747

RYOBI ONE+ HP 18V Brushless Cordless Wet/Dry Stick Mop and Vacuum

Model: PBLSV747

User Manual

Introduction

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your RYOBI ONE+ HP 18V Brushless Cordless Wet/Dry Stick Mop and Vacuum, model PBLSV747. Please read this manual thoroughly before using the product and retain it for future reference.

The RYOBI SWIFTClean Wet/Dry Stick Vac is designed for cleaning sealed hard floors such as hardwood, tile, stone, luxury vinyl plank (LVP), and luxury vinyl tile (LVT). It combines both wet mopping and dry vacuuming capabilities to handle various messes.



Image: The RYOBI ONE+ HP 18V Brushless Cordless Wet/Dry Stick Mop and Vacuum, showcasing its sleek design and integrated cleaning head.

Important Safety Instructions

WARNING:

- Always ensure the product is turned off and the battery removed before performing any adjustments, changing accessories, or storing the tool.
- Do not use the appliance on unsealed floors or carpets. This product is designed for sealed hard floors only.
- Use only RYOBI Hard Surface formulas with your SWIFTClean Wet/Dry Stick Vac. Using other solutions may damage the appliance and void the warranty.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.

- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.

Components and What's Included

Your RYOBI ONE+ HP Wet/Dry Stick Mop and Vacuum (Tool Only) package includes the following items:

- RYOBI ONE+ HP SWIFTClean Wet/Dry Stick Vacuum (PBLSV747)
- 8 oz. Hard Surface Advanced Cleaning Formula
- (2) Roller Bars
- (2) Filters
- Self-Cleaning Stand



Image: Overview of the RYOBI SWIFTClean Wet/Dry Stick Vacuum along with its included accessories: cleaning formula, two roller bars, two filters, and the self-cleaning stand.

Key Features:



Image: A detailed diagram highlighting key features of the RYOBI Wet/Dry Stick Vacuum, including the solution dispersal on/off, MAX mode, LED display, 14 oz. dirty tank, LED light, 22 oz. clean tank, tool-free removable roller bar, self-standing design, and 10" cleaning width.

- **Solution Dispersal On/Off:** Controls the release of cleaning solution.
- **MAX Mode:** Provides an extra boost of suction for tough messes.
- **LED Display:** Indicates vacuum status and settings.
- **14 oz. Dirty Tank:** Collects dirty water and debris.
- **LED Light:** Illuminates the cleaning path.
- **22 oz. Clean Tank:** Holds clean water and cleaning solution.
- **Tool-Free Removable Roller Bar:** Allows for easy cleaning and replacement.
- **Self-Standing Design:** Conveniently stands upright on its own.
- **10" Cleaning Width:** Ensures superior edge cleaning.
- **Compatible with all 18V ONE+ Batteries:** Part of the RYOBI ONE+ System.

Setup and Initial Assembly

1. **Unpacking:** Carefully remove all components from the packaging. Inspect for any damage.
2. **Handle Assembly:** Insert the handle into the main body of the vacuum until it clicks securely into place.
3. **Charging Battery (if applicable):** As this is a "Tool Only" product, ensure you have a compatible RYOBI ONE+ 18V battery and charger. Fully charge the battery before first use according to your battery and charger manual.
4. **Filling the Clean Water Tank:** Remove the clean water tank (22 oz. capacity). Fill it with clean water up to the indicated line, then add the recommended amount of RYOBI Hard Surface Advanced Cleaning Formula. Securely reattach the tank.
5. **Inserting the Battery:** Align the charged RYOBI ONE+ 18V battery with the battery port on the vacuum and slide it in until it locks.

Operating Instructions

Starting the Vacuum:

1. Ensure the clean water tank is filled and the dirty water tank is empty.
2. Press the power button to turn on the vacuum. The LED display will illuminate.
3. Tilt the vacuum back to engage the roller bar and begin cleaning.

Cleaning Modes:

- **Standard Mode:** For everyday cleaning and light messes. The vacuum will dispense solution and pick up debris simultaneously.
- **MAX Mode:** Press the MAX mode button on the handle for increased suction power to tackle stubborn or heavy messes.

Cleaning Technique:

Move the vacuum slowly forward and backward over the sealed hard floor surface. For best results, overlap your cleaning passes slightly. The 10-inch cleaning width allows for superior edge cleaning.



Image: The RYOBI Wet/Dry Stick Vacuum in action, demonstrating its 2-in-1 mop and vacuum capability on a hard floor, effectively cleaning up scattered debris.



Image: A close-up view of the RYOBI Wet/Dry Stick Vacuum's cleaning head, highlighting its ability to perform wall-to-wall superior edge cleaning.

Emptying the Dirty Water Tank:

When the dirty water tank is full, the LED display will indicate it. Turn off the vacuum, remove the dirty water tank, and empty its contents. Rinse the tank with clean water before reattaching.

Maintenance and Care

Self-Clean Cycle:

After each use, place the vacuum on its self-cleaning stand. Activate the self-clean cycle to flush the vacuum with clean water, helping to prevent odors and maintain performance. Refer to the LED display for self-clean cycle initiation.

Cleaning the Roller Bar:

The roller bar is tool-free removable for easy cleaning. Regularly remove the roller bar and rinse it under running water to remove any hair or debris. Allow it to air dry completely before reinserting.

Cleaning the Filter:

The filter should be cleaned regularly to maintain optimal suction. Remove the filter and tap out loose debris. Rinse the filter under water if necessary, and allow it to air dry completely before reinserting. Replace the filter every 3-6 months, or as needed, to ensure peak performance.

Storage:

Store the vacuum in a dry, indoor location. Ensure the clean and dirty water tanks are empty and clean before storage. The self-cleaning stand offers onboard storage for the filter and roller bar.

Troubleshooting

Problem	Possible Cause	Solution
Vacuum not turning on	Battery not charged or not inserted correctly.	Ensure battery is fully charged and properly seated.
Poor suction	Dirty filter; clogged roller bar; full dirty water tank.	Clean or replace filter. Remove and clean roller bar. Empty dirty water tank.
No solution dispensing	Clean water tank empty; solution dispersal switch off.	Refill clean water tank. Ensure solution dispersal is turned on.
Excessive foam	Using incorrect cleaning solution; too much solution.	Use only RYOBI Hard Surface formulas. Ensure correct dilution ratio.

Specifications

Feature	Detail
Model Number	PBLSV747
Power Source	18V ONE+ Battery (Tool Only)
Clean Water Tank Capacity	22 oz.
Dirty Water Tank Capacity	14 oz.

Feature	Detail
Cleaning Width	10 inches
Usage	Sealed Hard Floors (Indoor)
Control Method	Touch
Number of Power Levels	2 (Standard, MAX)

Warranty Information

RYOBI products are backed by a manufacturer's warranty. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your product or visit the official RYOBI website. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, replacement parts, or service, please contact RYOBI Customer Support:

- **Website:** www.ryobitools.com
- **Phone:** Refer to the RYOBI website for regional contact numbers.

When contacting support, please have your product model number (PBLSV747) and serial number (if applicable) ready.

© 2023 RYOBI. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question