Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

acer OMR243

acer Wireless Mouse OMR243 Instruction Manual

Model: OMR243 | Brand: acer

1. Introduction

Thank you for choosing the acer Wireless Mouse OMR243. This lightweight, 2.4GHz wireless mouse is designed for comfort and efficiency, featuring 5 buttons and a fixed 1200 DPI optical sensor. It offers a reliable connection and broad compatibility for various operating systems.

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new wireless mouse.



Image 1.1: The acer Wireless Mouse OMR243.

2. Product Components

The acer Wireless Mouse OMR243 includes the following components:

- Wireless Mouse (with Left Button, Right Button, Scroll Wheel, Forward Button, Backward Button)

- USB-A Receiver (stored inside the mouse battery compartment)

Batteries (2x AAA) are required for operation and are not included.



Image 2.1: Overview of mouse buttons and features.

3. Setup Instructions

Follow these steps to set up your acer Wireless Mouse:

1. **Install Batteries:** Open the battery compartment on the underside of the mouse. Insert two AAA batteries (not included), ensuring correct polarity.
2. **Retrieve USB-A Receiver:** The USB-A receiver is stored within the battery compartment. Carefully remove it.
3. **Connect Receiver:** Insert the USB-A receiver into an available USB-A port on your computer (laptop or desktop).
4. **Power On Mouse:** Locate the power switch on the underside of the mouse and slide it to the 'ON' position. The mouse should now be ready for use.



Image 3.1: Location of battery compartment and USB-A receiver storage.



Image 3.2: Inserting the USB-A receiver into a laptop.

Setup Video Guide

Your browser does not support the video tag.

Video 3.1: A visual guide demonstrating the setup and features of the acer Wireless Mouse.

4. Operating Instructions

The acer Wireless Mouse OMR243 is designed for intuitive use. Here's how to operate its main functions:

- **Left and Right Click:** Perform standard selection and context menu actions. The mouse features a crisp 'clicky' sound.
- **Scroll Wheel:** Use the scroll wheel for vertical navigation through documents and web pages.
- **Forward and Backward Buttons:** Located on the side, these buttons allow for quick navigation through web pages and folders, enhancing efficiency.
- **DPI:** The mouse operates at a fixed 1200 DPI, providing precise cursor control.



Image 4.1: Highlighting the Forward and Backward navigation buttons.



Image 4.2: Demonstrating a comfortable grip on the lightweight mouse.

5. Compatibility

The acer Wireless Mouse OMR243 is compatible with a wide range of operating systems and devices:

- **Operating Systems:** Windows, macOS, Linux, Chrome OS.
- **Device Connection:** Requires a USB-A port. For devices with only USB-C ports, a USB-C to USB-A adapter (not included) is necessary.



Image 5.1: Universal compatibility with various operating systems.

6. Maintenance

To ensure the longevity and optimal performance of your mouse, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the mouse. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the device.
- **Battery Replacement:** Replace AAA batteries when the mouse performance degrades or it stops responding. Always use fresh batteries of the same type.
- **Receiver Storage:** When not in use, especially during travel, store the USB-A receiver securely in its designated slot within the battery compartment to prevent loss.

7. Troubleshooting

If you encounter issues with your acer Wireless Mouse, refer to the following common solutions:

Problem	Solution
Mouse not responding	• Ensure the mouse is powered on. • Check if batteries are correctly installed and have sufficient charge. Replace if necessary. • Verify the USB-A receiver is securely plugged into a working USB-A port on your computer. • Try plugging the receiver into a different USB-A port. • Restart your computer.
Intermittent connection	• Ensure the mouse is within the 32-foot operating range of the receiver. • Minimize obstructions between the mouse and the receiver. • Avoid using the mouse on highly reflective or transparent surfaces.
Cursor movement is erratic	• Clean the optical sensor on the underside of the mouse. • Use the mouse on a suitable surface, preferably a mouse pad.
Forward/Backward buttons not working	These buttons are typically supported by most operating systems and web browsers. Ensure your software is up-to-date. No additional drivers are usually required.

8. Specifications

Feature	Detail
Model Number	OMR243
Dimensions (L x W x H)	4.3 x 2.6 x 0.04 inches

Feature	Detail
Item Weight	1.94 ounces
Connectivity Technology	2.4GHz Wireless (USB-A Receiver)
Movement Detection	Optical
DPI	1200 DPI (Fixed)
Buttons	5 (Left, Right, Scroll Wheel Click, Forward, Backward)
Batteries	2 x AAA (not included)
Durability	Up to 10 million clicks
Operating Range	Up to 32 feet (10 meters)

9. Warranty and Support

For warranty information and technical support, please refer to the documentation included with your product or visit the official acer website. Keep your purchase receipt for warranty claims.

© 2024 acer. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DKSFYTLD

More documents and user manuals: **https://manuals.plus/**