Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl Replacement for FineLife SP-04443, 04398, S04438, NV-06643, 06655, 06885, 06987, 06989

onerbl AC-DC Adapter Instruction Manual

For FineLife Cordless Percussion Massagers (Models: SP-04443, 04398, S04438, NV-06643, 06655, 06885, 06987, 06989)

1. Introduction

This manual provides essential information for the safe and effective use of your onerbl AC-DC Adapter. This adapter is designed as a replacement power supply for specific FineLife Cordless Percussion Massager models, ensuring your device receives the correct power for operation and charging.
Please read this manual thoroughly before using the adapter and retain it for future reference.



Figure 1: The onerbl AC-DC Adapter and its integrated power cord. This image displays the compact black adapter unit with a standard US two-prong plug and the coiled power cable ending in a DC barrel connector.

2. Important Safety Information

WARNING: To reduce the risk of fire, electric shock, or injury, observe the following safety precautions:

- **Indoor Use Only:** This adapter is designed for indoor use in dry locations. Do not expose to rain, moisture, or extreme temperatures.
- **Proper Voltage:** Ensure the wall outlet voltage matches the adapter's input specifications (AC 100-240V).
- **Avoid Overloading:** Do not overload electrical outlets or extension cords.
- **Cable Care:** Do not place heavy objects on the power cord or allow it to be pinched or sharply bent. Keep the

cord away from heat sources.

- **Disconnect Safely:** Always grasp the plug, not the cord, when disconnecting from the power outlet.
- **No Disassembly:** Do not attempt to open or modify the adapter. There are no user-serviceable parts inside.
- **Damage:** If the adapter or cord is damaged, discontinue use immediately and seek a replacement.
- **Over Voltage and Over Heat Protection:** This adapter includes built-in protection features to safeguard against over-voltage and overheating. However, proper usage is still essential.



Figure 2: The label on the adapter showing input specifications and the 'CAUTION INDOOR USE ONLY' warning. The label clearly states 'AC/DC ADAPTOR', 'MODEL:', 'INPUT: 100-240V AC 50/60Hz', and includes safety certifications.

3. Package Contents

Your package should contain the following items:

- 1 x onerbl AC-DC Adapter with integrated power cord

4. Product Specifications

Feature	Specification
Input Voltage	AC 100-240V, 50/60Hz
Output Voltage	DC 12V
Output Current	2000mAh (2A)
Power Output	24W
Cable Length	76 inches (approx. 1.93 meters)
Adapter Dimensions (L x W x H)	3.1 x 2.1 x 1.2 inches (approx. 7.9 x 5.3 x 3.0 cm)
Compatibility	FineLife SP-04443, 04398, S04438, NV-06643, 06655, 06885, 06987, 06989 Cordless Percussion Massagers



Figure 3: The adapter unit with its approximate dimensions labeled. The image shows the adapter's length as 3.1 inches, width as 2.1 inches, and thickness as 1.2 inches.

5. Setup Instructions

1. **Verify Compatibility:** Before connecting, ensure your FineLife Percussion Massager model is listed as compatible with this adapter.
2. **Connect to Device:** Insert the DC barrel connector of the adapter's power cord firmly into the power input port of your FineLife Percussion Massager.
3. **Connect to Power Outlet:** Plug the AC prongs of the adapter into a standard AC 100-240V wall power outlet.
4. **Power On:** Your device should now be receiving power or begin charging its internal battery, depending on its design.



Figure 4: The onerbl AC-DC Adapter plugged into a wall outlet, demonstrating a typical setup. The adapter is shown securely inserted into a white wall socket, with its cable extending downwards.

6. Operating the Adapter

Once connected, the adapter provides continuous power to your FineLife Percussion Massager. If your massager has a rechargeable battery, the adapter will also charge it. Refer to your massager's original instruction manual for specific charging indicators or operational modes.

- The adapter is designed for continuous use within its specified limits.
- It is normal for the adapter to feel slightly warm during operation. If it becomes excessively hot, disconnect it immediately and contact support.

7. Care and Maintenance

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Wipe the adapter with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and power cord for any signs of damage, such as cuts, fraying, or bent prongs. If damage is found, discontinue use.

8. Troubleshooting

Problem	Possible Cause	Solution
Device not powering on or charging.	• Adapter not properly plugged into outlet. • DC connector not fully inserted into device. • Power outlet is not active. • Device issue (not adapter). • Adapter or cable is damaged.	• Ensure adapter is securely plugged into a working wall outlet. • Verify the DC connector is fully seated in the device's port. • Test the outlet with another device. • Consult your massager's manual for troubleshooting. • Inspect adapter and cable for damage. If damaged, replace.
Adapter feels excessively hot.	• Overload or short circuit. • Poor ventilation.	• Immediately disconnect the adapter. Ensure the device is compatible and not drawing excessive power. • Ensure the adapter is in a well-ventilated area. If the issue persists, discontinue use.

9. Warranty and Support

onerbl products are manufactured to high-quality standards. This product comes with a standard limited warranty against defects in materials and workmanship. Please refer to the product packaging or the seller's website for specific warranty terms and duration.
For technical support, warranty claims, or general inquiries, please contact your retailer or the onerbl customer service team through the contact information provided at the point of purchase.

© 2024 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DKT5L4H8

More documents and user manuals: **https://manuals.plus/**