Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY Network 21.1

New Replacement IR UHF 21.1 Remote Control

Instruction Manual

Brand: ALLIMITY | Model: Network 21.1

Product Overview

This manual provides instructions for the ALLIMITY New Replacement IR UHF 21.1 Remote Control, designed to be compatible with Dish Network 21.1 Remote Controllers. This remote offers a straightforward replacement solution without the need for complex programming.
Key features include:

- Direct replacement for Dish Network 21.1 remote.
- No programming or pairing required; ready to use after battery insertion.
- Supports four modes: SAT, TV, DVD, and AUX for versatile control.
- Operates on 2 AAA batteries (not included).





Figure 1: Front view of the ALLIMITY Replacement IR UHF 21.1 Remote Control, showing all buttons and layout.

Setup

To begin using your new remote control, follow these simple steps:

1. **Install Batteries:** Locate the battery compartment on the back of the remote control. Slide the battery cover downwards to open it. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
2. **Close Battery Compartment:** Replace the battery cover by sliding it back into place until it clicks securely.

3. **Initial Operation:** The remote control is designed to work immediately after battery insertion. No programming or pairing is required for basic functionality.





Figure 2: Back view of the remote control with the battery compartment open, illustrating the correct orientation for AAA battery insertion.

Operating Instructions

The remote control features four distinct modes to control various devices: SAT, TV, DVD, and AUX. Before operating your device, ensure you select the correct mode.

- **Mode Selection:** Press the desired mode button (SAT, TV, DVD, or AUX) located at the top of the remote. The corresponding indicator light may illuminate briefly to confirm selection.
- **Basic Functions:**
  - **Power:** Press the **Power** button to turn your device on or off.
  - **Volume Control:** Use the **Volume Up** and **Volume Down** buttons to adjust audio levels.
  - **Channel Navigation:** Use the **Channel Up** and **Channel Down** buttons to change channels.
  - **Number Pad:** Use the numeric keypad (0-9) to directly enter channel numbers or other numerical inputs.
  - **Navigation Pad:** The central directional pad (up, down, left, right) and **SELECT** button are used for menu navigation and selection.
  - **Mute:** Press the **Mute** button to silence audio.
  - **Menu/Guide:** Access device menus or program guides using the **MENU** and **GUIDE** buttons.
  - **DVR/Playback Controls:** Buttons such as **PLAY**, **PAUSE**, **STOP**, **RECORD**, **SKIP BACK**, and **SKIP FWD** are available for controlling DVR or media playback functions.
- **Line of Sight:** Ensure there is a clear, unobstructed path between the remote control's infrared (IR) emitter and your device's IR receiver for optimal performance.

Maintenance

Proper care and maintenance will extend the life of your remote control:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as they can damage the remote's finish or buttons.
- **Battery Replacement:** Replace batteries when the remote's performance degrades or if it stops responding. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** When not in use for extended periods, it is recommended to remove the batteries to prevent leakage, which can damage the remote. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter issues with your remote control, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote is not responding.	Batteries are dead or incorrectly inserted.	Replace batteries with new AAA alkaline batteries, ensuring correct polarity (+/-).
Remote only controls some functions or devices.	Incorrect mode selected.	Press the correct mode button (SAT, TV, DVD, AUX) for the device you wish to control.
Remote works intermittently or only at close range.	Weak batteries or obstruction.	Replace batteries. Ensure there is nothing blocking the line of sight between the remote and the device's IR receiver.
Remote does not control my specific Dish Network receiver.	Compatibility issue or specific receiver model.	This remote is designed for Dish Network 21.1 compatible systems. Verify your receiver model. While no programming is typically needed, some advanced functions might require specific receiver settings.

Specifications

Feature	Detail
Product Dimensions	6 x 2 x 0.5 inches
Item Weight	5.3 ounces
Model Number	Network 21.1
Brand	ALLIMITY
Power Source	2 x AAA Batteries (not included)
Special Feature	Ergonomic design
Color	Black
Max Number of Supported Devices	18 (via mode selection)
Compatible Devices	Television, Satellite Receiver, DVD Player, AUX devices (when configured)

Warranty and Support

For any questions, technical assistance, or warranty inquiries regarding your ALLIMITY remote control, please contact the seller or manufacturer directly through your purchase platform. Please refer to your purchase documentation for specific warranty terms and contact information.

© 2025 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DKTGGL8D

More documents and user manuals: **https://manuals.plus/**