DEWENWILS B0DLGQ37GP

DEWENWILS Outdoor & Indoor Remote Control Outlet Switch User Manual

Model: B0DLGQ37GP

Introduction

This manual provides instructions for the safe and efficient use of your DEWENWILS Outdoor & Indoor Remote Control Outlet Switch. Please read this manual thoroughly before installation and operation, and retain it for future reference.

Product Overview

The DEWENWILS Remote Control Outlet Switch allows you to wirelessly control electrical appliances both indoors and outdoors. It features a strong RF signal for reliable operation through walls and doors, and is designed for ease of use with a simple plug-and-play setup.



Image: Three DEWENWILS outdoor remote control outlets with a remote control. Each outlet has two grounded AC receptacles and a short power cord with a 3-prong plug.



Image: Five compact white DEWENWILS indoor remote control outlets and two white remote controls. Each indoor outlet has a single grounded AC receptacle.

Setup Instructions

1. **Unpack the Device:** Carefully remove the remote control outlet(s) and remote transmitter from the packaging.
2. **Placement:** For outdoor use, ensure the outlet is placed in a location protected from direct heavy rain or submersion, despite its IP5X rating. For optimal signal range, avoid placing the receiver directly behind large metal objects or thick concrete walls, although the RF signal is designed to penetrate common obstacles.

3. **Plug In the Receiver:** Insert the remote control outlet receiver into a standard 3-prong electrical wall outlet.
4. **Connect Appliance:** Plug the appliance you wish to control into the receptacle(s) on the remote control outlet receiver. Ensure the appliance is switched to the 'ON' position if it has its own power switch.
5. **Initial Operation:** The units are pre-programmed for immediate use. No additional pairing or programming is typically required for initial setup.

Operating Instructions

The DEWENWILS Remote Control Outlet Switch offers both remote and manual control options.

Using the Remote Control

- **Power On/Off:** Press the corresponding 'ON' button on the remote control to turn on the connected appliance. Press the 'OFF' button to turn it off.
- **Range:** The remote control operates effectively up to 100 feet (30 meters) in open areas. The strong RF signal allows it to work through walls and doors without requiring a direct line of sight.
- **Expandability:** Additional DEWENWILS remote controls and sockets can be added to expand your system or customize combinations. Refer to the specific instructions provided with additional units for pairing procedures if necessary.
- **Interference:** The advanced technology minimizes interference with other RF remote control systems, ensuring reliable operation.



Image: A hand holding a DEWENWILS remote control, pressing the 'ON' button, with an outdoor remote outlet connected to holiday decorations in the background.

Manual Control

Each receiver unit is equipped with a manual ON/OFF button. Press this button to toggle the power to the connected appliance directly at the outlet.

Maintenance

- **Cleaning:** Disconnect the outlet from the power source before cleaning. Wipe the exterior with a soft, dry cloth.

Do not use harsh chemicals or abrasive cleaners.

- **Storage:** When not in use for extended periods, store the device in a cool, dry place away from direct sunlight.
- **Remote Battery Replacement:** If the remote control's indicator light does not illuminate or its range decreases significantly, the battery may need replacement. Typically, these remotes use a standard coin cell battery (e.g., CR2032). Refer to the remote's casing for specific battery type and replacement instructions.

Troubleshooting

- **Appliance Not Responding:**
  - Ensure the remote control outlet is securely plugged into a functioning wall outlet.
  - Verify that the connected appliance is properly plugged into the remote control outlet and its own power switch (if any) is in the 'ON' position.
  - Check the remote control's battery. Replace if necessary.
  - Ensure the remote control is within the effective operating range (up to 100 feet).
- **Intermittent Operation:**
  - While designed for minimal interference, extreme electromagnetic interference from other devices might affect performance. Try relocating the outlet or the remote.
  - Obstructions like thick concrete or multiple walls can reduce range. Try moving closer to the receiver.
- **Indicator Light Not On:**
  - Confirm the wall outlet has power. Test with another appliance.
  - If the remote's indicator light is off, replace the battery.

Specifications

Feature	Specification
Brand	DEWENWILS
Model	B0DLGQ37GP
Rated Current	15A Resistive
Rated Power	1,875W Resistive
Tungsten Rating	5A / 1,000W Tungsten
Motor Rating	1/2HP
Control Range	Up to 100 feet (30 meters) in open areas
Operation Mode	ON-ON-ON
Contact Type	Normally Open
Connector Type	2 Pin Plug
Terminal	Quick-connect
Circuit Type	Parallel

Mounting Type	Surface Mount
Actuator Type	Push Button
Contact Material	Copper
International Protection Rating	IP5X

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product or visit the official DEWENWILS website. You can typically find contact information and frequently asked questions on their support pages.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question